

BS2_GetFireAlarmZone 1
..... 1
..... 1
..... 1
..... 1

BS2_GetFireAlarmZone

가 .

```
#include "BS_API.h"

int BS2_GetFireAlarmZone(void* context, uint32_t deviceId, uint32_t* zoneIds, uint32_t zoneIdCount, BS2FireAlarmZone** zoneObj, uint32_t* numZone);
```

[BS2FireAlarmZone](#)

- [In] *context* : Context
- [In] *deviceId* :
- [In] *zoneIds* : 가 fire alarm zone id
- [In] *zoneIdCount* : fire alarm zone id
- [Out] *zoneObj* : fire alarm zone
- [Out] *numZone* : fire alarm zone



BS_SDK_SUCCESS , 가

[BS2_GetAllFireAlarmZone](#)
[BS2_GetFireAlarmZoneStatus](#)

[BS2_GetAllFireAlarmZoneStatus](#)
[BS2_SetFireAlarmZone](#)
[BS2_SetFireAlarmZoneAlarm](#)
[BS2_RemoveFireAlarmZone](#)
[BS2_RemoveAllFireAlarmZone](#)

From:

<https://kb.supremainc.com/kbtest/> - **BioStar Device SDK**

Permanent link:

https://kb.supremainc.com/kbtest/doku.php?id=ko:bs2_getfirealarmzone&rev=1468285995

Last update: **2016/07/12 10:13**