

**BS2\_GetFireAlarmZoneStatus** ..... 1

..... 1

..... 1

..... 1

..... 1

# BS2\_GetFireAlarmZoneStatus

가 .

```
#include "BS_API.h"

int BS2_GetFireAlarmZoneStatus(void* context, uint32_t deviceId, uint32_t* zoneIds, uint32_t zoneIdCount, BS2ZoneStatus** zoneStatusObj, uint32_t* numZoneStatus);
```

BS2ZoneStatus

- [In] *context* : Context
- [In] *deviceId* :
- [In] *zoneIds* : 가 fire alarm zone id
- [In] *zoneIdCount* : fire alarm zone id
- [Out] *zoneStatusObj* : zone status
- [Out] *numZoneStatus* : zone status



BS\_SDK\_SUCCESS , 가

[BS2\\_GetFireAlarmZone](#)  
[BS2\\_GetAllFireAlarmZone](#)

[BS2\\_GetAllFireAlarmZoneStatus](#)  
[BS2\\_SetFireAlarmZone](#)  
[BS2\\_SetFireAlarmZoneAlarm](#)  
[BS2\\_RemoveFireAlarmZone](#)  
[BS2\\_RemoveAllFireAlarmZone](#)

From:

<https://kb.supremainc.com/kbtest/> - **BioStar Device SDK**

Permanent link:

[https://kb.supremainc.com/kbtest/doku.php?id=ko:bs2\\_getfirealarmzonestatus](https://kb.supremainc.com/kbtest/doku.php?id=ko:bs2_getfirealarmzonestatus)

Last update: **2016/07/12 10:07**