

BS2_GetLiftLockUnlockZoneStatus 1
..... 1
..... 1
..... 1
..... 1

BS2_GetLiftLockUnlockZoneStatus

[+ 2.7.0] Lift / 가 .

```
#include "BS_API.h"

int BS2_GetLiftLockUnlockZoneStatus(void* context, uint32_t deviceId,
uint32_t* zoneIds, uint32_t zoneIdCount, BS2ZoneStatus** zoneStatusObj,
uint32_t* numZoneStatus);
```

BS2ZoneStatus

- [In] *context* : Context
- [In] *deviceId* :
- [In] *zoneIds* : 가 Lift lock/unlock zone id
- [In] *zoneIdCount* : Lift lock/unlock zone id
- [Out] *zoneStatusObj* : zone status
- [Out] *numZoneStatus* : zone status

zoneStatusObj [BS2_ReleaseObject](#)

BS_SDK_SUCCESS , 가

[BS2_GetLiftLockUnlockZone](#)
[BS2_GetAllLiftLockUnlockZone](#)

[BS2_GetAllLiftLockUnlockZoneStatus](#)
[BS2_SetLiftLockUnlockZone](#)
[BS2_SetLiftLockUnlockZoneAlarm](#)
[BS2_RemoveLiftLockUnlockZone](#)
[BS2_RemoveAllLiftLockUnlockZone](#)

From:

<https://kb.supremainc.com/kbtest/> - **BioStar Device SDK**

Permanent link:

https://kb.supremainc.com/kbtest/doku.php?id=ko:bs2_getliftlockunlockzonestatus

Last update: **2020/07/21 21:05**