

BS2_SetFireAlarmZoneAlarm 1
..... 1
..... 1
..... 1
..... 1

[Zone Control API](#) > [BS2_SetFireAlarmZoneAlarm](#)

BS2_SetFireAlarmZoneAlarm

```
#include "BS_API.h"

int BS2_SetFireAlarmZoneAlarm(void* context, uint32_t deviceId, uint8_t
alarmed, uint32_t* zoneIds, uint32_t zoneIdCount);
```

- [In] *context* : Context
- [In] *deviceId* :
- [In] *alarmed* :
- [In] *zoneIds* : fire alarm zone id
- [In] *zoneIdCount* : fire alarm zone id

BS_SDK_SUCCESS , 가

[BS2_GetFireAlarmZone](#)
[BS2_GetAllFireAlarmZone](#)
[BS2_GetFireAlarmZoneStatus](#)
[BS2_GetAllFireAlarmZoneStatus](#)
[BS2_SetFireAlarmZone](#)
[BS2_RemoveFireAlarmZone](#)
[BS2_RemoveAllFireAlarmZone](#)

From:
<https://kb.supremainc.com/kbtest/> - **BioStar Device SDK**

Permanent link:
https://kb.supremainc.com/kbtest/doku.php?id=ko:bs2_setfirealarmzonealarm

Last update: **2016/02/02 14:32**

