

Table of Contents

- BS2_GetAllInterlockZoneStatus** 1
- Declaration 1
- Parameter 1
- Return Value 1
- See Also 1

[Zone Control API](#) > [BS2_GetAllInterlockZoneStatus](#)

BS2_GetAllInterlockZoneStatus

[+ V2.6.0] Gets all Interlock zone's status information.

Declaration

```
#include "BS_API.h"

int BS2_GetAllInterlockZoneStatus(void* context, uint32_t deviceId,
BS2ZoneStatus** zoneStatusObj, uint32_t* numZoneStatus);
```

[BS2ZoneStatus Structure](#)

Parameter

- [In] *context* : Context
- [In] *deviceId* : Device ID
- [In] *zoneIds* : Interlock zone ID list trying to get
- [In] *zoneIdCount* : Size of Interlock zone ID list
- [Out] *zoneStatusObj* : Pointer to store the zone status list
- [Out] *numZoneStatus* : Number of zone status list

NOTE

The *zoneObj* variable needs to return the memory to the system by the [BS2_ReleaseObject](#) function after being used.

Return Value

If successfully done, `BS_SDK_SUCCESS` will be returned.

If there is an error, the corresponding error code will be returned.

See Also

[BS2_GetInterlockZone](#)

[BS2_GetInterlockZoneStatus](#)

[BS2_SetInterlockZone](#)
[BS2_SetInterlockZoneAlarm](#)
[BS2_RemoveInterlockZone](#)
[BS2_RemoveAllInterlockZone](#)

From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar 2 Device SDK**

Permanent link:

http://kb.supremainc.com/bs2sdk/doku.php?id=en:bs2_getallinterlockzonestatus

Last update: **2018/03/25 14:01**