

# Table of Contents

How to Configure Xpass D2 .....	1
Adding as a Slave Device .....	1
Using the device as a Wiegand Reader .....	1


[System Configuration](#), [BioStar 2](#), [Xpass D2](#)

# How to Configure Xpass D2

Xpass D2 is a new device introduced with BioStar 2.6. It is a dummy reader for reading cards, which means it doesn't perform data matching on the device. The device can be used as slave device, or a Wiegand reader to send Wiegand output. The device sends out a Wiegand signal with the default 26bit format and the Wiegand configuration will be done with a separate tool (to be released in May of 2018).

## Adding as a Slave Device


You will need a master device to add the slave D2 device. Refer to the article below to learn how to search a slave device. [RS485 Mode \(Master, Default, Slave\)](#)




## Using the device as a Wiegand Reader

If you have already used the device as a slave device before, you must reset the device to use it as a Wiegand reader (sending Wiegand output).


1. Delete the device from BioStar 2 client as a slave device.



2. Detach the metal bracket from the device.
3. Press the reset button.



4. Use the device as a Wiegand reader by adding it as a **Wiegand Device** on a master device.



You cannot use the device as a slave device and use Wiegand output at the same time.

From:  
<https://kb.supremainc.com/knowledge/> -  
Permanent link:  
[https://kb.supremainc.com/knowledge/doku.php?id=en:how\\_to\\_configure\\_xpass\\_d2&rev=1525238661](https://kb.supremainc.com/knowledge/doku.php?id=en:how_to_configure_xpass_d2&rev=1525238661)  
Last update: **2018/05/02 14:24**