

Table of Contents

How to Configure Xpass D2	1
Adding as a Slave Device	1
Using the device as a Wiegand Reader	1

[System Configuration](#), [BioStar 2](#), [Xpass D2](#)

How to Configure Xpass D2

Xpass D2 is a new device introduced with BioStar 2.6.

It is a dummy reader for reading cards, which means it doesn't perform data matching on the device.

The device can be used as slave device, or a Wiegand reader to send Wiegand output.


The device sends out a Wiegand signal with the default 26bit format and the Wiegand configuration will be done with a separate tool (to be released in May of 2018).

Adding as a Slave Device

You will need a master device to add the slave D2 device.

Refer to the article below to learn how to search a slave device.


[RS485 Mode \(Master, Default, Slave\)](#)



Using the device as a Wiegand Reader


If you have already used the device as a slave device before, you must reset the device to use it as a Wiegand reader (sending Wiegand output).

1. Delete the device from BioStar 2 client as a slave device.




2. Detach the metal bracket from the device.

3. Press the reset button.



4. Use the device as a Wiegand reader by adding it as a **Wiegand Device** on a master device.



You cannot use the device as a slave device and use Wiegand output at the same time.

From:
<http://kb.supremainc.com/knowledge/> -

Permanent link:
http://kb.supremainc.com/knowledge/doku.php?id=en:how_to_configure_xpass_d2&rev=1525238661

Last update: **2018/05/02 14:24**