

Table of Contents

How To Cleanly Use And Disinfect Suprema Products	1
Product disinfecting recommendations:	1

Fingerprint sensor, Disinfection

How To Cleanly Use And Disinfect Suprema Products

Product disinfecting recommendations:



Use rubbing alcohol (containing 70% Isopropyl alcohol) and a clean, non-abrasive cloth like lens wipe.



Moisten the cloth or the wipe with a proper amount of rubbing alcohol and gently clean all exposed surfaces including fingerprint sensor.



- Be sure to read and use the cautions for use of alcohol purchased.
- Be careful not to get alcohol into the product when cleaning the surface of the product. Disinfecting products should only be applied to exposed surfaces.
- Contact Suprema for approval to use specific cleaning products.
- Do not apply liquid directly to the surface of the product.
- Do not use any form of abrasive cleaner to painted or plastic surfaces.

From:
<https://kb.supremainc.com/knowledge/> -

Permanent link:
https://kb.supremainc.com/knowledge/doku.php?id=en:tc_technology_suprema_product_disinfection_guide

Last update: **2020/03/17 13:53**