How to Set Up the Timed Anti Passback

Timed Anti PassBack restricts frequent entries by setting an initialization time for anti-passback. This feature prevents users from re-authenticating with the same device immediately after access authentication, ensuring a defined period must elapse before re-authentication is possible.



Timed Anti PassBack can be used without a separate BioStar 2 license.

Setting Timed Anti PassBack on the Door

- 1 Click DOOR.
- 2 Click ADD DOOR and set Information, Configuration, Option, etc.

Information			
Name Description		• Group	All Doors 💌
Configuration			
 Entry Device Door Relay(*) 	BioStation 2a 50993389 (192.168.120.9) Relay 0 of BioStation 2a 50993389 (192.168.120.9) Devi		
Exit Button	Input Port 0 of BioStation 2a 50993389 (192.168.120.9) 💌	+ Switch	Normally Open
Door Sensor	Input Port 1 of BioStation 2a 50993389 (192.168.120.9) 💌	Does not activate rel Switch Use sensor when Entry Confirmed APB enable	lay OFF Normally Open y OFF 1
Option			
Open • Open Time	3 sec	Lock when door is closed Use Automatic Door	OFF OFF
Dual Authentication • Device	No device 💌		
Anti-Tailgating • Sensor	None •		

▶ The image above is an example screen and may differ from the actual screen.



- If the door is set up with a wireless door lock, Timed Anti PassBack cannot be used.
- Timed Anti PassBack can only be set when Entry Device or Exit Device and Door Relay are selected.
 - Since this feature is used to enhance door security, it can be set even when one of the Entry Device or Exit Device is selected.
- Timed Anti PassBack and Use sensor when Entry Confirmed APB enabled features cannot be used at the same time.
- Timed Anti PassBack and Anti PassBack features cannot be used at the same time.

3 Set Timed Anti PassBack to Use and enter the desired reset time.

Timed Anti PassBack					
Timed APB	Use	Reset Time	10	min.	

▶ The image above is an example screen and may differ from the actual screen.

- **Reset TIme**: The input unit is in minutes (min.), with a default setting of 10 minutes. Users can input a time within the range of 0 to 60 minutes.
- **4** Click **OK** to save the settings.

If Timed Anti PassBack occurs after setup, you can check the event and image logs in the MONITORING menu.



© 2024 Suprema Inc. Suprema and identifying product names and numbers herein are registered trade marks of Suprema, Inc. All non-Suprema brands and product names are trademarks or registered trademarks of their respective companies. Product appearance, build status and/or specifications are subject to change without notice.