Zone Control API > BS2_CheckGlobalAPBViolationByDoorOpen

BS2_CheckGlobalAPBViolationByDoorOpen

[+ 2.7.0]

```
#include "BS_API.h"

int BS2_CheckGlobalAPBViolationByDoorOpen(void* context, uint32_t deviceId,
uint16_t seq, int handleResult, uint32_t zoneID);
```

- [In] *context* : Context
- [In] *deviceId* :
- [In] *seq* :
- [In] *handleResult* : (BS_SDK_SUCCESS or BS_SDK_ERROR_XXX)
- [In] *zoneID* : id

> OnCheckGlobalAPBViolationByDoorOpen
> .

BS_SDK_SUCCESS ,

.

BS2_SetGlobalAPBViolationByDoorOpenHandler

From:
<http://kb.supremainc.com/bs2sdk./> - **BioStar Device SDK**

Permanent link:
http://kb.supremainc.com/bs2sdk./doku.php?id=ko:bs2_checkglobalapbviolationbydooropen

Last update: **2020/07/21 20:33**