

**BS2\_ClearDeviceZoneAccessRecord** ..... 1  
..... 1  
..... 1  
..... 1  
..... 1

[Zone Control API](#) > [BS2\\_ClearDeviceZoneAccessRecord](#)

---

## BS2\_ClearDeviceZoneAccessRecord

Ethernet

```
#include "BS_API.h"

int BS2_ClearDeviceZoneAccessRecord(void* context, uint32_t deviceId,
uint32_t zoneID, char* uids, uint32_t uidCount);
```

- [In] *context* : Context
- [In] *deviceId* :
- [In] *zoneID* :
- [In] *uids* : user ID
- [In] *uidCount* : user ID

BS\_SDK\_SUCCESS , 가

[BS2\\_GetDeviceZone](#)  
[BS2\\_GetAllDeviceZone](#)  
[BS2\\_SetDeviceZone](#)  
[BS2\\_RemoveDeviceZone](#)  
[BS2\\_SetAntiPassbackZone](#)  
[BS2\\_RemoveAllDeviceZone](#)  
[BS2\\_SetDeviceZoneAlarm](#)  
[BS2\\_ClearAllDeviceZoneAccessRecord](#)

From:  
<http://kb.supremainc.com/bs2sdk/> - **BioStar Device SDK**

Permanent link:  
[http://kb.supremainc.com/bs2sdk./doku.php?id=ko:bs2\\_cleardevicezoneaccessrecord&rev=1504534199](http://kb.supremainc.com/bs2sdk./doku.php?id=ko:bs2_cleardevicezoneaccessrecord&rev=1504534199)

Last update: **2017/09/04 23:09**

