

BS2_RemoveAccessGroupEntranceLimit 1

..... 1

..... 1

..... 1

..... 1

BS2_RemoveAccessGroupEntranceLimit

```
#include "BS_API.h"

int BS2_RemoveAccessGroupEntranceLimit(void* context, BS2_DEVICE_ID
deviceId, const BS2_ZONE_ID* Ids, uint32_t IdCount);
```

- [In] *context* : Context
- [In] *deviceId* :
- [In] *Ids* : device zone id
- [In] *IdCount* : device zone id

BS_SDK_SUCCESS , 가

- [BS2_GetAccessGroupEntranceLimit](#)
- [BS2_GetAllAccessGroupEntranceLimit](#)
- [BS2_SetAccessGroupEntranceLimit](#)
- [BS2_RemoveAllAccessGroupEntranceLimit](#)

From: <https://kb.supremainc.com/bs2sdk/> - **BioStar Device SDK**

Permanent link: https://kb.supremainc.com/bs2sdk/doku.php?id=ko:bs2_removeaccessgroupentrancelimit&rev=1504535729

Last update: **2017/09/04 23:35**