

BS2_SetTimedAntiPassbackZone 1
..... 1
..... 1
..... 1
..... 1

[Zone Control API](#) > [BS2_SetTimedAntiPassbackZone](#)

BS2_SetTimedAntiPassbackZone

```
#include "BS_API.h"

int BS2_SetTimedAntiPassbackZone(void* context, uint32_t deviceId,
BS2TimedAntiPassbackZone* zones, uint32_t zoneCount);
```

[BS2TimedAntiPassbackZone](#)

- [In] *context* : Context
- [In] *deviceId* :
- [In] *zones* : timed anti-passback zone
- [In] *zoneCount* : timed anti-passback zone

BS_SDK_SUCCESS , 가

[BS2_GetTimedAntiPassbackZone](#)
[BS2_GetAllTimedAntiPassbackZone](#)
[BS2_GetTimedAntiPassbackZoneStatus](#)
[BS2_GetAllTimedAntiPassbackZoneStatus](#)
[BS2_SetTimedAntiPassbackZoneAlarm](#)
[BS2_RemoveTimedAntiPassbackZone](#)
[BS2_RemoveAllTimedAntiPassbackZone](#)
[BS2_ClearTimedAntiPassbackZoneStatus](#)
[BS2_ClearAllTimedAntiPassbackZoneStatus](#)

From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar Device SDK**

Permanent link:

http://kb.supremainc.com/bs2sdk/doku.php?id=ko:bs2_settimedantipassbackzone

Last update: **2016/07/12 09:42**