

Table of Contents

BS2_GetAllScheduledLockUnlockZone	1
Declaration	1
Parameter	1
Return Value	1
See Also	1

[Zone Control API](#) > [BS2_GetAllScheduledLockUnlockZone](#)

BS2_GetAllScheduledLockUnlockZone

Retrieves all Scheduled Lock/Unlock zones.

Declaration

```
#include "BS_API.h"

int BS2_GetAllScheduledLockUnlockZone(void* context, uint32_t deviceId,
BS2ScheduledLockUnlockZone** zoneObj, uint32_t* numZone);
```

[See BS2ScheduledLockUnlockZone Structure](#)

Parameter

- [In] *context* : Context
- [In] *deviceId* : Device ID
- [Out] *zoneObj* : Scheduled Lock/Unlock zone list pointer
- [Out] *numZone* : Number of Scheduled Lock/Unlock zones

NOTE

The *zoneObj* variable needs to return the memory to the system by the [BS2_ReleaseObject](#) function after being used.

Return Value

If successfully done, `BS_SDK_SUCCESS` will be returned.
If there is an error, the corresponding error code will be returned.

See Also

[BS2_GetScheduledLockUnlockZone](#)
[BS2_GetScheduledLockUnlockZoneStatus](#)
[BS2_GetAllScheduledLockUnlockZoneStatus](#)
[BS2_SetScheduledLockUnlockZone](#)

[BS2_SetScheduledLockUnlockZoneAlarm](#)
[BS2_RemoveScheduledLockUnlockZone](#)
[BS2_RemoveAllScheduledLockUnlockZone](#)

From:

<https://kb.supremainc.com/bs2sdk/> - **BioStar Device SDK**

Permanent link:

https://kb.supremainc.com/bs2sdk/doku.php?id=en:bs2_getallscheduledlockunlockzone

Last update: **2016/07/12 09:47**