

Table of Contents

BS2_GetOsdpStandardActionConfig	1
Declaration	1
Parameter	1
Return Value	1
See Also	1
Sample Code(C++)	1
Sample Code (C#)	2

[Configuration API](#) > [BS2_GetOsdpStandardActionConfig](#)

BS2_GetOsdpStandardActionConfig

[+ 2.9.1] Get the LED/buzzer settings for each action of the OSDP device.

Declaration

```
#include "BS_API.h"

int BS2_GetOsdpStandardActionConfig(void* context, uint32_t deviceId,
BS2OsdpStandardActionConfig* config);
```

[See BS2OsdpStandardActionConfig Structure](#)

Parameter

- [In] *context* : Context
- [In] *deviceId* : Device Identifier
- [In] *config* : Pointer to store LED/buzzer information of OSDP device

Return Value

If successfully done, BS_SDK_SUCCESS will be returned. If there is an error, the corresponding error code will be returned.

See Also

[BS2_SetOsdpStandardActionConfig](#)

Sample Code(C++)

[sample_getosdpstandardactionconfig.cpp](#)

```
int sdkResult = BS2_GetOsdpStandardActionConfig(context_, id, &config);
if (BS_SDK_SUCCESS != sdkResult)
    printf("BS2_GetOsdpStandardActionConfig call failed: %d",
sdkResult);
```

```
return sdkResult;
```

Sample Code (C#)

[sample_getosdpstandardactionconfig.cs](#)

```
BS2ErrorCode result =  
(BS2ErrorCode)API.BS2_GetOsdpStandardActionConfig(sdkContext, deviceID,  
out config);  
if (result != BS2ErrorCode.BS_SDK_SUCCESS)  
    Console.WriteLine("Got error({0}).", result);  
else  
    Console.WriteLine("Call success.");  
return result;
```

From:

<https://kb.supremainc.com/bs2sdk/> - **BioStar Device SDK**

Permanent link:

https://kb.supremainc.com/bs2sdk/doku.php?id=en:bs2_getosdpstandardactionconfig

Last update: **2023/02/28 14:59**