Table of Contents

USB Exported Control API > BS2_GetUserInfosExFromDirWithKey

BS2_GetUserInfosExFromDirWithKey

[+2.8.2] Gets the user information corresponding to the user identifier from the data extracted by USB.

Declaration

```
#include "BS_API.h"

int BS2_GetUserInfosExFromDirWithKey(void* context, const char* szDir, char*
uids, uint32_t uidCount, BS2UserBlobEx* userBlob, const BS2EncryptKey* key);
```

> View of the structure BS2UserBlobEx

Parameters

- [In] *context* : Context
- [In] *szDir* : Data storage path
- [In] *uids* : List of user identifiers to be imported
- [In] *uidCount* : Number of user identifiers
- [Out] *userBlob* : Pointer to store user information
- [In] *key* : Encryption key and the key value specified by BS2_SetDataEncryptKey

Return value

Returns BS_SDK_SUCCESS if performed successfully, or a corresponding error code if an error occurs.

Watch Together

BS2_GetUserDatabaseInfoFromDirWithKey
BS2_GetUserListFromDirWithKey
BS2_GetUserInfosFromDirWithKey
BS2_GetUserDatasFromDirWithKey
BS2_GetUserDatasExFromDirWithKey
BS2_GetLogFromDirWithKey
BS2_GetLogBlobFromDirWithKey
BS2_GetFilteredLogFromDirWithKey

From:
<http://kb.supremainc.com/bs2sdk/> - **BioStar Device SDK**

Permanent link:
http://kb.supremainc.com/bs2sdk/doku.php?id=en:bs2_getuserinfosexfromdirwithkey&rev=1650245648

Last update: **2022/04/18 10:34**