

# Table of Contents

<b>BS2_GetUserInfosFromDir</b> .....	1
Declaration .....	1
Parameter .....	1
Return Value .....	1
See Also .....	1

User Management API > [BS2\\_GetUserInfosFromDir](#)

---

## BS2\_GetUserInfosFromDir

Gets the user information of the given user ID from storage path in device.

### Declaration

```
#include "BS_API.h"

int BS2_GetUserInfosFromDir(void* context, const char* szDir, char* uids,
uint32_t uidCount, BS2UserBlob* userBlob);
```

[See BS2UserBlob Structure](#)

### Parameter

- [In] *context* : Context
- [In] *szDir* : Storage path in device
- [In] *uids* : User ID list trying to get
- [In] *uidCount* : Number of user ID
- [Out] *userBlob* : Pointer to store the user information

### Return Value

If successfully done, `BS_SDK_SUCCESS` will be returned.  
If there is an error, the corresponding error code will be returned.

### See Also

[BS2\\_GetUserListFromDir](#)

[BS2\\_GetUserInfosExFromDir](#)

From:  
<http://kb.supremainc.com/bs2sdk/> - **BioStar Device SDK**

Permanent link:  
[http://kb.supremainc.com/bs2sdk/doku.php?id=en:bs2\\_getuserinfosfromdir&rev=1504591339](http://kb.supremainc.com/bs2sdk/doku.php?id=en:bs2_getuserinfosfromdir&rev=1504591339)

Last update: **2017/09/05 15:02**

