

BS2_GetAllAntiPassbackZoneStatus 1
..... 1
..... 1
..... 1
..... 1

BS2_GetAllAntiPassbackZoneStatus

가 .

```
#include "BS_API.h"

int BS2_GetAllAntiPassbackZoneStatus(void* context, BS2_DEVICE_ID deviceId,
BS2ZoneStatus** zoneStatusObj, uint32_t* numZoneStatus);
```

[BS2ZoneStatus](#)

- [In] *context* : Context
- [In] *deviceId* :
- [Out] *zoneStatusObj* : zone status
- [Out] *numZoneStatus* : zone status



BS_SDK_SUCCESS , 가

- [BS2_GetAntiPassbackZone](#)
- [BS2_GetAllAntiPassbackZone](#)
- [BS2_GetAntiPassbackZoneStatus](#)
- [BS2_SetAntiPassbackZone](#)
- [BS2_SetAntiPassbackZoneAlarm](#)

[BS2_RemoveAntiPassbackZone](#)
[BS2_RemoveAllAntiPassbackZone](#)
[BS2_ClearAntiPassbackZoneStatus](#)
[BS2_ClearAllAntiPassbackZoneStatus](#)

From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar Device SDK**

Permanent link:

http://kb.supremainc.com/bs2sdk/doku.php?id=ko:bs2_getallantipassbackzonestatus

Last update: **2016/07/12 10:22**