

**BS2\_GetAllFloorLevel** ..... 1  
..... 1  
..... 1  
..... 1  
..... 1

# BS2\_GetAllFloorLevel

Floor 가 .

```
#include "BS_API.h"

int BS2_GetAllFloorLevel(void* context, uint32_t deviceId, BS2FloorLevel** floorLevelObj, uint32_t* numFloorLevel);
```

BS2FloorLevel

- [In] *context* : Context
- [In] *deviceId* :
- [Out] *floorLevelObj* : floor level
- [Out] *numFloorLevel* : floor level



BS\_SDK\_SUCCESS , 가

- [BS2\\_GetFloorLevel](#)
- [BS2\\_SetFloorLevel](#)
- [BS2\\_RemoveFloorLevel](#)
- [BS2\\_RemoveAllFloorLevel](#)

From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar Device SDK**

Permanent link:

[http://kb.supremainc.com/bs2sdk/doku.php?id=ko:bs2\\_getallfloorlevel](http://kb.supremainc.com/bs2sdk/doku.php?id=ko:bs2_getallfloorlevel)

Last update: **2017/06/28 11:40**