

BS2_RemoveAllIntrusionAlarmZone 1
..... 1
..... 1
..... 1
..... 1

[Zone Control API](#) > [BS2_RemoveAllScheduledLockUnlockZone](#)

BS2_RemoveAllIntrusionAlarmZone

```
#include "BS_API.h"

int BS2_RemoveAllIntrusionAlarmZone(void* context, uint32_t deviceId);
```

- [In] *context* : Context
- [In] *deviceId* :

BS_SDK_SUCCESS , 가

[BS2_GetIntrusionAlarmZone](#)
[BS2_GetIntrusionAlarmZoneStatus](#)
[BS2_GetAllIntrusionAlarmZoneStatus](#)
[BS2_SetIntrusionAlarmZone](#)
[BS2_SetIntrusionAlarmZoneAlarm](#)
[BS2_RemoveIntrusionAlarmZone](#)
[BS2_SetIntrusionAlarmZoneArm](#)

From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar Device SDK**

Permanent link:

http://kb.supremainc.com/bs2sdk/doku.php?id=ko:bs2_removeallintrusionalarmzone&rev=1504480741

Last update: **2017/09/04 08:19**