

BS2_SetDoorAlarm 1

..... 1

..... 1

..... 1

..... 1

BS2_SetDoorAlarm


```
#include "BS_API.h"

int BS2_SetDoorAlarm(void* context, uint32_t deviceId, uint8_t flag,
uint32_t* doorIds, uint32_t doorIdCount);
```

- [In] *context* : Context
- [In] *deviceId* :
- [In] *flag* :
- [In] *doorIds* : door id
- [In] *doorIdCount* : door id

BS_SDK_SUCCESS , 가

- [BS2_GetDoor](#)
- [BS2_GetAllDoor](#)
- [BS2_GetDoorStatus](#)
- [BS2_GetAllDoorStatus](#)
- [BS2_SetDoor](#)
- [BS2_RemoveDoor](#)
- [BS2_RemoveAllDoor](#)
- [BS2_ReleaseDoor](#)
- [BS2_LockDoor](#)
- [BS2_UnlockDoor](#)



From:

<https://kb.supremainc.com/bs2sdk/> - **BioStar Device SDK**

Permanent link:

https://kb.supremainc.com/bs2sdk/doku.php?id=ko:bs2_setdooralarm

Last update: **2016/02/02 14:28**