

BS2_SetScheduledLockUnlockZone 1
..... 1
..... 1
..... 1
..... 1

BS2_SetScheduledLockUnlockZone

/ .

```
#include "BS_API.h"

int BS2_SetScheduledLockUnlockZone(void* context, uint32_t deviceId,
BS2ScheduledLockUnlockZone* zones, uint32_t zoneCount);
```

BS2ScheduledLockUnlockZone

- [In] *context* : Context
- [In] *deviceId* :
- [In] *zones* : scheduled lock/unlock zone
- [In] *zoneCount* : scheduled lock/unlock zone

BS_SDK_SUCCESS , 가

- [BS2_GetScheduledLockUnlockZone](#)
- [BS2_GetAllScheduledLockUnlockZone](#)
- [BS2_GetScheduledLockUnlockZoneStatus](#)
- [BS2_GetAllScheduledLockUnlockZoneStatus](#)
- [BS2_SetScheduledLockUnlockZoneAlarm](#)
- [BS2_RemoveScheduledLockUnlockZone](#)
- [BS2_RemoveAllScheduledLockUnlockZone](#)

From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar Device SDK**

Permanent link:

http://kb.supremainc.com/bs2sdk./doku.php?id=ko:bs2_setscheduledlockunlockzone

Last update: **2016/07/12 09:55**