

Table of Contents

<i>BS2_CheckGlobalAPBViolationByDoorOpen</i>	1
Declaration	1
Parameter	1
Return Value	1
See Also	1

 **This page is not fully translated, yet. Please help completing the translation.**
(remove this paragraph once the translation is finished)

Zone Control API > [BS2_CheckGlobalAPBViolationByDoorOpen](#)

BS2_CheckGlobalAPBViolationByDoorOpen

[+ 2.7.0] Transfers Global APB by door open results to the device.

Declaration

```
#include "BS_API.h"

int BS2_CheckGlobalAPBViolationByDoorOpen(void* context, uint32_t deviceId,
uint16_t seq, int handleResult, uint32_t zoneID);
```

Parameter

- [In] *context* : Context
- [In] *deviceId* : Devicd ID
- [In] *seq* : Packet sequence
- [In] *handleResult* : Global Anti Passback determination result(BS_SDK_SUCCESS or BS_SDK_ERROR_XXX)
- [In] *zoneID* : Global Anti Passback zone Id

NOTE

Packet sequence must be the same with the value from OnCheckGlobalAPBViolationByDoorOpen

Return Value

If successfully done, BS_SDK_SUCCESS will be returned.

If there is an error, the corresponding error code will be returned.

See Also

[BS2_SetGlobalAPBViolationByDoorOpenHandler](#)

From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar 2 Device SDK**

Permanent link:

http://kb.supremainc.com/bs2sdk/doku.php?id=en:bs2_checkglobalapbviolationbydooropen&rev=1595988466

Last update: **2020/07/29 11:07**