Table of Contents

How to utilize BioStar 2 integrating with Milestone	1
The summary of Procedure	1
Step 1: Install BioStar 2	2
Step 2: Install one of Milestone XProtect VMS (with professional license or higher)	<u>3</u>
Step 3: Install BioStar 2 Integration for Milestone XProject	4
Step 4: Add IP Camera in Milestone XProtect VMS	4
Step 5: Create new Access Control to connect Milestone to BioStar 2	8
Major Features	. 15
Feature 1: Access Control Events	. 15
Feature 2: Cardholders	
Step 6: Utilize XProtect Smart Client	19
Major Features	. 20
Feature 1: Live	20
Feature 2: Alarm Manager	26
Feature 3: BioStar2	
Feature 4: Access Control	30

System Configuration, BioStar 2, Milestone

How to utilize BioStar 2 integrating with Milestone

The summary of Procedure

- 1. Install BioStar 2.
- 2. Install one of Milestone XProtect VMS (with professional license or higher).
- 3. Install BioStar 2 Integration for Milestone XProject.
 - AC Plugin for BioStar2
 - WorkspacePluginforBioStar2
- 4. Add IP Camera in Milestone XProtect VMS.
- 5. Create new Access Control to connect Milestone to BioStar 2.
- 6. Utilize XProtect Smart Client.

Before you integrate Milestone with BioStar 2, check the Prerequisites below.

Prerequisites

- Must install the one of Milestone XProtect VMS.
 - XProtect Professional 2017 R2
 - XProtect Professional+ 2017 R2
 - XProtect Expert 2017 R2
 - XProtect Corporate 2017 R2
- Must install BioStar 2.4.1 or higher version.
- Must have a Milestone license for XProtect Professional or higer version.
- XProtect VMS and BioStar 2 must be installed first.
- All access control configuration settings of BioStar 2 must be completed.
- System requrements
 - CPU: 4GHz Quad Core
 - RAM: Minimum 10 GB
 - Hard disk space: Minimum 1 TB free hard disk space available
 - Operating system:

Microsoft® Windows® 10 Pro (64 bit)*

Microsoft Windows 10 Enterprise (64 bit)*

Microsoft Windows 8.1 Pro (64-bit)

Microsoft Windows 8 Enterprise (64-bit)

Microsoft Windows 8 Pro (64-bit)

Microsoft Windows 7 Ultimate (64-bit)

Microsoft Windows 7 Enterprise (64-bit)

Microsoft Windows 7 Professional (64-bit)

Microsoft Windows 2008 R2 (64bit): Standard

Other Microsoft .NET 4.5.1 Framework

⁻ http://kb.supremainc.com/knowledge/

Step 1: Install BioStar 2


Refer to the below link if you do not know how to install BioStar 2. BioStar 2 Installation

If you use port number 443 and 9000 for BioStar 2, you should change it into other numbers. This is because the port number for BioStar 2 will have collided with the port number used when XProtect Management Client 2017 R3 is installed. When you set the port number 443 and 9000 for BioStar 2 and then try to install XProtect Management Client 2017 R3, you will get the below error.

When you set the port number 443 for BioStar 2 and then try to install XProtect Management Client 2017 R3, you will get the below error.



Therefore we recommend that you change the port number for HTTPS on BioStar 2 and 9000 port to avoid port conflict issues. Also, even if you changed HTTPS port for BioStar 2, the icon and configuration file do not be changed automatically. So, please update manually the icon and 'server_url.conf' file to the port number for BioStar 2's HTTPS.



Step 2: Install one of Milestone XProtect VMS (with professional license or higher)

You can download the installation file of Milestone XProtect VMS in the below link.

https://www.milestonesys.com/support/resources/download-software/

While you install the application, it is required to activate Milestone's license.


Step 3: Install BioStar 2 Integration for Milestone XProject

You should install two installation files below.

- AC Plugin for BioStar2
 WorkspacePluginforBioStar2
- AC Plugin for BioStar2.exe is used to connect the access control system and XProtect VMS.
- WorkspacePluginforBioStar2.exe provides the functionality for using BioStar 2 in the XProtect Smart Client.

You can refer to BioStar2 Integration for Milestone XProtect Setup Guide to install them.


After succeeding in installation of two applications, start the Milestone XProtect Event Server manually. You can find it in the system tray and right-click on the below icon.



Step 4: Add IP Camera in Milestone XProtect VMS

When you run XProtect Management Client 2017 R3 and connect to your PC, you can see the below screen.


⁻ http://kb.supremainc.com/knowledge/



Prepare IP camera.


Go to Servers > Recording Servers.

Right click one of **Recording Servers** and select **Add Hardware**.




Select Express (recommended) and then click Next button.


⁻ http://kb.supremainc.com/knowledge/




Add new user and enter User Name & Password for IP camera. Then, click Next button.




If you enter the information correctly, available camera will be found. To add IP camera, click **Next** button.




Click Next button.



Click folder icon and select one default camera group. Then, click **Finish** button.




If you succeed in add IP camera, you can see your camera in the Recording Servers's tree.



Step 5: Create new Access Control to connect Milestone to BioStar 2

Right click Access Control and select Create new.


⁻ http://kb.supremainc.com/knowledge/




Enter all items.

- Name: Enter name of Access Control you want to use
- Integration plug-in: Select BioStar2 Server
- Address: Enter URL for access to BioStar 2 (including port number)
- User: Login ID for BioStar 2
- Password: Password for BioStar 2


lame the access cont	trol system integration, select the integration plug-in and enter the connection details.		
lame:	BioStar 2		
ntegration plug-in:			
Address: https://192.168.14.17:456/			
Jser:	admin		
assword:			
Jse HTTP encryption:			



If you fail to connect to the access control system (BioStar 2 AC), you will get the below error. Please check if all settings are correct.




If you succeed in connection to the access control system (BioStar 2 AC), you can see below picture.




If BioStar 2 connected to Milestone successfully, the below screen will appear.

After selecting IP camera you will use in the right panel, **drag the cameras to the access points** for each door in the left list.



⁻ http://kb.supremainc.com/knowledge/

If you succeeded in integrate Milestone with BioStar2 with IP camera, you can see below picture.




Once you succeed in integration between BioStar 2 and Milestone, you can add/edit the access control properties at any time.

To manage them, you need to select one of Access Control.

At the bottom, there are 5 tabs you can configure.

⁻ http://kb.supremainc.com/knowledge/




- General Settings: You can update the access control system name, network settings and login information.
- Doors and Associated Cameras: You can associate the cameras with access points.
- Access Control Events: You can activate or deactivate the access control event from BioStar 2, also create and assign the user-defined categories.
- Access Request Notifications: You can create an access control action or command which is
 performed by the operator on the associated access points. For example, when a card holder
 requests the door open, XProtect display a notification and then operator sending a door open
 command.
- Cardholders: You can view or search the cardholder information. The cardholder information is synchronized with user information of BioStar 2. In BioStar 2, user information includes user name, access group, RFID card number, fingerprint template, face template and PIN.


Major Features

Feature 1: Access Control Events

This function is used for classifying Access Control Events into certain Event Category. In general, there are a variety of different events in each access control system. To manage them efficiently in Milestone, you should map all access control events to certain Event Category.



If you want to create customized Event Category, you can make it by clicking **User-defined Categories** button.



Feature 2: Cardholders


The user who is enrolled in BioStar 2 is synchronized with the cardholder in Milestone.

List of all Users

BioStar 2:




Milestone:



User Details


BioStar 2:



Milestone:




Although the information on user/door/device is changed except for real-time events in BioStar 2, it will not be updated in Milestone automatically. In these cases, you should click **Refresh Configuration** button in Milestone (**Access Control** > **General Settings**). Otherwise, the user information between BioStar 2 and Milestone are different.



Step 6: Utilize XProtect Smart Client

If you succeed in integration with Milestone with BioStar2, you can monitor real-time video, identify the detected alarm from the door, access to BioStar 2 and check the event logs displayed in BioStar 2 by utilizing XProtect Smart Client.




- Live
- Alarm Manager
- BioStar2
- Access Control


Major Features

Feature 1: Live


In Milestone XProtect Smart Client, you can monitor real-time video recorded by IP camera. After you select the camera you associated in Milestone XProtect management, drag it into the right panel.



Then, you can see the real-time video recorded by IP camera.




In addition, you can adjust direction or zoom in/out by clicking the icon located in left-bottom side.




You can customize the View in Live tab.


For example, if you want to monitor video and check the information on users who authenticate their identity with PIN/Fingerprint template at the same time, click **Setup** button.




Then, you can see various options you can configure. First of all, click **Create New View** icon.




After that, you can select one option you want to customize in the view. By clicking the icon shaped pencil, you can modify the name. Then, Click **Set** button.




Next, drag **Access Monitor** in **System Overview**. In the Access Monitor Settings, you should specify the settings for the Access Monitor and click **OK** button.




Once you click OK button, you can see the customized view. Please note that you should click Setup button again to escape the setting of View. If you see below screenshot, you can monitor video and the information on users who authenticate their identity to enter the door simultaneously.






If someone fails to authenticate their identity, the notification will be displayed in the right-bottom side and display the real-time video.




Feature 2: Alarm Manager

If an alarm occurs in BioStar 2, the alarm message will be generated in Milestone.

BioStar 2:



Milestone:




In Milestone, Alarm Manager will judge if generated event should be dealt with alarm based on Access Control Events tab and Alarm Definitions.

[How to configure the alarm]

This setting is required to view or acknowledge the access control event alarms of BioStar 2 in XProtect Smart Client. The alarm can be set in Setting menu of BioStar 2 and if the event alarm happens, XProtect Smart Client displays the alarm in Alarm Manager.


Go to Alarms in the Site Navigation and select **Alarm Definitions**. Then, right click **Alarm Definitions** and click **Add New**.



Enter Name in Alarm definition section.

Select **Access Control Event Categories** and one of Events you want to set in **Trigger** section. In below picture, I selected **Alarm**.

Selet one option for **Sources** in **Trigger** section. In below picture, I selected **All doors**.




At this point, please check Access Control Events which **Alarm** event is allocated. You can map Alarm event to certain Access Control Events. In below picture, I set Alarm event for the Access Control Event, "Access denied (Blacklist)".

	Select th	SS CONTrol events he events you want to monitor in XProtect Smart Client, Use o	stancries to simp Bu the use of trippering events	
		d Access Control Event	Source Type	Event Category
	∠ laulet	인증 실패 (시간 초과)	Access Point, Door	Access denied, Access Point, Access request, Zone Related
		인증 실패 (잘모된 인증 모드)	Access Point, Door	Access denied, Access Point, Access request, Zone Related
	7	인증 실패 (잘못된 크리덴셜)	Access Point, Door	Access denied, Access Point, Access request, Zone Related
	✓	입력 감지	BioStar2 Terminal	Device Related
	✓		BioStar2 Terminal	Device Related
	✓	장치 시간 설정 장치 시작	BioStar2 Terminal	Device Related
				Device Related
	✓	장치 잠금	BioStar2 Terminal	
	✓	장치 잡급 해제	BioStar2 Terminal	Device Related
	~	장치 재설정	BioStar2 Terminal	Device Related
	✓	장치 재시작	BioStar2 Terminal	Device Related
	~	장치연결해제 감지	BioStar2 Terminal	Alarm, Device Related
	✓	출입 거부 (기간 만료)	Access Point, Door	Access Point, Alarm, Zone Related
		출입 거부 (블랙리스트)	Access Point, Door	Access Point, Alarm, Zone Related
	<u>~</u>	율업 거무 (비율장 사용사)	Access Point, Door	All categories
	✓	출입 거부 (소프트 시간 지정 안티패스백)	Access Point, Door	Access denied
	✓	출입 거부 (소프트 안티패스백)	Access Point, Door	
	✓	출입 거부 (스케쥴 장금)	Access Point, Door	Access granted
	✓	출입 거부 (시간 지정 안티페스백)	Access Point, Door	✓ Access Point
	✓	출입 거부 (얼굴 건출 살펴)	Access Point, Door	☐ Access request
	✓	출입 거부 (잘못된 출입 그룹)	Access Point, Door	
	✓	출입 거부 (촬영 실패)	Access Point, Door	✓ Alarm
	✓	흥입 거부 (하드 안티페스백)	Access Point, Door	☐ Device Related
	✓	출입문 강제 열림	Access Point, Door	Alam
	✓	출입문 강제 열림 알람	Access Point, Door	☐ Door Related
	✓	출입문 강제 열림 알람 해제	Access Point, Door	□ Error
	✓	출입문 개방	Access Point, Door	☐ Lift Related
	✓	출입문 닫힘	Access Point, Door	
	✓	출입문 안티페스백 알람	Access Point, Door	☐ Test Event Category
	✓	출입문 안티페스백 알람 해제	Access Point, Door	П
	✓	출입문 열림	Access Point, Door	Access Point, Door Related
	✓	출입문 잠금	Access Point, Door	Access Point, Door Related
	✓	출입문 장시간 열림	Access Point, Door	Access Point, Alarm, Door Related
	✓	출입문 장시간 열림 알람	Access Point, Door	Access Point, Alarm, Door Related
	✓	출입문 장시간 열림 알람 해제	Access Point, Door	Access Point, Door Related
	✓	취입 감지	Door	Alarm, Zone Related
	✓	침입 경보 상태 해제	Door	Zone Related
	✓	타입존 설정	BioStar2 Terminal	Device Related


Feature 3: BioStar2

In Milestone XProtect Smart Client, you can access to BioStar 2 and add/modify the data (e.g. User, Device, Door) in BioStar 2.




Feature 4: Access Control

You can check Events, Doors and Cardholders for BioStar 2 in Milestone.



You can also create the PDF report for Event records by clicking **Access report** button.



From:

http://kb.supremainc.com/knowledge/ -

Permanent link:

 $http://kb.supremainc.com/knowledge/doku.php?id=en:how_to_integrate_milestone_with_biostar_2\&rev=1583994744$

Last update: 2020/03/12 15:32