# Table of Contents

Configuration API > BS2_GetCustomCardConfig

---

# BS2_GetCustomCardConfig

[+ 2.9.4] Retrieves Custom smart card settings.

## Declaration

```
#include "BS_API.h"

int BS2_GetCustomCardConfig(void* context, uint32_t deviceId,
BS2CustomCardConfig* config);
```

> See to structure BS2CustomCardConfig

## Parameter

- [In] *context* : Context
- [In] *deviceId* : Device Identifier
- [In] *config* : Pointer to get Custom smart card information

## Return Value

If successfully done, BS_SDK_SUCCESS will be returned. If there is an error, the corresponding error code will be returned.

## See Also

BS2_SetCustomCardConfig

## Sample Code(C++)

sample_getcustomcardconfig.cpp

```
    int sdkResult = BS2_GetCustomCardConfig(context_, id, &config);
    if (BS_SDK_SUCCESS != sdkResult)
        printf("BS2_GetCustomCardConfig call failed: %d", sdkResult);
    return sdkResult;
```

# Sample Code(C#)

[sample_getcustomcardconfig.cs](#)

```csharp
    BS2ErrorCode result =
(BS2ErrorCode)API.BS2_GetCustomCardConfig(sdkContext, deviceID, out
config);
    if (result != BS2ErrorCode.BS_SDK_SUCCESS)
        Console.WriteLine("Got error({0}).", result);
    else
        Console.WriteLine("Call success.");
    return result;
```