

Table of Contents

BS2_GetOsdpStandardDevice	1
Declaration	1
Parameter	1
Return Value	1
See Also	1
Sample Code(C++)	1
Sample Code (C#)	2

[Slave Control API](#) > [BS2_GetOsdpStandardDevice](#)

BS2_GetOsdpStandardDevice

[+ 2.9.1] CoreStation40 Gets OSDP device information.

Declaration

```
#include "BS_API.h"

int BS2_GetOsdpStandardDevice(void* context, uint32_t osdpDeviceId,
BS2OsdpStandardDevice* osdpDevice);
```

[See BS2OsdpStandardDevice Structure](#)

Parameter

- [In] *context* : Context
- [In] *osdpDeviceId* : OSDP Device Identifier
- [Out] *osdpDevice* : Pointer to store OSDP device information

Return Value

If successfully done, BS_SDK_SUCCESS will be returned. If there is an error, the corresponding error code will be returned.

See Also

[BS2_AddOsdpStandardDevice](#)
[BS2_GetOsdpStandardDevice](#)
[BS2_GetAvailableOsdpStandardDevice](#)
[BS2_UpdateOsdpStandardDevice](#)
[BS2_RemoveOsdpStandardDevice](#)
[BS2_GetOsdpStandardDeviceCapability](#)
[BS2_SetOsdpStandardDeviceSecurityKey](#)

Sample Code(C++)

[sample_bs2_getosdpstandarddevice.cpp](#)

```
BS2osdpStandardDevice osdpDevice = { , };

BS2_DEVICE_ID osdpID = Utility::selectSlaveID();
int sdkResult = BS2_GetOsdpStandardDevice(context_, osdpID,
&osdpDevice);
if (BS_SDK_SUCCESS != sdkResult)
    printf("BS2_GetOsdpStandardDevice call failed: %d", sdkResult);

return sdkResult;
```

Sample Code (C#)

[sample_bs2_getosdpstandarddevice.cs](#)

```
UInt32 id = Util.GetInputSlaveID();

BS2osdpStandardDevice osdpDevice;
BS2ErrorCode result =
(BS2ErrorCode)API.BS2_GetOsdpStandardDevice(sdkContext, id, out
osdpDevice);
if (result != BS2ErrorCode.BS_SDK_SUCCESS)
    Console.WriteLine("Got error({0}).", result);
else
    Console.WriteLine("Call success.");

return result;
```

From:

<https://kb.supremainc.com/kbtest/> - **BioStar 2 Device SDK**

Permanent link:

https://kb.supremainc.com/kbtest/doku.php?id=en:bs2_getosdpstandarddevice

Last update: **2023/02/28 15:40**