

Table of Contents

USB Exported Control API 1

USB Exported Control API

This API allows to control/manage USB Exported.

- **BS2_AllocateUsbContext**: Allocates context which manages & controls USB device.
- **BS2_ReleaseUsbContext**: Releases context which manages & controls USB device.
- **BS2_GetUserDatabaseInfoFromDir**: Gets total user information(Number of user/card/fingerprint/face) from USB exported data.
- **BS2_GetUserListFromDir**: Gets the enrolled user ID list from USB exported data.
- **BS2_GetUserInfosFromDir**: Gets the user information of the given user ID from USB exported data.
- **BS2_GetUserDatasFromDir**: Gets the user information of the given user ID & usermask from USB exported data.
- **BS2_GetUserInfosExFromDir**: Gets the user information of the given user ID from USB exported data. (Including Job, phrase)
- **BS2_GetUserDatasExFromDir**: Gets the user information of the given user ID & usermask from USB exported data. (Including Job, phrase)
- **BS2_GetUserSmallInfosFromDir**: [+ 2.6.3] Gets the user information of the given user ID from USB exported data.
- **BS2_GetUserSmallDatasFromDir**: [+ 2.6.3] Gets the user information of the given user ID & usermask from USB exported data.
- **BS2_GetUserSmallInfosExFromDir**: [+ 2.6.3] Gets the user information of the given user ID from USB exported data. (Including Job, phrase)
- **BS2_GetUserSmallDatasExFromDir**: [+ 2.6.3] Gets the user information of the given user ID & usermask from USB exported data. (Including Job, phrase)
- **BS2_GetLogFromDir**: Gets certain amount of logs from USB exported data.
- **BS2_GetLogBlobFromDir**: Gets certain amount of logs based on the event mask from USB exported data.
- **BS2_GetFilteredLogFromDir**: Gets filtered logs from USB exported data.
- **BS2_GetLogSmallBlobFromDir**: [+ 2.6.4] Gets certain amount of logs based on the event mask from USB exported data in an efficient way.
- **BS2_GetLogSmallBlobExFromDir**: [+ 2.7.1] Gets certain amount of logs including temperature information based on the event mask from USB exported data in an efficient way.
- **BS2_GetUserInfosFaceExFromDir**: [+2.7.1] USB·Î ÃßÃâÇÑ Dataζi¼ »çzèÀÚ IDÀÇ Áæº,¼, °iÁ®zÉ'Í'Ù.
- **BS2_GetUserDatasFaceExFromDir**: [+2.7.1] USB·Î ÃßÃâÇÑ Dataζi¼ UserMaskζi, Â°Ô »çzèÀÚ IDÀÇ Áæº,¼, °iÁ®zÉ'Í'Ù.

[+2.8.2] USB Exported,¼, °ü,®Çĭ±â ÀŞÇÑ APIÀÔ'Í'Ù.

»çzèÀÚ °ü·Ã ÁÖzä 1°" Áæº, Â ÄãÄi ³»ζi¼ »çzèÀÚi ÁæÀÇµÈ Å° °æÀ,¼·Î ¼/İËËÈ µÇ¼î ÁúÀâµÈ'Í'Ù.

,¼,Äĭ **BS2_SetDataEncryptKey** ÇÔ¼/ö,¼, Àìèçĭz© ÀãÄiÀÇ »çzèÀÚ Áæº, ¼/İËËÈ Å°,¼, °-°æÇÑ ÀùÀì ÀÖ'Ù,é, USB°ü·Ã API,¼, Àìèçĭ±â ÀŞÇØ ÇØ'ç Å° °æÀ» Äü'þÇØ ÁÔ¼/¼/ß ÇÔ'Í'Ù.

- **BS2_GetUserDatabaseInfoFromDirWithKey**: [+2.8.2] USB·Î ÃßÃâÇÑ Dataζi¼ ÄüÃ¼ »çzèÀÚ Áæº,¼ (»çzèÀÚ°¼/ö, Ä«µâ°¼/ö, Áö¹®°¼/ö, ¼/ó±¼ °¼/ö),¼, °iÁ®zÉ'Í'Ù.
- **BS2_GetUserListFromDirWithKey**: [+2.8.2] USB·Î ÃßÃâÇÑ Dataζi¼ »çzèÀÚ ID,¼, ®½°Æ®,¼, °iÁ®zÉ'Í'Ù.
- **BS2_GetUserInfosFromDirWithKey**: [+2.8.2] USB·Î ÃßÃâÇÑ Dataζi¼ »çzèÀÚ IDÀÇ Áæº,¼, °iÁ®zÉ'Í'Ù.
- **BS2_GetUserDatasFromDirWithKey**: [+2.8.2] USB·Î ÃßÃâÇÑ Dataζi¼ UserMaskζi, Â°Ô »çzèÀÚ

- IDÀÇ Áæº,¸¸¸¸ ºiÁ®¿É'Í'Ù.
- **BS2_GetUserInfosExFromDirWithKey:** [+2.8.2] USB·Í ÃßÃâÇÑ Data¿i¼¼ »ç¿ëÀÚ IDÀÇ Áæº,¸¸¸¸ ºiÁ®¿É'Í'Ù. (Job, phrase Æ÷ÇÔ)
- **BS2_GetUserDatasExFromDirWithKey:** [+2.8.2] USB·Í ÃßÃâÇÑ Data¿i¼¼ UserMask¿i ¿Á°Ô »ç¿ëÀÚ IDÀÇ Áæº,¸¸¸¸ ºiÁ®¿É'Í'Ù. (Job, phrase Æ÷ÇÔ)
- **BS2_GetUserSmallInfosFromDirWithKey:** [+2.8.2] USB·Í ÃßÃâÇÑ Data¿i¼¼ »ç¿ëÀÚ IDÀÇ Áæº,¸¸¸¸ ºiÁ®¿É'Í'Ù.
- **BS2_GetUserSmallDatasFromDirWithKey:** [+2.8.2] USB·Í ÃßÃâÇÑ Data¿i¼¼ UserMask¿i ¿Á°Ô »ç¿ëÀÚ IDÀÇ Áæº,¸¸¸¸ ºiÁ®¿É'Í'Ù.
- **BS2_GetUserSmallInfosExFromDirWithKey:** [+2.8.2] USB·Í ÃßÃâÇÑ Data¿i¼¼ »ç¿ëÀÚ IDÀÇ Áæº,¸¸¸¸ ºiÁ®¿É'Í'Ù. (Job, phrase Æ÷ÇÔ)
- **BS2_GetUserSmallDatasExFromDirWithKey:** [+2.8.2] USB·Í ÃßÃâÇÑ Data¿i¼¼ UserMask¿i ¿Á°Ô »ç¿ëÀÚ IDÀÇ Áæº,¸¸¸¸ ºiÁ®¿É'Í'Ù. (Job, phrase Æ÷ÇÔ)
- **BS2_GetLogFromDirWithKey:** [+2.8.2] USB·Í ÃßÃâÇÑ Data¿i¼¼ ÄÏÁæ·®ÀÇ ·Í±x¸¸¸¸ ºiÁ®¿É'Í'Ù.
- **BS2_GetLogBlobFromDirWithKey:** [+2.8.2] USB·Í ÃßÃâÇÑ Data¿i¼¼ EventMask¿i ¿Á°Ô ÄÏÁæ·®ÀÇ ·Í±x¸¸¸¸ ºiÁ®¿É'Í'Ù.
- **BS2_GetFilteredLogFromDirWithKey:** [+2.8.2] USB·Í ÃßÃâÇÑ Data¿i¼¼ Á¶°Ç¿i ¿Á°Ô ·Í±x¸¸¸¸ ºiÁ®¿É'Í'Ù.
- **BS2_GetLogSmallBlobFromDirWithKey:** [+2.8.2] È¿À²ÀùÀ¿·Í ¿,¿,ø,®,¸¸¸¸ »ç¿ëÇ¿,é¼¼, USB·Í ÃßÃâÇÑ Data¿i¼¼ EventMask¿i ¿Á°Ô ÄÏÁæ·®ÀÇ ·Í±x¸¸¸¸ ºiÁ®¿É'Í'Ù.
- **BS2_GetLogSmallBlobExFromDirWithKey:** [+2.8.2] È¿À²ÀùÀ¿·Í ¿,¿,ø,®,¸¸¸¸ »ç¿ëÇ¿,é¼¼, USB·Í ÃßÃâÇÑ Data¿i¼¼ EventMask¿i »ç¿ëÇø¼¼ Ä¼¼¿ÄÀ» Æ÷ÇÔÇÑ ·Í±x¸¸¸¸ ºiÁ®¿É'Í'Ù.
- **BS2_GetUserInfosFaceExFromDirWithKey:** [+2.8.2] USB·Í ÃßÃâÇÑ Data¿i¼¼ »ç¿ëÀÚ IDÀÇ Áæº,¸¸¸¸ ºiÁ®¿É'Í'Ù.
- **BS2_GetUserDatasFaceExFromDirWithKey:** [+2.8.2] USB·Í ÃßÃâÇÑ Data¿i¼¼ UserMask¿i ¿Á°Ô »ç¿ëÀÚ IDÀÇ Áæº,¸¸¸¸ ºiÁ®¿É'Í'Ù.

From:
<https://kb.supremainc.com/kbtest/> - **BioStar 2 Device SDK**

Permanent link:
https://kb.supremainc.com/kbtest/doku.php?id=en:use_exported_control_api&rev=1650843829

Last update: **2022/04/25 08:43**