

BS2_GetAllDoorStatus 1
..... 1
..... 1
..... 1
..... 1

BS2_GetAllDoorStatus


가 .

```
#include "BS_API.h"

int BS2_GetAllDoorStatus(void* context, uint32_t deviceId, BS2DoorStatus**
doorStatusObj, uint32_t* numDoorStatus);
```

BS2DoorStatus

- [In] *context* : Context
- [In] *deviceId* :
- [Out] *doorStatusObj* : door status
- [Out] *numDoorStatus* : door status



BS_SDK_SUCCESS , 가

- [BS2_GetDoor](#)
- [BS2_GetAllDoor](#)
- [BS2_GetDoorStatus](#)
- [BS2_SetDoor](#)
- [BS2_SetDoor](#)

[BS2_SetDoorAlarm](#)
[BS2_RemoveDoor](#)
[BS2_RemoveAllDoor](#)
[BS2_ReleaseDoor](#)
[BS2_LockDoor](#)
[BS2_UnlockDoor](#)

From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar 2 Device SDK**

Permanent link:

http://kb.supremainc.com/bs2sdk./doku.php?id=ko:bs2_getalldoorstatus

Last update: **2016/08/08 15:13**