

BS2_SetInterlockZoneAlarm 1

..... 1

..... 1

..... 1

..... 1

BS2_SetInterlockZoneAlarm

[+ V2.6.0]

```
#include "BS_API.h"

int BS2_SetInterlockZoneAlarm(void* context, uint32_t deviceId, uint8_t
alarmed, uint32_t* zoneIds, uint32_t zoneIdCount);
```

- [In] *context* : Context
- [In] *deviceId* :
- [In] *alarmed* :
- [In] *zoneIds* : zone id
- [In] *zoneIdCount* : zone id

BS_SDK_SUCCESS , 가

- [BS2_GetInterlockZone](#)
- [BS2_GetInterlockZoneStatus](#)
- [BS2_GetAllInterlockZoneStatus](#)
- [BS2_SetInterlockZone](#)
- [BS2_RemoveInterlockZone](#)
- [BS2_RemoveAllInterlockZone](#)

From:
<http://kb.supremainc.com/bs2sdk/> - **BioStar 2 Device SDK**

Permanent link:
http://kb.supremainc.com/bs2sdk/doku.php?id=ko:bs2_setinterlockzonealarm

Last update: **2018/03/11 20:43**