

**BS2\_SetScheduledLockUnlockZoneAlarm** ..... 1  
..... 1  
..... 1  
..... 1  
..... 1

[Zone Control API](#) > [BS2\\_SetScheduledLockUnlockZoneAlarm](#)

---

## BS2\_SetScheduledLockUnlockZoneAlarm

/

```
#include "BS_API.h"

int BS2_SetScheduledLockUnlockZoneAlarm(void* context, uint32_t deviceId,
uint8_t alarmed, uint32_t* zoneIds, uint32_t zoneIdCount);
```

- [In] *context* : Context
- [In] *deviceId* :
- [In] *alarmed* :
- [In] *zoneIds* : scheduled lock/unlock zone id
- [In] *zoneIdCount* : scheduled lock/unlock zone id

BS\_SDK\_SUCCESS , 가

[BS2\\_GetScheduledLockUnlockZone](#)  
[BS2\\_GetAllScheduledLockUnlockZone](#)  
[BS2\\_GetScheduledLockUnlockZoneStatus](#)  
[BS2\\_GetAllScheduledLockUnlockZoneStatus](#)  
[BS2\\_SetScheduledLockUnlockZone](#)  
[BS2\\_RemoveScheduledLockUnlockZone](#)  
[BS2\\_RemoveAllScheduledLockUnlockZone](#)

From:  
<http://kb.supremainc.com/bs2sdk/> - **BioStar 2 Device SDK**

Permanent link:  
[http://kb.supremainc.com/bs2sdk/doku.php?id=ko:bs2\\_setscheduledlockunlockzonealarm](http://kb.supremainc.com/bs2sdk/doku.php?id=ko:bs2_setscheduledlockunlockzonealarm)

Last update: **2016/02/02 14:33**

