

Slave Control API	1
.....	1
BS2Rs485SlaveDevice	1
BS2Rs485SlaveDeviceEX	1

Slave Control API

RS485

- [BS2_GetSlaveDevice](#): RS485
- [BS2_SetSlaveDevice](#): CoreStation 가/ /
- [BS2_GetSlaveExDevice](#): CoreStation RS485
- [BS2_SetSlaveExDevice](#): CoreStation 가/ /
- [BS2_SearchDevicesCoreStation](#): CoreStation
- [BS2_SearchDevicesCoreStationEx](#): [+ 2.6.3] CoreStation
(host ip)
- [BS2_GetDevicesCoreStation](#): CoreStation

SDK가 가

BS2Rs485SlaveDevice

```
typedef struct {
    uint32_t deviceID;
    uint16_t deviceType;
    uint8_t enableOSDP;
    uint8_t connected;
} BS2Rs485SlaveDevice;
```

1. *deviceID*

2. *deviceType*

3. *enableOSDP*

flag

4. *connected*

가

flag

BS2Rs485SlaveDeviceEX

```
typedef struct {  
    uint32_t deviceID;  
    uint16_t deviceType;  
    uint8_t enableOSDP;  
    uint8_t connected;  
    uint8_t channelInfo;  
    uint8_t reserved[3];  
} BS2Rs485SlaveDeviceEX;
```

1. *deviceID*

2. *deviceType*

3. *enableOSDP*

flag

4. *connected*

가

flag

5. *channelInfo*

Channel

6. *reserved*

From:

<https://kb.supremainc.com/bs2sdk/> - **BioStar 2 Device SDK**

Permanent link:

https://kb.supremainc.com/bs2sdk./doku.php?id=ko:slave_control_api&rev=1557745704

Last update: **2019/05/13 20:08**