

Table of Contents

Configuration API	1
Structure	3
BS2FactoryConfig	3
BS2SystemConfig	4
BS2AuthConfig	6
BS2StatusConfig	8
BS2DisplayConfig	9
BS2IpConfig	12
BS2IpConfigExt	14
BS2TNAConfig	14
BS2CardConfig	16
BS2FingerprintConfig	18
BS2Rs485Config	20
BS2WiegandConfig	22
BS2WiegandDeviceConfig	25
BS2InputConfig	26
BS2WlanConfig	28
BS2Trigger	29
BS2Action	30
BS2TriggerActionConfig	35
BS2EventConfig	35
BS2WiegandMultiConfig	36
BS1CardConfig	37
BS2SystemConfigExt	38
BS2VoipConfig	39
BS2FaceConfig	40
BS2Rs485ConfigEX	49
BS2CardConfigEx	57
BS2DstConfig	64
BS2Configs	74
BS2IPV6Config	82
BS2DesFireCardConfigEx	95
BS2AuthConfigExt	101
BS2FaceConfigExt	118
BS2ThermalCameraConfig	141
BS2BarcodeConfig	149
BS2InputConfigEx	158
BS2RelayActionConfig	164
BS2VoipConfigExt	174
BS2RtspConfig	190

Configuration API

The following APIs are used to read and write system configuration information.

- [BS2_ResetConfig](#): Initializes the device's configurations.
- [BS2_ResetConfigExceptNetInfo](#): Initializes the setting information of the device. (Excluding network settings)
- [BS2_GetConfig](#): Retrieves configuration blob from the device.
- [BS2_SetConfig](#): Stores configuration blob on the device.
- [BS2_GetFactoryConfig](#): Retrieves software version and hardware settings from the device.
- [BS2_GetSystemConfig](#): Retrieves system settings from the device.
- [BS2_SetSystemConfig](#): Stores system settings on the device.
- [BS2_GetAuthConfig](#): Retrieves authentication settings from the device.
- [BS2_SetAuthConfig](#): Stores authentication settings on the device.
- [BS2_GetStatusConfig](#): Retrieves LED and buzzer settings from the device.
- [BS2_SetStatusConfig](#): Stores LED and buzzer settings on the device.
- [BS2_GetDisplayConfig](#): Retrieves sound and UI settings from the device.
- [BS2_SetDisplayConfig](#): Stores sound and UI settings on the device.
- [BS2_GetIPConfig](#): Retrieves IP settings from the device.
- [BS2_GetIPConfigViaUDP](#): Retrieves IP settings from the device via the UDP broadcasting.
- [BS2_SetIPConfig](#): Stores IP settings on the device.
- [BS2_SetIPConfigViaUDP](#): Stores IP settings on the device via the UDP broadcasting.
- [BS2_GetIPConfigExt](#): Retrieves DNS and server URL settings from the device.
- [BS2_SetIPConfigExt](#): Stores DNS and server URL settings on the device.
- [BS2_GetTNAConfig](#): Retrieves time and attendance settings from the device.
- [BS2_SetTNAConfig](#): Stores time and attendance settings on the device.
- [BS2_GetCardConfig](#): Retrieves smart card settings from the device.
- [BS2_SetCardConfig](#): Stores smart card settings on the device.
- [BS2_GetFingerprintConfig](#): Retrieves fingerprint matching settings from the device.
- [BS2_SetFingerprintConfig](#): Stores fingerprint matching settings on the device.
- [BS2_GetRS485Config](#): Retrieves RS-485 network settings from the device.
- [BS2_SetRS485Config](#): Stores RS-485 network settings on the device.
- [BS2_GetWiegandConfig](#): Retrieves Wiegand I/O settings from the device.
- [BS2_SetWiegandConfig](#): Stores Wiegand I/O settings on the device.
- [BS2_GetWiegandDeviceConfig](#): Retrieves Wiegand device settings from the device.
- [BS2_SetWiegandDeviceConfig](#): Stores Wiegand device settings on the device.
- [BS2_GetInputConfig](#): Retrieves supervised input port settings from the device.
- [BS2_SetInputConfig](#): Stores supervised input port settings on the device.
- [BS2_GetWlanConfig](#): Retrieves wireless LAN settings from the device.
- [BS2_SetWlanConfig](#): Stores wireless LAN settings on the device.
- [BS2_GetTriggerActionConfig](#): Retrieves trigger and action settings from the device.
- [BS2_SetTriggerActionConfig](#): Stores trigger and action settings on the device.
- [BS2_GetEventConfig](#): Retrieves image log filter settings from the device.
- [BS2_SetEventConfig](#): Stores image log filter settings on the device.
- [BS2_GetWiegandMultiConfig](#): Retrieves Multi-Wiegand settings from the device.
- [BS2_SetWiegandMultiConfig](#): Stores Multi-Wiegand settings on the device.
- [BS2_GetCard1xConfig](#): Retrieves v1 Template on Card settings from the device.
- [BS2_SetCard1xConfig](#): Stores v1 Template on Card settings on the device.
- [BS2_GetSystemExtConfig](#): Retrieves Master and slave device encryption settings from the

device.

- [BS2_SetSystemExtConfig](#): Stores Master and slave device encryption settings on the device
- [BS2_GetVoipConfig](#): Retrieves VoIP settings from the device.
- [BS2_SetVoipConfig](#): Stores VoIP settings on the device.
- [BS2_GetFaceConfig](#): Retrieves face settings from the device.
- [BS2_SetFaceConfig](#): Stores face settings on the device.
- [BS2_GetRS485ConfigEx](#): In case of Corestation, retrieves RS-485 network settings from the device.
- [BS2_SetRS485ConfigEx](#): In case of CoreStation, stores RS-485 network settings on the device.
- [BS2_GetCardConfigEx](#): Retrieves iClass SEOS card settings from the device.
- [BS2_SetCardConfigEx](#): Stores iClass SEOS card settings on the device.
- [BS2_GetDstConfig](#): Retrieves the device DST information.
- [BS2_SetDstConfig](#): Stores the device DST information.
- [BS2_GetSupportedConfigMask](#): Retrieves supported configuration of the device.
- [BS2_GetIPConfigViaUDPEx](#): [+ 2.6.3] Retrieves IP configuration through UDP broadcast with host IP.
- [BS2_SetIPConfigViaUDPEx](#): [+ 2.6.3] Stores IP configuration through UDP broadcast with host IP.
- [BS2_GetIPv6Config](#): [+ 2.6.3] Retrieves IPv6 configuration information.
- [BS2_SetIPv6Config](#): [+ 2.6.3] Stores IPv6 configuration information.
- [BS2_GetIPv6ConfigViaUDP](#): [+ 2.6.3] Retrieves IPv6 configuration through UDP broadcast.
- [BS2_SetIPv6ConfigViaUDP](#): [+ 2.6.3] Stores IPv6 configuration through UDP broadcast.
- [BS2_GetIPv6ConfigViaUDPEx](#): [+ 2.6.3] Retrieves IPv6 configuration through UDP broadcast with host IP.
- [BS2_SetIPv6ConfigViaUDPEx](#): [+ 2.6.3] Stores IPv6 configuration through UDP broadcast with host IP.
- [BS2_GetDesFireCardConfigEx](#): [+ 2.6.4] Retrieves DesFire advanced configuration from the device.
- [BS2_SetDesFireCardConfigEx](#): [+ 2.6.4] Sets DesFire advanced configuration in the device.
- [BS2_GetAuthConfigExt](#): [+ 2.7.1] FaceStation F2 Retrieves authentication settings from the device.
- [BS2_SetAuthConfigExt](#): [+ 2.7.1] FaceStation F2 Stores authentication settings from the device.
- [BS2_GetFaceConfigExt](#): [+ 2.7.1] FaceStation F2, FaceStation2 Retrieves configuration of thermal camera and mask detection.
- [BS2_SetFaceConfigExt](#): [+ 2.7.1] FaceStation F2, FaceStation2 Stores configuration of thermal camera and mask detection.
- [BS2_GetThermalCameraConfig](#): [+ 2.7.1] FaceStation F2, FaceStation2 Retrieves configuration of thermal camera.
- [BS2_SetThermalCameraConfig](#): [+ 2.7.1] FaceStation F2, FaceStation2 Stores configuration of thermal camera.
- [BS2_GetBarcodeConfig](#): [+ 2.8] X-Station 2 Retrieves configuration of Barcode.
- [BS2_SetBarcodeConfig](#): [+ 2.8] X-Station 2 Stores configuration of Barcode.
- [BS2_GetInputConfigEx](#): [+ 2.8.1] IM-120 Retrieves Expanded Configuration related to the Input.
- [BS2_SetInputConfigEx](#): [+ 2.8.1] IM-120 Retrieves Expanded Configuration related to the Input.
- [BS2_GetRelayActionConfig](#): [+ 2.8.1] IM-120 Retrieves Configuration related to the RelayAction.
- [BS2_SetRelayActionConfig](#): [+ 2.8.1] IM-120 Retrieves Configuration related to the RelayAction.

Structure

BS2FactoryConfig

```
typedef struct {
    uint8_t major;
    uint8_t minor;
    uint8_t ext;
    uint8_t reserved[1];
} Version;

typedef struct {
    uint32_t deviceID;
    uint8_t macAddr[BS2_MAC_ADDR_LEN];
    uint8_t reserved[2];
    char modelName[BS2_MODEL_NAME_LEN];
    Version boardVer;
    Version kernelVer;
    Version bscoreVer;
    Version firmwareVer;
    char kernelRev[BS2_KERNEL_REV_LEN];
    char bscoreRev[BS2_BSCORE_REV_LEN];
    char firmwareRev[BS2_FIRMWARE_REV_LEN];
    uint8_t reserved2[32];
} BS2FactoryConfig;
```

1. **deviceID**

Device identifier.

2. **macAddr**

MAC address of the network adaptor.

3. **reserved**

Reserved space.

4. **modelName**

Model name.

5. **boardVer**

Hardware version.

6. **kernelVer**

Kernel version.

7. **bscoreVer**

BioStar Core version.

8. **firmwareVer**

Firmware version.

9. *kernelRev*

Kernel revision information.

10. *bscoreRev*

BioStar Core revision information.

11. *firmwareRev*

Firmware revision information.

12. *reserved2*

Reserved space.

BS2SystemConfig

```
typedef struct {
    uint8_t notUsed[16 * 16 * 3];
    int32_t timezone;
    uint8_t syncTime;
    uint8_t serverSync;
    uint8_t deviceLocked;
    uint8_t useInterphone;
    uint8_t useUSBConnection;
    uint8_t keyEncrypted;
    uint8_t useJobCode;
    uint8_t useAlphanumericID;
    uint32_t cameraFrequency;
    bool secureTamper;[]
    bool reserved0; // (write protected)
    uint8_t reserved[2];
    uint32_t useCardOperationMask;
    uint8_t reserved2[16];
} BS2SystemConfig;
```

1. *notUsed*

Not used.

2. *timezone*

Represents standard time zone in seconds.

3. *syncTime*

Stores when synchronization with BioStar has occurred.

4. *serverSync*

Reserved variable.

5. *deviceLocked*

Indicates the current locked state of the device. (Read only filed)

6. *useInterphone*

Decides whether to use intercom.

7. useUSBConnection

This is not used anymore. (The device automatically detects USB connection.)

8. keyEncrypted

Decides whether to use OSDP secure key.

9. useJobCode

Decides whether to use job codes.

10. useAlphanumericID

Decides whether to use alphanumeric ID.

11. cameraFrequency

Frequency of the camera.

Value	Description
1	50Hz
2	60Hz

***12. secureTamper**

Flag to determine whether to use a security tamper.

When Tamper on, the following data is deleted from the device. (User, log, data encryption key, SSL certificate)

13. reserved0

Reserved space.

14. reserved

Reserved space.

15. useCardOperationMask

[+ V2.6.4] Provides a card selective option not to read all kinds of cards from the device.

You can select multiple cards using MASK. The user can select or deselect of a specific card reading option using this option.

However, it can be applied to the card types the device supporting. If you add a card type which isn't supported from the device would be ignored.

Also, the required card type MASK should be combined with CARD_OPERATION_USE.

For example, useCardOperationMask needs to be configured x0x80000001 when EM card is selected only.

Value	Description
0xFFFFFFFF	CARD_OPERATION_MASK_DEFAULT
0x80000000	CARD_OPERATION_USE
0x00000200	CARD_OPERATION_MASK_BLE
0x00000100	CARD_OPERATION_MASK_NFC
0x00000080	CARD_OPERATION_MASK_SEOS
0x00000040	CARD_OPERATION_MASK_SR_SE
0x00000020	CARD_OPERATION_MASK_DESFIRE_EV1
0x00000010	CARD_OPERATION_MASK_CLASSIC_PLUS
0x00000008	CARD_OPERATION_MASK_ICLASS

Value	Description
0x00000004	CARD_OPERATION_MASK_MIFARE_FELICA
0x00000002	CARD_OPERATION_MASK_HIDPROX
0x00000001	CARD_OPERATION_MASK_EM

16. reserved2

Reserved space.

BS2AuthConfig

```
typedef struct {
    uint32_t authSchedule[BS2_NUM_OF_AUTH_MODE];
    uint8_t useGlobalAPB;
    uint8_t globalAPBFailAction;
    uint8_t useGroupMatching;
    uint8_t reserved;
    uint8_t reserved[28];
    uint8_t usePrivateAuth;
    uint8_t faceDetectionLevel;
    uint8_t useServerMatching;
    uint8_t useFullAccess;
    uint8_t matchTimeout;
    uint8_t authTimeout;
    uint8_t numOperators;
    uint8_t reserved2[1];
    struct {
        char userID[BS2_USER_ID_SIZE];
        uint8_t level;
        uint8_t reserved[3];
    } operators[BS2_MAX_OPERATORS];
} BS2AuthConfig;
```

1. authSchedule

Stores schedules for different types of authentication modes.

It has the following meanings in the value of the array.

If the value in the array is greater than 0, the corresponding authentication mode is enabled.

Biometric information in the descriptions below refers to the fingerprint or face depending on the device.

Value	Code	Description
0	BS2_AUTH_MODE BIOMETRIC ONLY	Biometric only
1	BS2_AUTH_MODE BIOMETRIC PIN	Biometric + PIN
2	BS2_AUTH_MODE CARD ONLY	Card only
3	BS2_AUTH_MODE CARD BIOMETRIC	Card + Biometric
4	BS2_AUTH_MODE CARD PIN	Card + PIN

Value	Code	Description
5	BS2_AUTH_MODE_CARD_BIOMETRIC_OR_PIN	Card + Biometric or PIN
6	BS2_AUTH_MODE_CARD_BIOMETRIC_PIN	Card + Biometric + PIN
7	BS2_AUTH_MODE_ID_BIOMETRIC	ID + Biometric
8	BS2_AUTH_MODE_ID_PIN	ID + PIN
9	BS2_AUTH_MODE_ID_BIOMETRIC_OR_PIN	ID + Biometric or PIN
10	BS2_AUTH_MODE_ID_BIOMETRIC_PIN	ID + Biometric + PIN

2. *useGlobalAPB*

Decides whether to enable global APB zone.

3. *globalAPBFailAction*

Default action that will be executed when the BioStar application cannot determine if the authentication has violated global APB rules.

Value	Description
0	Not use
1	Operate as soft APB
2	Operate as hard APB

4. *useGroupMatching*

Decides whether to use face group matching.

5. *reserved*

Reserved space.

6. *usePrivateAuth*

Decides whether to use private authentication mode.

7. *faceDetectionLevel*

Level of face detection in user authentication. If the detected face level is lower than the configuration, it will be processed as authentication fail.

When set, the camera view according to Normal/Strict is displayed, access is denied if the device doesn't recognize facial image through image log. Default is 0.

Value	Description
0	Face detection not used
1	Normal mode
2	Strict mode

Only valid for A2. Not used with FaceStation2 or FaceLite.

8. *useServerMatching*

Decides whether to perform fingerprint/face matchings on the server.

9. *useFullAccess*

Decides whether to allow full access to all authenticated users regardless to the access group rules.

10. *matchTimeout*

Timeout in seconds for fingerprint/face matching.

11. *authTimeout*

Timeout in seconds for the user authentication response.

12. *numOperators*

The number of operators defining user privileges.

13. *reserved2*

Reserved space.

14. *userID*

User identifier.

15. *level*

Specifies the privilege of the user when accessing to the device's menu.

Value	Description
0	No privilege
1	Administrative privilege
2	Privilege to change the system settings
3	Privilege to change user information

CAUTION

To add an operator, the ***numOperators*** field needs to be set equivalent to the number of operators that will be added.

16. *reserved*

Reserved space.

BS2StatusConfig

```
typedef struct {
    struct {
        uint8_t enabled;
        uint8_t reserved[1];
        uint16_t count;
        BS2LedSignal signal[BS2_LED_SIGNAL_NUM];
    };
```

```
    } led[BS2_DEVICE_STATUS_NUM];
    uint8_t reserved1[32];
    struct {
        uint8_t enabled;
        uint8_t reserved[1];
        uint16_t count;
        BS2BuzzerSignal signal[BS2_BUZZER_SIGNAL_NUM];
    } buzzer[BS2_DEVICE_STATUS_NUM];
    uint8_t configSyncRequired;
    uint8_t reserved2[31];
} BS2StatusConfig;
```

1. *enabled*

Decides whether to use the LED.

2. *reserved*

Reserved space.

3. *count*

Number of LED signal execution count. When it is set as 0, repeats infinitely.

4. *signal*

List of LED signal patterns, which can be configured up to 3 patterns.

5. *reserved1*

Reserved space.

6. *enabled*

Decides whether to use the buzzer.

7. *reserved*

Reserved space.

8. *count*

Number of buzzer signal execution count. When it is set as 0, repeats infinitely.

9. *signal*

List of buzzer signal patterns, which can be configured up to 3 patterns.

10. *configSyncRequired*

If the device's configuration has been modified, this value will be set to true.

11. *reserved2*

Reserved space.

BS2DisplayConfig

```
typedef struct {
```

```

    uint32_t language;
    uint8_t background;
    uint8_t volume;
    uint8_t bgTheme;
    uint8_t dateFormat;
    uint16_t menuTimeout;
    uint16_t msgTimeout;
    uint16_t backlightTimeout;
    uint8_t displayDateTime;
    uint8_t useVoice;
    uint8_t timeFormat;
    uint8_t homeFormation;
    BS2_BOOL useUserPhrase;
    BS2_BOOL queryUserPhrase;
    uint8_t shortcutHome[BS2_MAX_SHORTCUT_HOME];
    uint8_t tnaIcon[16];
    uint8_t useScreenSaver;
    uint8_t reserved1[31];
} BS2DisplayConfig;

```

1. *language*

Language code.

Value	Description
0	Korean
1	English
2	Custom

2. *background*

Background image type.

Value	Description
0	LOGO
1	NOTICE
2	SLIDE
3	PDF

3. *volume*

The volume of sound. The volume can be set from 0 to 100. 0 means no sound.

4. *bgTheme*

Theme type.

Value	Description
0	Logo image
1	Notice
2	Slide show
3	PDF

5. *dateFormat*

Date format.

Value	Description
0	YYYY/MM/DD
1	MM/DD/YYYY
2	DD/MM/YYYY

6. *menuTimeout*

Timeout in seconds for lock screen when the user is inactive. The timeout can be set from 0 to 255 seconds. 0 means no lock screen.

Value	Description
0	No timeout.
10	Menu timeout 10 sec.
20	Menu timeout 20 sec. (Default)
30	Menu timeout 30 sec.
40	Menu timeout 40 sec.
50	Menu timeout 50 sec.
60	Menu timeout 60 sec.

7. *msgTimeout*

Message timeout in milliseconds. The timeout can be set from 500 to 5000 milliseconds.

Value	Description
500	Message timeout 500 msec.
1000	Message timeout 1 sec.
2000	Message timeout 2 sec. (Default)
3000	Message timeout 3 sec.
4000	Message timeout 4 sec.
5000	Message timeout 5 sec.

8. *backlightTimeout*

Backlight timeout in seconds.

Value	Description
0	Backlight timeout 0 sec.
10	Backlight timeout 10 sec.
20	Backlight timeout 20 sec. (Default)
30	Backlight timeout 30 sec.
40	Backlight timeout 40 sec.
50	Backlight timeout 50 sec.
60	Backlight timeout 60 sec.

9. *displayDateTime*

Decides whether to display clock on screen.

10. *useVoice*

Decides whether to use voice instruction.

11. *timeFormat*

Time format.

Value	Description
0	12 hour
1	24 hour

However, Linux OS devices like BioStation 2, BioStation L2, BioLite N2 and FaceLite have opposite settings.(0 = 24 hour / 1 = 12 hour)

12. *homeFormation*

Home screen settings(Currently, not used).

Value	Description
1	Interphone
2	Shortcut 1
3	Shortcut 2
4	Shortcut 3
5	Shortcut 4

13. *useUserPhrase*

Flag that determines whether to use the user phrase feature.

13. *queryUserPhrase*

If set true, asks for the user phrase to the server.

15. *shortcutHome*

Home screen layout(Going to apply later, not used currently).

16. *tNALcon*

Icon displayed on the device corresponding TNA key.

17. *useScreenSaver*

FaceStation 2, FaceStation F2 If set true, you can activate the screensaver.

18. *reserved1*

Reserved space.

BS2IpConfig

```
typedef struct {
    uint8_t connectionMode;
    uint8_t useDHCP;
    uint8_t useDNS;
    uint8_t reserved[1];
    char ipAddress[BS2_IPV4_ADDR_SIZE];
    char gateway[BS2_IPV4_ADDR_SIZE];
    char subnetMask[BS2_IPV4_ADDR_SIZE];
```

```
char serverAddr[BS2_IPV4_ADDR_SIZE];
uint16_t port;
uint16_t serverPort;
uint16_t mtuSize;
uint8_t baseband;
uint8_t reserved2[1];
uint16_t sslServerPort;
uint8_t reserved3[30];
} BS2IpConfig;
```

1. *connectionMode*

Represents the connection mode between BioStar and devices. There are two modes depending on who initiates the connection: Direct mode (0x0) and Server mode (0x1). The Direct mode means that BioStar initiates the connection to the devices and the Server mode means that the devices initiate the connection to the server. The default connection mode of a device is the Direct mode.

2. *useDHCP*

Decides whether to use DHCP.

3. *useDNS*

Decides whether to use server address or server URL.

4. *reserved*

Reserved space.

5. *ipAddress*

IP address assigned to the device.

6. *gateway*

IP address of the gateway.

7. *subnetMask*

Subnet mask of the device.

8. *serverAddr*

IP address of BioStar. Used only in the server mode.

9. *port*

Port number of the device.

10. *serverPort*

Port number of BioStar. Used only in the server mode.

11. *mtuSize*

MTU¹⁾ size for the TCP/IP communication.

12. *baseband*

Bandwidth of the device. The value can be set to 10MB/S or 100 MB/S.

13. *reserved2*

Reserved space.

14. *sslServerPort*

Used when the connectionMode is set as server SSL mode, which is the port of the SDK application.

15. *reserved3*

Reserved space.

BS2IpConfigExt

```
typedef struct {
    char dnsAddr[BS2_IPV4_ADDR_SIZE];
    char serverUrl[BS2_URL_SIZE];
    uint8_t reserved[32];
} BS2IpConfigExt;
```

1. *dnsAddr*

DNS server address.

2. *serverUrl*

URL of the BioStar application server. The maximum length is 256 characters.

3. *reserved*

Reserved space.

BS2TNAConfig

```
typedef struct {
    uint8_t tnaMode;
    uint8_t tnaKey;
    uint8_t tnaRequired;
    uint8_t reserved[1];
    uint32_t tnaSchedule[BS2_MAX_TNA_KEY];
    uint8_t unused[BS2_MAX_TNA_KEY];
} BS2TNAInfo;

typedef struct {
    char tnaLabel[BS2_MAX_TNA_KEY][BS2_MAX_TNA_LABEL_LEN];
    uint8_t unused[BS2_MAX_TNA_KEY];
} BS2TNAExtInfo;

typedef struct {
    BS2TNAInfo tnaInfo;
    BS2TNAExtInfo tnaExtInfo;
    uint8_t reserved2[32];
} BS2TNAConfig;
```

1. *tnaMode*

Time and attendance management mode.

Value	Description
0	Not used
1	Applying time and attendance code according to a user
2	Applying time and attendance code according to a T&A schedule
3	Applying the time and attendance code that the previous user has selected
4	Using a fixed time and attendance code

2. *tnaKey*

Represents time and attendance code. This is mapped to a key on the device.

Device Type	T&A Code	Mapped Key	Value
BioStation 2	BS2_TNA_UNSPECIFIED	(N/A)	0
	BS2_TNA_KEY_1	F1	1
	BS2_TNA_KEY_2	F2	2
	BS2_TNA_KEY_3	F3	3
	BS2_TNA_KEY_4	F4	4
	BS2_TNA_KEY_5	1	5
	BS2_TNA_KEY_6	2	6
	BS2_TNA_KEY_7	3	7
	BS2_TNA_KEY_8	4	8
	BS2_TNA_KEY_9	5	9
	BS2_TNA_KEY_10	6	10
	BS2_TNA_KEY_11	7	11
	BS2_TNA_KEY_12	8	12
	BS2_TNA_KEY_13	9	13
	BS2_TNA_KEY_14	Call	14
	BS2_TNA_KEY_15	0	15
	BS2_TNA_KEY_16	Esc	16

3. *tnaRequired*

Decides whether time and attendance code entry is mandatory when the time and attendance management mode is set to 1.

4. *reserved*

Reserved space.

5. *tnaSchedule*

Specifies a schedule for a time and attendance code.

6. *unused*

Not used.

7. *tnaLabel*

A label that shows the meaning of the time and attendance code.

8. *unused*

Not used.

BS2CardConfig

```
typedef struct {
    uint8_t primaryKey[6];
    uint8_t reserved1[2];
    uint8_t secondaryKey[6];
    uint8_t reserved2[2];
    uint16_t startBlockIndex;
    uint8_t reserved[6];
} BS2MifareCard;

typedef struct {
    uint8_t primaryKey[8];
    uint8_t secondaryKey[8];
    uint16_t startBlockIndex;
    uint8_t reserved[6];
} BS2IClassCard;

typedef struct {
    uint8_t primaryKey[16];
    uint8_t secondaryKey[16];
    uint8_t appID[3];
    uint8_t fileID;
    uint8_t encryptionType;
    uint8_t operationMode;
    uint8_t reserved[2];
} BS2DesFireCard;

typedef struct {
    uint8_t byteOrder;
    uint8_t useWiegandFormat;
    uint8_t dataType;
    uint8_t useSecondaryKey;
    BS2MifareCard mifare;
    BS2IClassCard iclass;
    BS2DesFireCard desfire;
    uint8_t formatID;
    uint8_t cipher;
    uint8_t reserved[24];
} BS2CardConfig;
```

1. *primaryKey*

Primary encryption key to access the Mifare card information.

2. *reserved1*

Reserved space.

3. secondaryKey

Secondary encryption key to access the Mifare card information.

4. reserved2

Reserved space.

5. startBlockIndex

Start block index on the Mifare data storage.

6. reserved

Reserved space.

7. primaryKey

Primary encryption key to access the iClass card information.

8. secondaryKey

Secondary encryption key to access the iClass card information..

9. startBlockIndex

Start block index on the Mifare data storage.

10. reserved

Reserved space.

11. primaryKey

Primary encryption key to access the DesFire card information.

12. secondaryKey

Secondary encryption key to access the Desfire card information.

13. appID

Application Id that is stored inside the DesFire card for user authentication.

14. fileId

File ID that is stored inside the DesFire card, which will be used by the application to read and write data.

15. encryptionType

Type of data encryption.

Value	Description
0	DES/3DES
1	AES

16. operationMode

Operation mode. (operationMode will be supported soon.)

Value	Description
0	Lagacy mode (Using PICC master key)
1	New mode (Using App master key)

17. reserved

Reserved space.

18. byteOrder

Order of how the byte of the card is stored. When it is set as 0, will function as MSB²⁾. When it is set as 1, will function as LSB³⁾.

19. useWiegandFormat

Decides whether to use Wiegand format.

20. dataType

Type of card data.

Value	Description
0	Binary
1	ASCII
2	UTF16
3	BCD

21. useSecondaryKey

Decides whether to use the secondary encryption key.

22. formatID

ID that is used when the card configuration needs to be managed from the database on the BioStar application.

23. cipher

Activates 'Keypad card ID' option.

Default value is 0, it is only valid for Gangbox Keypad type of Xpass 2, XPass D2.

Value	Description
0	Deactivate
1	Activate

24. reserved5

Reserved space.

BS2FingerprintConfig

```
typedef struct {
    uint8_t      securityLevel;
    uint8_t      fastMode;
    uint8_t      sensitivity;
    uint8_t      sensorMode;
    uint16_t     templateFormat;
    uint16_t     scanTimeout;
    uint8_t      successiveScan;
    uint8_t      advancedEnrollment;
    uint8_t      showImage;
```

```

    uint8_t      lfdLevel;
    bool        checkDuplicate;

    uint8_t      reserved3[31];
} BS2FingerprintConfig;

```

1. ***securityLevel***

Fingerprint authentication security level. This is used across the system.

Value	Description
0	Basic
1	Highly secure
2	The most highly secure

2. ***fastMode***

Fingerprint matching speed.

Value	Description
0	Automatic
1	Basic
2	High
3	Very High

3. ***sensitivity***

Sensitivity of the fingerprint sensor.

Value	Description
0	Lowest
1	Level 1
2	Level 2
3	Level 3
4	Level 4
5	Level 5
6	Level 6
7	Highest

4. ***sensorMode***

Decides the sensor mode. 0 means the sensor is always on. 1 means the sensor is activated when the finger is near the sensor.

5. ***templateFormat***

Fingerprint template type.

Value	Description
0	Suprema
1	ISO
2	ANSI

6. ***scanTimeout***

Fingerprint scanning timeout in seconds. The default is 10 seconds.

7. successiveScan

Not Used.

8. advancedEnrollment

Decides whether to utilize fingerprint quality information. If the option is disabled, the BS_SDK_ERROR_CAPTURE_LOW_QUALITY / BS_SDK_ERROR_EXTRACTION_LOW_QUALITY error codes are not returned even if the quality of fingerprint image acquired is low.

9. showImage

Decides whether to display scanned fingerprint image on the screen.

10. lfdLevel

Configuration for the LFD(Live Fingerprint Detection - fake fingerprint detection) sensitivity.

Value	Description
0	Not Use
1	Strict
2	More Strict
3	Most Strict

11. checkDuplicate

[+ V2.6.4] If set to true, it will determine if the fingerprint is a duplicate.

12. reserved3

Reserved space.

BS2Rs485Config

```

typedef struct {
    uint8_t supportConfig;
    uint8_t useExceptionCode;
    uint8_t exceptionCode[BS2_RS485_MAX_FAIL_CODE_LEN];
    uint8_t outputFormat;
    uint8_t osdpID;
    uint8_t reserved[4];
} BS2IntelligentPDIInfo; //Added 2.8.0 for Intelligent Slave Feature

typedef struct {
    uint32_t baudRate;
    uint8_t channelIndex;
    uint8_t useResistance;
    uint8_t num0fDevices;
    uint8_t reserved[1];
    BS2Rs485SlaveDevice slaveDevices[BS2_RS485_MAX_SLAVES_PER_CHANNEL];
} BS2Rs485Channel;

typedef struct {
    uint8_t mode;
}

```

```

    uint8_t numOfChannels;
    uint8_t reserved[2];
    BS2IntelligentPDInfo intelligentInfo; //Updated to v2.8.0
    uint8_t reserved1[16];
    BS2Rs485Channel channels[BS2_RS485_MAX_CHANNELS];
} BS2Rs485Config;

```

1. supportConfig

[+V2.8] If this value is 0, the device will ignore all settings related to Intelligent PD (Peripheral Device) below.

useExceptionCode

exceptionCode

outputFormat

osdpID

2. useExceptionCode

[+V2.8] This option is available to choose whether the exception code is sent or not.

3. exceptionCode

[+V2.8] This function sends an exception code in case of authentication failure or authentication success but no card registered user.

Set the exception code to be used at this time.

If the exception code is 0 (0x0000000000000000), no exception code is generated.

4. outputFormat

[+V2.8] Intelligent Slave device can send Card ID or User ID upon successful authentication. If it is 0, the card ID is output, if it is 1, the user ID is output.

5. osdpID

[+V2.8] This is a value used to distinguish two or more Suprema Intelligent devices from each other when connecting to the RS485 port of the same third party controller. You can set and designate a unique value between 0 and 127. The default OSDP ID for Suprema intelligent devices is 0.

6. reserved

[+V2.8] Reserved space.

7. baudRate

The RS-485 communication speed which can be configured as below.

Value
9600
19200
38400
57600
115200

8. channelIndex

(non configurable index) Communication channel index of the RS-485 network.

9. useResistance

Resistance flag - no effect on operation.

10. *numOfDevices*

Number of slave devices.

11. *reserved*

Reserved space.

12. *slaveDevices*

List of slave devices, which can be configured up to 32 devices.

13. *mode*

Decides the operating mode on the RS-485 network.

Value	Description
0	Not use
1	Master
2	Slave
3	Standalone

14. *numOfChannels*

Number of RS-485 channel.

15. *reserved*

Reserved space.

16. *intelligentInfo*

[+V2.8] This is Intelligent Slave Device Information

This only works when the device mode is RS485 default.

Once the Suprema device is connected to a slave device to the 3rd party ACU through RS485(OSDP), the Suprema device becomes a Peripheral Device of the OSDP automatically.

17. *reserved1*

Reserved space.

18. *channels*

List of RS-485 channels, which can be configured up to 4 channels.

BS2WiegandConfig

```

typedef struct {
    uint32_t length;
    uint8_t idFields[BS2_WIEGAND_MAX_FIELDS][BS2_WIEGAND_FIELD_SIZE];
    uint8_t parityFields[BS2_WIEGAND_MAX_PARITIES][BS2_WIEGAND_FIELD_SIZE];
    BS2_WIEGAND_PARITY parityType[BS2_WIEGAND_MAX_PARITIES];
    uint8_t parityPos[BS2_WIEGAND_MAX_PARITIES];
} BS2WiegandFormat;

typedef struct {
    uint8_t mode;

```

```

    uint8_t useWiegandBypass;
    uint8_t useFailCode;
    uint8_t failCode;
    uint16_t outPulseWidth;
    uint16_t outPulseInterval;
    uint32_t formatID;
    BS2WiegandFormat format;
    uint16_t wiegandInputMask;
    uint16_t wiegandCardMask;
    uint8_t wiegandCSNIndex;
    uint8_t useWiegandUserID;
    uint8_t reserved[26];
} BS2WiegandConfig;

```

1. ***length***

The length of the wiegand card format.

2. ***idFields***

You can set 4 id fields maximum. Each field's id needs to be inserted from the beginning to the end starting from the end of the array. For example, Standard 26bit wiegand card data is made up as "P FFFFFFFF NNNNNNNNNNNNNNNN P". The Facility Code is "0 1111111 0000000000000000 0", so it has the value of 0x01FE0000, and the Card Number has the value of 0x0001FFE.

```

// for Facility Code
idFields[1][28] = 0x01;
idFields[1][29] = 0xFE;
idFields[1][30] = 0x00;
idFields[1][31] = 0x00;

// for Card Number
idFields[1][28] = 0x00;
idFields[1][29] = 0x01;
idFields[1][30] = 0xFF;
idFields[1][31] = 0xFE;

```

3. ***parityFields***

You can set 4 parity fields maximum, and enter the beginning and the end of the range where to check the parity.

4. ***parityType***

Set the parity type.

Value	Description
0	Does not check parity
1	check odd parity
2	check even parity

5. ***parityPos***

Select the position of the parity bit on the wiegand card data.

6. ***mode***

Set the wiegand Input/Output mode.

Value	Description
0	Input
1	Output
2	In/Output

7. **useWiegandBypass**

The flag that indicates whether to send out a card data.

Value	Description
0	Output when authenticated.
1	Output without authentication.

8. **useFailCode**

The flag that indicates whether to send out a fail code when a card fails to authenticate.

9. **failCode**

Fail code value to replace the card data.

Value
0x00
0xFF

10. **outPulseWidth**

Output pulse width having a range of 20 ~ 100 us.

11. **outPulseInterval**

Output pulse frequency having a range of 200 ~ 20000 us.

12. **formatID**

The value used to distinguish the wiegand card format in the application, and this is not used from the device.

13. **format**

Wiegand format structure.

14. **wiegandInputMask**

Input mask for the wiegand input of the slave and wiegand device.

15. **wiegandCardMask**

Input mask for the wiegand input of the master device.

16. **wiegandCSNIndex**

Index that determines in which format the device will send out a wiegand ouput after the card has been read. This field is used only for Mifare and EM devices. Please check the *useWiegandFormat* field of the [BS2CardConfig](#) structure before configuring.

17. **useWiegandUserID**

The flag you can select whether card ID or user ID to be sent via Wiegand output.

Value	Description
0	Not use
1	Card ID
2	User ID

18. reserved

Reserved space.

BS2WiegandDeviceConfig

```
typedef struct {
    uint32_t deviceID;
    uint16_t port;
    uint8_t switchType;
    uint8_t reserved[1];
} BS2WiegandTamperInput;

typedef struct {
    uint32_t deviceID;
    uint16_t port;
    uint8_t reserved[10];
} BS2WiegandLedOutput;

typedef struct {
    uint32_t deviceID;
    uint16_t port;
    uint8_t reserved[34];
} BS2WiegandBuzzerOutput;

typedef struct {
    BS2WiegandTamperInput tamper;
    BS2WiegandLedOutput led[BS2_WIEGAND_STATUS_NUM];
    BS2WiegandBuzzerOutput buzzer;
    uint32_t reserved[32];
} BS2WiegandDeviceConfig;
```

1. deviceID

ID of the device which will receive the tamper signal of the Wiegand card reader.

2. port

Input port for the Wiegand card reader's tamper.

3. switchType

If the switch type is normally open, and the input isignal is on, it will set off the trigger.

Value	Description
0	Normally open
1	Normally closed

4. reserved

Reserved space.

5. deviceID

ID of the device which will send the LED signal to the Wiegand card reader.

6. port

Output port for the Wiegand card reader's LED signal.

7. reserved

Reserved space.

8. deviceID

ID of the device which will send the buzzer signal to the Wiegand card reader.

9. port

Output port for the Wiegand card reader's buzzer signal.

10. reserved

Reserved space.

10. led

List of devices sending LED signals of the Wiegand card reader, which can be configured up to 2 devices.

Value	Description
0	Red LED
1	Green LED

BS2InputConfig

```

typedef struct {
    uint16_t minValue;
    uint16_t maxValue;
} BS2SVInputRange;

typedef struct {
    uint32_t deviceID;
    uint16_t port;
    uint8_t reserved[10];
} BS2WiegandLedOutput;

typedef struct {
    BS2SVInputRange shortInput;
    BS2SVInputRange openInput;
    BS2SVInputRange onInput;
    BS2SVInputRange offInput;
} BS2SupervisedInputConfig;

typedef struct {

```

```

    uint8_t numInputs;
    uint8_t numSupervised;
    uint16_t reseved;
    struct {
        uint8_t portIndex;
        uint8_t enabled;
        uint8_t supervised_index;
        uint8_t reserved[5];
        BS2SupervisedInputConfig config;
    } supervised_inputs[BS2_MAX_INPUT_NUM];
} BS2InputConfig;

```

1. minValue

Minimum voltage which has a range from 0 ~ 3300(3.3v).

2. maxValue

Maximum voltage which has a range from 0 ~ 3300(3.3v).

3. shortInput

Range of the voltage which will be distinguished as short input.

4. openInput

Range of the voltage which will be distinguished as open input.

5. onInput

Range of the voltage which will be distinguished as on input.

6. offInput

Range of the voltage which will be distinguished as off input.

7. numInputs

Number of input ports.

8. numSupervised

Number of the supervised input ports.

9. portIndex

Input port number.

10. enabled

Decides whether to use as a supervised input.

11. supervised_index

Type of supervised input's resistance value.

Value	Description
0	1k resistance
1	2.2k resistance
2	4.7k resistance
3	10k resistance

Value	Description
255	Custom

12. reserved

Reserved space.

13. config

Configuration that distinguishes the supervised input signal type. This configuration will be valid only when the supervised input's resistance is set as custom .

BS2WlanConfig

```
typedef struct {
    uint8_t enabled;
    uint8_t operationMode;
    uint8_t authType;
    uint8_t encryptionType;
    char essid[BS2_WLAN_SSID_SIZE];
    char authKey[BS2_WLAN_KEY_SIZE];
    uint8_t reserved2[32];
} BS2WlanConfig;
```

1. enabled

Decides whether to use the wireless LAN.

2. operationMode

Type of wireless LAN.

Value	Description
0	infrastructure
1	Ad-hoc

3. authType

Type of Wireless LAN authentication.

Value	Description
0	Open
1	Shared
2	WPA-PSK
3	WPA2-PSK

4. encryptionType

Type of wireless LAN encryption.

Value	Description
0	None
1	WEP
2	TKIP/AES
3	AES

Value	Description
3	TKIP

5. *essid*

ESS ID of the wireless network.

6. *authKey*

Password of the wireless network.

7. *reserved*

Reserved space.

BS2Trigger

```
typedef struct {
    uint16_t code;
    uint8_t reserved[2];
} BS2EventTrigger;

typedef struct {
    uint8_t port;
    uint8_t switchType;
    uint16_t duration;
    uint32_t scheduleID;
} BS2InputTrigger;

typedef struct {
    uint32_t type;
    uint32_t scheduleID;
} BS2ScheduleTrigger;

typedef struct {
    uint32_t deviceID;
    uint8_t type;
    uint8_t reserved[3];

    union {
        BS2EventTrigger event;
        BS2InputTrigger input;
        BS2ScheduleTrigger schedule;
    }
} BS2Trigger;
```

1. *code*

Event log that will set off the trigger.

2. *reserved*

Reserved space.

3. port

Input port number that will set off the trigger.

4. switchType

If the switch type is normally open, and the input signal is on, it will set off the trigger.

Value	Description
0	Normally open
1	Normally closed

5. duration

The duration time of the signal that will set off the trigger. The unit of time is milliseconds and the minimum value is 100.

6. scheduleID

ID of the time schedule when to operate the trigger.

7. type

Type of the schedule trigger.

Value	Description
0	Start schedule trigger
1	End schedule trigger

8. scheduleID

ID of the time schedule when to operate the trigger.

9. deviceID

ID of the device that will perform the trigger.

10. type

Type of trigger.

Value	Description
0	None
1	Event trigger
2	Input trigger
3	Schedule trigger

BS2Action

```

typedef struct {
    uint32_t signalID;
    uint16_t count;
    uint16_t onDuration;
    uint16_t offDuration;
    uint16_t delay;
} BS2Signal;

typedef struct {

```

```
    uint8_t portIndex;
    uint8_t reserved[3];
    BS2Signal signal;
} BS2OutputPortAction;

typedef struct {
    uint8_t relayIndex;
    uint8_t reserved[3];
    BS2Signal signal;
} BS2RelayAction;

typedef struct {
    uint8_t color;
    uint8_t reserved[1];
    uint16_t duration;
    uint16_t delay;
} BS2LedSignal;

typedef struct {
    uint16_t count;
    uint8_t reserved[2];
    BS2LedSignal signal[3];
} BS2LedAction;

typedef struct {
    uint8_t tone;
    uint8_t fadeout;
    uint16_t duration;
    uint16_t delay;
} BS2BuzzerSignal;

typedef struct {
    uint16_t count;
    uint8_t reserved[2];
    BS2BuzzerSignal signal[3];
} BS2BuzzerAction;

typedef struct {
    uint8_t duration;
    uint8_t reserved[3];
    uint32_t displayID;
    uint32_t resourceId;
} BS2DisplayAction;

typedef struct {
    uint8_t count;
    uint16_t soundIndex;
    uint8_t reserved[5];
} BS2SoundAction;

typedef struct {
```

```

    uint32_t deviceID;
    uint8_t type;
    uint8_t stopFlag;
    uint16_t delay;
    union {
        BS2RelayAction relay;
        BS2OutputPortAction outputPort;
        BS2DisplayAction display;
        BS2SoundAction sound;
        BS2LedAction led;
        BS2BuzzerAction buzzer;
    };
} BS2Action;

```

1. *signalID*

Index that is used to manage the signal type from the application.

2. *count*

Number of signal execution count.

3. *onDuration*

Duration of the ON signal. The unit of time is milliseconds.

4. *offDuration*

Duration of the OFF signal. The unit of time is milliseconds.

5. *delay*

Delay time before the signal starts. The unit of time is milliseconds/ For example, count(2), onDuration(100), offDuration(100), delay(50) will execute a signal as below.

50ms wait	signal on(100)	signal off(100)	signal on(100)	signal off(100)
------------------	-----------------------	------------------------	-----------------------	------------------------

6. *portIndex*

Number of the TTL output port.

7. *reserved*

Reserved Space.

8. *relayIndex*

Number of the TTL output port.

9. *reserved*

Reserved Space.

10. *color*

LED color type.

Value	Description
0	LED Off
1	Red LED
2	Yellow LED

Value	Description
3	Green LED
4	Blue-Green LED
5	Blue LED
6	Magenta LED
7	White LED

11. reserved

Reserved space.

12. duration

Duration of the LED. The unit of time is milliseconds.

13. delay

Delay before the LED flickers. The unit of time is milliseconds.

14. count

Number of LED signal count. When set as 0 it is disabled, and when set as -1 it will repeat infinitely.

15. reserved

Reserved space.

16. tone

Volume of the buzzer.

Value	Description
0	No sound
1	Low
2	Medium
3	High

17. count

Number of buzzer signal count. When set as 0 it is disabled, and when set as -1 it will repeat infinitely.

18. reserved

Reserved space.

19. duration

Duration of the display operation. The unit of time is milliseconds.

20. reserved

Reserved space.

21. displayID

Not supported yet.

22. resourceId

Not supported yet.

23. count

Number of the sound signal count.

24. *soundIndex*

Index of the sound resource.

Value	Description
0	Welcome sound
1	Auth success sound
2	Auth fail sound

25. *deviceID*

ID of the device that will execute the action.

26. *type*

Action types.

[DoorModule-20, CoreStation-40]

If the action type is relay or TTL (Output) and the action device is DM20, CS40, Action type should be set only as relay action (6). (TTL setting not possible)

[DM20]

- Action type : Relay
- relay.relayIndex : 0 ~ 3 (RELAY 0 ~ 3)
- relay.relayIndex : 4 ~ 9 (OUTPUT 0 ~ 5)

[CS40]

- Action type : Relay
- relay.relayIndex : 0 ~ 3 (RELAY 0 ~ 3)
- relay.relayIndex : 4 ~ 11 (OUTPUT 0 ~ 7)

Value	Description
0	None
1	Lock device
2	Unlock device
3	Reboot device
4	Release alarm
5	General input
6	Relay action
7	TTL action
8	Sound action
9	Display action
10	Buzzer action
11	Led action
12	Fire alarm input

Value	Description
13	Auth Success(Access granted)
14	Auth Fail(Access denied)
15	Lift action

27. *stopFlag*

Specifies the condition to stop the Action.

If this value is set to 1 and the signal is detected through the door sensor, the action will stop.

If this value is set to 2, it can be stopped only by the current action information.

In general, related APIs that stop an action are called with a zone id, in which case all devices in the zone will stop the action.

By setting stopFlag to 2 and loading action information, you can selectively control only the alarms of that device.

Value	Description
0	Don't stop
1	Stop if door is closed
2	Stop by command(Added in V2.6.0)

28. *delay*

Action delay. Unit is millisecond(ms).

BS2TriggerActionConfig

```
typedef struct {
    uint8_t numItems;
    uint8_t reserved[3];
    BS2TriggerAction items[BS2_MAX_TRIGGER_ACTION];
    uint8_t reserved2[32];
} BS2TriggerActionConfig;
```

1. *numItems*

Number of trigger actions.

2. *reserved*

Reserved space.

3. *items*

List of trigger actions, which can be configured up to 128 trigger actions.

4. *reserved2*

Reserved space.

BS2EventConfig

```
typedef struct {
    uint32_t numImageEventFilter;
```

```

struct {
    uint8_t mainEventCode;
    uint8_t reserved[3];
    uint32_t scheduleID;
} imageEventFilter[BS2_EVENT_MAX_IMAGE_CODE_COUNT];
uint8_t reserved[32];
} BS2EventConfig;

```

1. numImageEventFilter

Number of image log filters.

2. mainEventCode

Main code of the log where the image log will be placed.

3. reserved

Reserved space.

4. scheduleID

ID of the time schedule when to store the image logs.

5. reserved

Reserved space.

BS2WiegandMultiConfig

```

typedef struct {
    uint32_t formatID;
    BS2WiegandFormat format;
    uint8_t reserved[32];
} BS2WiegandInConfig;

typedef struct {
    BS2WiegandInConfig formats[MAX_WIEGAND_IN_COUNT];
    uint8_t reserved[32];
} BS2WiegandMultiConfig;

```

1. formatID

Wiegand format index.

2. format

Wiegand format structure.

3. reserved

Reserved space.

4. formats

Available to configure up to 15 formats.

5. reserved

Reserved space.

BS1CardConfig

```
typedef struct {
    enum {
        MIFARE_KEY_SIZE = 6,
        MIFARE_MAX_TEMPLATE = 4,
        VALID_MAGIC_NO = 0x1f1f1f1f,
    };

    // Options
    uint32_t magicNo;
    uint32_t disabled;
    uint32_t useCSNOnly;           // default 0
    uint32_t bioentryCompatible;  // default 0

    // Keys
    uint32_t useSecondaryKey;
    uint32_t reserved1;
    uint8_t primaryKey[MIFARE_KEY_SIZE];
    uint8_t reserved2[2];
    uint8_t secondaryKey[MIFARE_KEY_SIZE];
    uint8_t reserved3[2];

    // Layout
    uint32_t cisIndex;
    uint32_t num0fTemplate;
    uint32_t templateSize;
    uint32_t templateStartBlock[MIFARE_MAX_TEMPLATE];

    uint32_t reserve4[15];
} BS1CardConfig;
```

1. *magicNo*

Not used.

2. *disabled*

Not used.

3. *useCSNOnly*

Flag that indicates whether to read the v1 ToC cards.

4. *bioentryCompatible*

Not used.

5. *useSecondaryKey*

Not used.

6. *reserved1*

Reserved space.

7. *primaryKey*

Not used.

8. *reserved2*

Reserved space.

9. *secondaryKey*

Not used.

10. *reserved3*

Reserved Space.

11. *cisIndex*

Not used.

12. *numOfTemplate*

Number of template that is used.

13. *templateSize*

Size of each template.

14. *templateStartBlock*

Not used.

15. *reserve4*

Reserved Space.

BS2SystemConfigExt

```
typedef struct {
    uint8_t primarySecureKey[SEC_KEY_SIZE];
    uint8_t secondarySecureKey[SEC_KEY_SIZE];

    uint8_t reserved3[32];
} BS2SystemConfigExt;
```

1. *primarySecureKey*

Primary encryption key used between master and slave devices.

2. *secondarySecureKey*

Secondary encryption key used between master and slave devices.

3. *reserved3*

Reserved space.

BS2VoipConfig

```

typedef struct {
    BS2_URL          serverUrl;           ///
    BS2_PORT         serverPort;          ///
    BS2_USER_ID      userID;              ///
    BS2_USER_ID      userPW;              ///

    uint8_t          exitButton;          /// << *, #, 0~9
    uint8_t          dtmfMode;            ///
    BS2_BOOL         bUse;                ///
    uint8_t          reseverd[1];         ///

    uint32_t         numPhonBook;
    BS2UserPhoneItem phonebook[BS2_VOIP_MAX_PHONEBOOK]; ///

    uint8_t          reserved2[32];        ///
} BS2VoipConfig;

```

1. *serverUrl*

URL of the SIP server.

2. *serverPort*

Port number of the SIP server.

3. *userID*

User ID to access the SIP server.

4. *userPW*

Password that is used to access the SIP server.

5. *exitButton*

Button to be used as an exit button. (*, #, 0~9)

Value	Description
0	*
1	#
2 ~ 11	0 ~ 9

6. *dtmfMode*

Tone of the keypad.

7. *bUse*

Flag that determines whether the VoIP feature is used.

8. *reseverd*

Reserved space.

9. *numPhonBook*

Number of phone books.

10. *phonebook*

List of extension numbers, which can be configured up to 32.

8. *reserved2*

Reserved space.

BS2FaceConfig

```
typedef struct {
    uint8_t      securityLevel;
    uint8_t      lightCondition;
    uint8_t      enrollThreshold;
    uint8_t      detectSensitivity;

    uint16_t     enrollTimeout;
    uint8_t      lfdLevel;
    bool         quickEnrollment;

    uint8_t      previewOption;
    bool         checkDuplicate;
    uint8_t      operationMode;
    uint8_t      maxRotation;

    struct {
        uint16_t  min;
        uint16_t  max;
    } faceWidth;

    struct {
        uint16_t  x;
        uint16_t  width;
    } searchRange;

    uint8_t      reserved2[18];
} BS2FaceConfig;
```

1. ***securityLevel***

Face authentication security level. This is used across the system. .

Value	Description
0	Basic
1	Highly secure
2	Most highly secure

2. ***lightCondition***

Configuration of the light condition.

Value	Description
0	Indoor
1	Outdoor
2	Automatic
3	[+V2.8] Not used (FaceStation F2 v1.1.0 or higher version)

[Note]

FaceStation F2: v1.0.0 - v1.0.5

Ambient Brightness: Normal, High, Auto

FaceStation F2: v1.1.0 or higher version

Light Brightness: Normal, High, Not Used

3. **enrollThreshold**

Threshold of face enrollment. It determines how much movement of pose is allowed when enrolling the face.

Value	Description
0	THRESHOLD_0 (Most strict)
1	THRESHOLD_1
2	THRESHOLD_2
3	THRESHOLD_3
4	THRESHOLD_4 (Default)
5	THRESHOLD_5
6	THRESHOLD_6
7	THRESHOLD_7
8	THRESHOLD_8
9	THRESHOLD_9 (Least strict)

4. **detectSensitivity**

Configuration of sensitivity on detecting the face.

Value	Description
0	Off
1	Low
2	Medium
3	High

5. **enrollTimeout**

FaceStation2, FaceLite : Timeout period of face scanning which is 60 seconds by default.

Value	Description
BS2_FACE_ENROLL_TIMEOUT_MIN	30
BS2_FACE_ENROLL_TIMEOUT_MAX	60
BS2_FACE_ENROLL_TIMEOUT_DEFAULT	BS2_FACE_ENROLL_TIMEOUT_MAX

FaceStation F2 : [+ V2.7.1] Face scan wait time, default is 20 seconds.

Value	Description
BS2_FACE_EX_ENROLL_TIMEOUT_MIN	10
BS2_FACE_EX_ENROLL_TIMEOUT_MAX	20
BS2_FACE_EX_ENROLL_TIMEOUT_DEFAULT	BS2_FACE_EX_ENROLL_TIMEOUT_MAX

6. *lfdLevel*

[+ V2.6.3] Configuration for the LFD(Live Face Detection - fake face detection) sensitivity.

FaceStation2, FaceLite : Default is 0.

FaceStation F2 : [+ V2.7.1] Default is 1.

Value	Description
0	Not Use
1	Strict
2	More Strict
3	Most Strict

7. *quickEnrollment*

[+ V2.6.3] Quick face enrollment process.

True - Face enrollment process with a single step.

False - Face enrollment process with 3 steps.

Please use false if you want to enroll with a high quality of face templates.

8. *previewOption*

[+ V2.6.3] IR camera preview option when you authenticate with the face.

Only used to FaceLite.

Value	Description
0	Preview not used
1	Preview not used at first of authentication, preview at 1/2 stage
2	Preview of all stages on authentication

9. *checkDuplicate*

[+ V2.6.4] Check whether the scanned face is duplicated in the device.

10. *operationMode*

[+ V2.7.1] FaceStation F2 Configures operation mode with below values, default is Fusion mode.

Value	Mode	Description	Default
0	Fusion Mode	Visual matching + IR matching	Default
1	Visual Mode	Visual matching	
2	Visual + IR	Visual matching, IR detects only face	

11. *maxRotation*

[+ V2.7.1] FaceStation F2 When face is recognized normally it's front side.

Still, it is possible to determine how many degrees the image has been rotated from the front when FSF2 detects a face.

This enables detection failure in the case of images rotated over a certain angle. maxRotation represents the maximum allowable value in this case, and the default value is 15 degrees.

12. **faceWidth**

[+ V2.7.1] FaceStation F2 This indicates the width of the face image, and you can specify the minimum and maximum values.

[+ 2.8.3] BioStation 3 The settings are ignored.

	Default(min)	Default(max)
FSF2	66	250
BS3	-	-

13. **searchRange**

[+ V2.7.1]

FaceStation F2

Represents the face search range, and you can specify the x value (horizontal coordinate) of the range and the width from the x value point.

The default values of x and width are as follows.

[+ 2.8.3]

BioStation 3 The settings are ignored.



14.

det

ect

Dist

anc

e

[+

2.8.

3]

Bio

Sta

tio

n 3

This

con

figu

res

the

min
imu
m
and
ma
xim
um
det
ecti
on
ran
ge
for
faci
al
rec
ogn
itio
n..
We
no
lon
ger
sup
port
fac
eWi
dth
to
pin
poi
nt
the
fac
e
loca
tion
usi
ng
pix
el
unit
s
due
to
its
co
mpl
exit
y.
Inst

ead
,
we
set
the
det
ecti
on
ran
ge
of
the
sub
ject
(fac
e).
The
unit
is
set
to
cm,
and
the
val
ue
mu
st
be
inp
utte
d
as
a
mul
tipl
e of
10.

=====

15.
wid
eSe
arc
h
[+
2.8.
3]
Bio
Sta
tio

n 3
This
can
incr
eas
e
the
det
ecti
on
ran
ge
for
faci
al
rec
ogn
itio
n.
We
no
lon
ger
sup
port
sea
rch
Ran
ge
to
set
the
x-
coo
rdin
ate
and
wid
th
due
to
its
co
mpl
exit
y.
Inst
ead
,
we
set

the
fac
e
det
ecti
on
sett
ing
as
def
ault
(fal
se),
or a
wid
e
are
a(tr
ue).
The
det
ails
of
the
sett
ing
s
and
prot
ocol
s
for
the
det
ecti
on
of
wid
e
are
a is
set
wit
hin
the
dev
ice,
whi
ch
the
use

r
can
not
cha
nge
.

If
this
sett
ing
is
set
to
TRU
E,
the
ca
mer
a
det
ect
s
sub
ject
s
wit
hin
a
larg
e
ran
ge,
and
uni
nne
ntio
nall
y
det
ect
and
aut
hen
tica
te
mul
tipl
e
sub
ject

s at
onc
e.
The
refo
re,
the
def
ault
sett
ing
is
at
fals
e.

16.
unu
sed
Res
erv
ed
spa
ce.

17.
res
erv
ed
Res
erv
ed
spa
ce.

BS
2R
s4
85
Co
nfi
gE
X

ty
pe
de
f
st

```
ru
ct
{
ui
nt
32
_t
ba
ud
Ra
te
;
ui
nt
8_
t
ch
an
ne
lI
nd
ex
;
ui
nt
8_
t
us
eR
eg
is
ta
nc
e;
ui
nt
8_
t
nu
m0
fD
ev
ic
es
;
ui
nt
8_
t
re
se
```

```
rv  
ed  
[1  
];  
BS  
2R  
s4  
85  
Sl  
av  
eD  
ev  
ic  
eE  
X  
sl  
av  
eD  
ev  
ic  
es  
[B  
S2  
_R  
S4  
85  
_M  
AX  
_S  
LA  
VE  
S_  
PE  
R_  
CH  
AN  
NE  
L;  
;  
}  
BS  
2R  
s4  
85  
Ch  
an  
ne  
lE  
X;  
ty
```

```
pe  
de  
f  
st  
ru  
ct  
{  
ui  
nt  
8_  
t  
mo  
de  
[B  
S2  
_R  
S4  
85  
_M  
AX  
_C  
HA  
NN  
EL  
S_  
EX  
];  
ui  
nt  
8_  
t  
nu  
m0  
fC  
ha  
nn  
el  
s;  
ui  
nt  
8_  
t  
re  
se  
rv  
ed  
[2  
];  
ui  
nt  
8_
```

```
t  
re  
se  
rv  
ed  
1[  
32  
];  
BS  
2R  
s4  
85  
Ch  
an  
ne  
lE  
X  
ch  
an  
ne  
ls  
[B  
S2  
_R  
S4  
85  
_M  
AX  
_C  
HA  
NN  
EL  
S]  
;  
}  
BS  
2R  
s4  
85  
Co  
nf  
ig  
EX  
;
```

1.
bau
dRa
te
The
RS-

485
co
mm
uni
cati
on
spe
ed
whi
ch
can
be
con
figu
red
as
bel
ow.

Value
9600
19200
38400
57600
115200

2.
*cha
nne
lInd
ex
Co
mm
uni
cati
on
cha
nne
l
ind
ex
of
the
RS-
485
net
wor
k.*

3.
*use
Reg
ista
nce*

Dec
ides
wh
eth
er
to
use
a
resi
sta
nce
.

4.
*nu
mO
fDe
vice
s
Nu
mb
er
of
slav
e
dev
ices*
.

5.
*slav
eDe
vice
s
List
of
slav
e
dev
ices*

,

whi
ch
can
be
con
figu
red
up
to
32

dev
ices

.

6.
mo
de
Dec
ides
the
ope
rati
ng
mo
de
on
the
RS-
485
net
wor
k.

Value	Description
0	Master
1	Slave
2	Groundline

7.
nu
mO
fCh
ann
els
Nu
mb
er
of
RS-
485
cha
nne
l.

8.
res
erv
ed
Res
erv
ed
spa
ce.

9.
res
erv
ed1
Res
erv
ed
spa
ce.

10.
cha
nne
ls
List
of
RS-
485
cha
nne
ls,
whi
ch
can
be
con
figu
red
up
to 8
cha
nne
ls.

BS
2C
ar
dC
on
fig
Ex

ty
pe
de
f
st
ru
ct

```
{  
ui  
nt  
8_  
t  
oi  
d_  
AD  
F[  
13  
];  
//  
/  
//  
va  
li  
d  
va  
lu  
e/  
/{  
0x  
2A  
,  
0  
x8  
5,  
0x  
70  
,  
0  
x8  
1,  
0x  
1E  
,  
0  
x1  
0,  
0x  
00  
,  
0  
x0  
7,  
0x  
00  
,  
0  
x0  
0,  
0x  
02  
,  
0  
x0  
0,
```

```
0x
00
}
ui
nt
8_
t
si
ze
_A
DF
;
//ui
nt
8_
t
re
se
rv
ed
1[
2]
;
///
/
ui
nt
8_
t
oi
d_
Da
ta
Ob
je
ct
ID
[8
];
ui
nt
16
_t
si
ze
_D
at
a0
bj
ec
```

```
t[  
8]  
;  
ui  
nt  
8_  
t  
pr  
im  
ar  
yK  
ey  
Au  
th  
[1  
6]  
;  
//  
va  
li  
d  
va  
lu  
e  
ui  
nt  
8_  
t  
se  
co  
nd  
ar  
yK  
ey  
Au  
th  
[1  
6]  
;  
//  
/  
//  
va  
li  
d  
va  
lu  
e  
ui  
nt  
8_
```

```
t  
re  
se  
rv  
ed  
2[  
24  
];  
}  
BS  
2S  
eo  
sC  
ar  
d;  
ty  
pe  
de  
f  
st  
ru  
ct  
{  
BS  
2S  
eo  
sC  
ar  
d  
se  
os  
;  
ui  
nt  
8_  
t  
re  
se  
rv  
ed  
[2  
4]  
;  
}  
BS  
2C  
ar  
dC  
on  
fi  
gE
```

x;

1.

oid_
ADF
ADF
Add
res
s
(No
n
cha
nga
ble)

2.

size
_AD
F
ADF
size

3.

res
erv
ed1
Res
erv
ed
sap
ce

4.

oid_
Dat
aOb
ject
ID
Dat
aOb
ject
ID

5.

size
_Da
taO
bje
ct
Dat
aOb

ject
size

6.
pri
mar
yKe
yAu
th
Pri
mar
y
enc
rypt
ion
key
to
acc
ess
the
Seo
sca
rd
info
rma
tion

7.
sec
ond
ary
Key
Aut
h
Sec
ond
ary
enc
rypt
ion
key
to
acc
ess
the
Seo
sca
rd
info
rma
tion

8.
res
erv
ed2
Res
erv
ed
spa
ce

9.
seo
s
BS2
Seo
sCa
rd
info
rma
tion

10.
res
erv
ed
Res
erv
ed
spa
ce

BS
2D
st
Co
nfi
g

en
um
{
BS
2_
MA
X_
DS
T_
SC
HE

```
DU
LE
=
2,
};

ty
pe
de
f
st
ru
ct
{
ui
nt
16
_t
ye
ar
;
//ye
ar
,
0
me
an
s
ev
er
y
ye
ar
.
ui
nt
8_
t
mo
nt
h;
//[
0
,
11
]
:
mo
nt
hs
```

```
si  
nc  
e  
Ja  
nu  
ar  
y  
in  
t8  
_t  
or  
di  
na  
l;  
//  
[0  
,  
-1  
]  
:  
fi  
rs  
t,  
se  
co  
nd  
,  
..  
.,  
la  
st  
ui  
nt  
8_  
t  
we  
ek  
Da  
y;  
//  
[0  
,  
6]  
:  
da  
ys  
si  
nc  
e  
Su  
nd
```

```
ay
ui
nt
8_
t
ho
ur
;
//[
,
23
]
ui
nt
8_
t
mi
nu
te
;
//[
,
59
]
ui
nt
8_
t
se
co
nd
;
//[
,
59
]
}
BS
2W
ee
kT
im
e;
ty
pe
de
f
```

```
st
ru
ct
{
BS
2W
ee
kT
im
e
st
ar
tT
im
e;
BS
2W
ee
kT
im
e
en
dT
im
e;
in
t3
2_
t
ti
me
Of
fs
et
;
//in
se
co
nd
s
ui
nt
8_
t
re
se
rv
ed
[4
];
}
```

```
    }  
BS  
2D  
st  
Sc  
he  
du  
le  
;  
  
ty  
pe  
de  
f  
st  
ru  
ct  
{  
ui  
nt  
8_  
t  
nu  
mS  
ch  
ed  
ul  
es  
;  
ui  
nt  
8_  
t  
re  
se  
rv  
ed  
[3  
1]  
;  
  
BS  
2D  
st  
Sc  
he  
du  
le  
sc  
he  
du
```

```
le  
s [  
BS  
2_  
MA  
X_  
DS  
T_  
SC  
HE  
DU  
LE  
];  
}  
BS  
2D  
st  
Co  
nf  
ig  
;
```

1.
year
Me
ans
year,
and
if
set
to
0, it
me
ans
yearly.

2.
month
Me
ans
month,
and
has
a
value

bet
wee
n 0
and
11
[Jan
uar
y-
Dec
em
ber]
.

3.
*ordi
nal*
It
star
ts
wit
h 0
and
me
ans
the
ord
er
of
first
,,
sec
ond
,,
etc.

4.
wee
*kDa
y*
Day
of
the
wee
k, 0
me
ans
Sun
day
, 1
me
ans

Mo
nda
y.

5.
hou
r
Spe
cifi
es
the
tim
e in
24-
hou
r
for
mat
. .

6.
min
ute
Spe
cifi
es
the
min
ute.

7.
sec
ond
Spe
cifi
es
the
sec
ond
s.

8.
star
tTi
me
It
me
ans
star
t
dat

e
and
tim
e.

9.
end
Tim
e
It
me
ans
the
end
dat
e.

10.
tim
eO
ffse
t
You
can
app
ly
the
DST
tim
e in
sec
ond
s.
For
exa
mpl
e, if
you
wa
nt
to
app
ly 1
hou
r,
ent
er
360
0.

11.

res
erv
ed
Res
erv
ed
spa
ce.

12.
nu
mS
che
dul
es
The
nu
mb
er
of
DST
sch
edu
les
to
app
ly.

13.
sch
edu
les
DST
sch
edu
le,
up
to
two
can
be
spe
cifi
ed.

BS
2C
on

fig**s**

```
ty  
pe  
de  
f  
st  
ru  
ct  
{  
ui  
nt  
32  
_t  
co  
nf  
ig  
Ma  
sk  
;  
BS  
2F  
ac  
to  
ry  
Co  
nf  
ig  
fa  
ct  
or  
yC  
on  
fi  
g;  
BS  
2S  
ys  
te  
mC  
on  
fi  
g  
sy  
st  
em  
Co  
nf  
ig  
;
```

```
BS  
2A  
ut  
hC  
on  
fi  
g  
au  
th  
Co  
nf  
ig  
;  
BS  
2S  
ta  
tu  
sC  
on  
fi  
g  
st  
at  
us  
Co  
nf  
ig  
;  
BS  
2D  
is  
pl  
ay  
Co  
nf  
ig  
di  
sp  
la  
yC  
on  
fi  
g;  
BS  
2I  
pC  
on  
fi  
g  
ip  
Co
```

```
nf  
ig  
;  
BS  
2I  
pC  
on  
fi  
gE  
xt  
ip  
Co  
nf  
ig  
Ex  
t;  
BS  
2T  
NA  
Co  
nf  
ig  
tn  
aC  
on  
fi  
g;  
BS  
2C  
ar  
dC  
on  
fi  
g  
ca  
rd  
Co  
nf  
ig  
;  
BS  
2F  
in  
ge  
rp  
ri  
nt  
Co  
nf  
ig  
fi
```

```
ng  
er  
pr  
in  
tC  
on  
fi  
g;  
BS  
2R  
s4  
85  
Co  
nf  
ig  
rs  
48  
5C  
on  
fi  
g;  
BS  
2W  
ie  
ga  
nd  
Co  
nf  
ig  
wi  
eg  
an  
dC  
on  
fi  
g;  
BS  
2W  
ie  
ga  
nd  
De  
vi  
ce  
Co  
nf  
ig  
wi  
eg  
an  
dD
```

```
ev  
ic  
eC  
on  
fi  
g;  
BS  
2I  
np  
ut  
Co  
nf  
ig  
in  
pu  
tC  
on  
fi  
g;  
BS  
2W  
la  
nC  
on  
fi  
g  
wl  
an  
Co  
nf  
ig  
;  
BS  
2T  
ri  
gg  
er  
Ac  
ti  
on  
Co  
nf  
ig  
tr  
ig  
ge  
rA  
ct  
io  
nC  
on
```

```
fi
g;
BS
2E
ve
nt
Co
nf
ig
ev
en
tC
on
fi
g;
BS
2W
ie
ga
nd
Mu
lt
iC
on
fi
g
wi
eg
an
dM
ul
ti
Co
nf
ig
;
BS
1C
ar
dC
on
fi
g
ca
rd
1x
Co
nf
ig
;
BS
```

```
2S  
ys  
te  
mC  
on  
fi  
gE  
xt  
sy  
st  
em  
Ex  
tC  
on  
fi  
g;  
BS  
2V  
oi  
pC  
on  
fi  
g  
vo  
ip  
Co  
nf  
ig  
;  
BS  
2F  
ac  
eC  
on  
fi  
g  
fa  
ce  
Co  
nf  
ig  
;  
}  
BS  
2C  
on  
fi  
gs  
;
```

1.

con

fig

Ma

sk

Mas

k

val

ue

of

the

con

figu

rati

on

to

be

retr

iev

ed

or

set.



BS

2I

PV

6C

on

fig

en

um

{

BS

2_

MA

X_

IP

V6

_A

LL

0C

```
AT
ED
_A
DD
R
=
8,
};

ty
pe
de
f
st
ru
ct
{
ui
nt
8_
t
us
eI
PV
6;
ui
nt
8_
t
re
se
rv
ed
1;
ui
nt
8_
t
us
eD
hc
pV
6;
ui
nt
8_
t
us
eD
ns
V6
```

```
;  
ui  
nt  
8_t  
re  
se  
rv  
ed  
[1  
];  
ch  
ar  
st  
at  
ic  
Ip  
Ad  
dr  
es  
sV  
6[  
BS  
2_  
IP  
V6  
_A  
DD  
R_  
SI  
ZE  
];  
ch  
ar  
st  
at  
ic  
Ga  
te  
wa  
yV  
6[  
BS  
2_  
IP  
V6  
_A  
DD  
R_  
SI  
ZE
```

```
];
ch
ar
dn
sA
dd
rV
6[
BS
2_
IP
V6
_A
DD
R_
SI
ZE
];
ch
ar
se
rv
er
Ip
Ad
dr
es
sV
6[
BS
2_
IP
V6
_A
DD
R_
SI
ZE
];
ui
nt
16
_t
se
rv
er
Po
rt
V6
;
ui
```

```
nt  
16  
_t  
ss  
lS  
er  
ve  
rP  
or  
tV  
6;  
ui  
nt  
16  
_t  
po  
rt  
V6  
;  
ui  
nt  
8_  
t  
nu  
m0  
fA  
ll  
oc  
at  
ed  
Ad  
dr  
es  
sV  
6;  
ui  
nt  
8_  
t  
nu  
m0  
fA  
ll  
oc  
at  
ed  
Ga  
te  
wa  
yV  
6;
```

```
ui  
nt  
8_t  
re  
se  
rv  
ed  
[8  
];  
ch  
ar  
al  
lo  
ca  
te  
dI  
pA  
dd  
re  
ss  
V6  
[B  
S2  
_I  
PV  
6_  
AD  
DR  
_S  
IZ  
E]  
[B  
S2  
_M  
AX  
_I  
PV  
6_  
AL  
LO  
CA  
TE  
D_  
AD  
DR  
];  
ch  
ar  
al  
lo
```

```
cate  
dG  
at  
ew  
ay  
V6  
[B  
S2  
_I  
PV  
6_  
AD  
DR  
_S  
IZ  
E]  
[B  
S2  
_M  
AX  
_I  
PV  
6_  
AL  
L0  
CA  
TE  
D_  
AD  
DR  
];  
}  
BS  
2I  
pC  
on  
fi  
g;
```

```
1.  
use  
IPV  
6  
Fla  
g  
indi  
cati  
ng  
wh  
eth
```

er
to
use
IP
V6.

2.
res
erv
ed1
Res
erv
ed
spa
ce.

3.
use
Dhc
pV6
Fla
g
indi
cati
ng
wh
eth
er
to
use
DH
CP.

4.
use
Dns
V6
Dec
ides
wh
eth
er
to
use
ser
ver
add
res
s or
ser
ver

URL

.

5.

*stat
iclp
Add
res
sv6
Stat
ic IP
V6
add
res
s of
curr
ent
dev
ice.*

6.

*stat
icG
ate
way
V6
Stat
ic IP
V6
add
res
s of
gat
ewa
y.*

7.

*dns
Add
rV6
DN
S
add
res
s.*

8.

*ser
verl
pAd
dre*

ssV
6
IP
add
res
s of
Bio
Star

.

Use
d
onl
y in
the
ser
ver
mo
de.

9.
ser
ver
Port
V6
Port
nu
mb
er
of
Bio
Star

.

Use
d
onl
y in
the
ser
ver
mo
de.

10.
sslS
erv
erP
ort
V6
Use
d
wh

en
the
con
nec
tion
Mo
de
is
set
as
ser
ver
SSL
mo
de,
whi
ch
is
the
port
of
the
SDK
app
lica
tion

.

11.
port
V6
Port
nu
mb
er
of
the
dev
ice.

12.
*nu
mO
fAll
oca
ted
Add
res
sV6*
The
nu

mb
er
of
IP
V6
add
res
s
curr
entl
y
assi
gne
d to
the
dev
ice.

13.
nu
mO
fAll
oca
ted
Gat
ewa
yV6
The
nu
mb
er
of
gat
ewa
y
add
res
s
curr
entl
y
assi
gne
d to
the
dev
ice.

14.
res
erv

ed
Res
erv
ed
spa
ce.

15.
allo
cat
edl
pAd
dre
ssV
6
The
IP
V6
add
res
s
curr
entl
y
assi
gne
d to
the
dev
ice.

16.
allo
cat
edG
ate
way
V6
The
gat
ewa
y
add
res
s
curr
entl
y
assi
gne
d to

the
dev
ice.

BS 2D es Fir eC ar dC on fig Ex

```
ty  
pe  
de  
f  
st  
ru  
ct  
{  
ui  
nt  
8_  
t  
ap  
pM  
as  
te  
rK  
ey  
[1  
6]  
;  
ui  
nt  
8_  
t  
fi  
le  
Re  
ad  
Ke  
y[  
16  
];
```

```
ui  
nt  
8_  
t  
fi  
le  
Wr  
it  
eK  
ey  
[1  
6]  
;  
ui  
nt  
8_  
t  
fi  
le  
Re  
ad  
Ke  
yN  
um  
be  
r;  
ui  
nt  
8_  
t  
fi  
le  
Wr  
it  
eK  
ey  
Nu  
mb  
er  
;  
ui  
nt  
8_  
t  
re  
se  
rv  
ed  
[2  
];  
}
```

```
BS  
2D  
es  
Fi  
re  
Ap  
pL  
ev  
el  
Ke  
y;  
//  
/<  
52  
by  
te  
s
```

```
ty  
pe  
de  
f  
st  
ru  
ct  
{  
BS  
2D  
es  
Fi  
re  
Ap  
pL  
ev  
el  
Ke  
y  
de  
sf  
ir  
eA  
pp  
Ke  
y;  
//  
/<  
52  
by  
te  
s  
ui
```

```
nt  
8_  
t  
re  
se  
rv  
ed  
[1  
6]  
;  
}  
BS  
2D  
es  
Fi  
re  
Ca  
rd  
Co  
nf  
ig  
Ex  
;  
//  
/<  
68  
by  
te  
s
```

1.
app
Mas
ter
Key
App
lica
tion
ma
ster
key
of
Des
Fire

.

2.
file
Rea
dKe
y

The
key
use
d to
rea
d
the
file.

3.
file
Wri
teK
ey
The
key
use
d to
writ
e
the
file.

4.
file
Rea
dKe
yNu
mb
er
The
ind
ex
of
the
key
for
rea
din
g
the
file.

5.
file
Wri
teK
eyN
um
ber
The

ind
ex
of
the
key
for
writ
ing
the
file.

6.
res
erv
ed
Res
erv
ed
spa
ce.

7.
des
fire
App
Key
A
stru
ctur
e
con
tain
ing
Des
Fire
key
info
rma
tion

.

8.
res
erv
ed
Res
erv
ed
spa
ce.

**BS
2A
ut
hC
on
fig
Ex
t**

```
ty
pe
de
f
st
ru
ct
{
ui
nt
32
_t
ex
tA
ut
hS
ch
ed
ul
e[
BS
2_
MA
X_
NU
M_
OF
_E
XT
_A
UT
H_
MO
DE
];
ui
nt
8_
t
us
eG
```

```
lo  
ba  
lA  
PB  
;  
ui  
nt  
8_  
t  
gl  
ob  
al  
AP  
BF  
ai  
lA  
ct  
io  
n;  
ui  
nt  
8_  
t  
us  
eG  
ro  
up  
Ma  
tc  
hi  
ng  
;  
ui  
nt  
8_  
t  
re  
se  
rv  
ed  
;  
ui  
nt  
8_  
t  
re  
se  
rv  
ed  
2[
```

```
4]
;
ui
nt
8_
t
us
eP
ri
va
te
Au
th
;
ui
nt
8_
t
fa
ce
De
te
ct
io
nL
ev
el
;
ui
nt
8_
t
us
eS
er
ve
rM
at
ch
in
g;
ui
nt
8_
t
us
eF
ul
lA
cc
```

```
es
s;

ui
nt
8_
t
ma
tc
hT
im
eo
ut
;
ui
nt
8_
t
au
th
Ti
me
ou
t;
ui
nt
8_
t
nu
m0
pe
ra
to
rs
;
ui
nt
8_
t
re
se
rv
ed
3[
1]
;

st
ru
ct
{
```


```
ch
ar
us
er
ID
[B
S2
_U
SE
R_
ID
_S
IZ
E]
;
ui
nt
8_
t
le
ve
l;
ui
nt
8_
t
re
se
rv
ed
[3
];
}
op
er
at
or
s[
BS
2_
MA
X_
OP
ER
AT
OR
S]
;
ui
nt
```

```
8_
t
re
se
rv
ed
4[
25
6]
;
}
BS
2A
ut
hC
on
fi
gE
xt
;
```

1.
ext
Aut
hSc
he
dul
e
Sch
edu
le
val
ues
to
ope
rate
wh
en
eac
h
aut
hen
tica
tion
mo
de
is
acti
vat
ed.
It

has
the
foll
owi
ng
me
ani
ngs
for
eac
h
val
ue.
If
the
val
ue
in
the
arr
ay is
gre
ater
tha
n 0,
the
aut
hen
tica
tion
mo
de
is
acti
vat
ed.
In
the
exp
lan
atio
ns
bel
ow,
bio
met
ric
info
rma
tion
me

ans
fing
erp
rint
s or
fac
es
dep
end
ing
on
the
dev
ice.



2.
use
Glo
bal
APB
This
flag
det
erm
ines
wh
eth
er
to
ena
ble
Glo
bal
APB
zon
e.

3.
glo
bal
APB
Fail
Acti
on
This
is a
basi
c

acti
on
to
be
perf
orm
ed
wh
en
the
dev
ice
can
not
que
ry
the
ser
ver
for
Glo
bal
APB
viol
atio
n.

Value	Description
0	Block APB
1	Allow APB
2	Force APB

4.
use
Gro
up
Mat
chi
ng
Ena
bles
faci
al
gro
up
mat
chi
ng.

5.
res
erv
ed
Res

erv
ed
spa
ce.

6.
res
erv
ed2
Res
erv
ed
spa
ce.

7.
use
Priv
ate
Aut
h
Ena
ble
priv
ate
aut
hen
tifica
tion
mo
de.

8.
fac
eDe
tect
ion
Lev
el
This
is
the
fac
e
det
ecti
on
lev
el
val
ue

when authenticating the user in BioStation A2, and if a face is detected at a level lower than the specified level, it is treated as an authentication failure. When enabled, the ca

mer
a
vie
w
acc
ordi
ng
to
Nor
mal
/Stri
ct is
dis
pla
yed
,

' and
acc
ess
is
den
ied
if
the
ima
ge
log
is
not
rec
ogn
ized
as
a
fac
e
wh
en
suc
ces
sful
aut
hen
tica
tion
. The
def
ault
is
0.

Index	Description
0	Do not check mode
1	Normal mode
2	Check mode

It is available only in Bio Station A2, not available in FaceStation 2 or FaceLite.

9.
use
Server
Matrix
changing
Enable
server
matrix
changing
for finding
ERP
printing
matrix
changing

or
faci
al
mat
chi
ng.

10.
use
Full
Acc
ess
This
par
am
eter
is
not
in
use
.

11.
mat
chT
ime
out
The
ma
xim
um
res
pon
se
tim
e in
fing
erp
rint
or
faci
al
mat
chi
ng
and
the
unit
is
sec
ond

s(se
c).

12.
aut
hTi
me
out
The
ma
xim
um
res
pon
se
tim
e in
use
r
aut
hen
tica
tion
and
the
unit
is
sec
ond
s(se
c).

13.
nu
mO
per
ator
s
The
nu
mb
er
of
ope
ratio
rs.

14.
res
erv
ed3

Res
erv
ed

15.
use
rID
Use
r ID

16.
lev
el
It
spe
cifi
es
the
corr
esp
ond
ing
lev
el
of
the
use
r
wh
en
the
use
r is
aut
hen
tica
ted.

Value	Description
0	User level
1	Normal
2	Administrator
3	Super Administrator

CA
UT
IO
N
Yo
u
mu
st
spe
cify

the
nu
mb
er
of
op
era
tor
s
to
be
ad
de
d
in
the
fiel
d
***nu
m
Op
er
at
ors***
wh
en
ad
din
g
op
era
tor
s.

17.
res
erv
ed
Res
erv
ed
18.
res
erv
ed4
Res
erv
ed

**BS
2F
ac
eC
on
fig
Ex
t**

```
ty
pe
de
f
st
ru
ct
{
ui
nt
8_
t
th
er
ma
lC
he
ck
Mo
de
;
ui
nt
8_
t
ma
sk
Ch
ec
kM
od
e;
ui
nt
8_
t
re
se
rv
ed
[2]
```

```
];
uint8_t thermaLFormat;
uint8_t reserved2;

uint16_t thermalResHoldLow;
uint16_t thermalResHoldHigh;
```

```
;  
ui  
nt  
8_  
t  
ma  
sk  
De  
te  
ct  
io  
nL  
ev  
el  
;  
ui  
nt  
8_  
t  
au  
di  
tT  
em  
pe  
ra  
tu  
re  
;  
  
ui  
nt  
8_  
t  
us  
eR  
ej  
ec  
tS  
ou  
nd  
;  
ui  
nt  
8_  
t  
us  
e0  
ve  
rl  
ap  
Th
```

```
er  
ma  
l;  
ui  
nt  
8_  
t  
us  
eD  
yn  
am  
ic  
R0  
I;  
ui  
nt  
8_  
t  
fa  
ce  
Ch  
ec  
k0  
rd  
er  
;  
}  
BS  
2F  
ac  
eC  
on  
fi  
gE  
xt  
;
```

1.
*ther
mal
Che
ckM
ode
Set
s
the
ther
mal
che
ck
mo*

de.
Wh
en
set
to
HA
RD,
acc
ess
is
den
ied
if
exc
eed
ing
the
ther
mal
Thr
esh
old.
Wh
en
set
to
SOF
T,
acc
ess
is
not
affe
cte
d
eve
n if
exc
eed
ing
the
ther
mal
Thr
esh
old
but
lea
ves
a
rela

ted
log.
If
ther
mal
Che
ckM
ode
is
set
to
No
use
(0),
The
sett
ing
s of
ther
mal
For
mat
,
ther
mal
Thr
esh
old,
aud
itTe
mp
erat
ure,
and
use
Ove
rlap
The
rma
l
are
ign
ore
d.
And
the
reje
ct
sou
nd
due

to
ther
mal
che
ck
by
use
Rej
ect
Sou
nd,
the
tem
per
atur
e
che
ck
by
fac
eCh
eck
Ord
er
is
ign
ore
d.



2.
ma
skC
hec
kMo
de
Fac
eSt
ati
on
F2
Set
s
the
Mas
k
Che
ck
Mo
de.

Fac
eSt
ati
on
2
This
sett
ing
is
ign
ore
d.
Wh
en
set
to
HA
RD,
acc
ess
is
den
ied
if
not
det
ecti
ng
any
ma
sk
on
the
fac
e
bas
ed
on
ma
skD
ete
ctio
nLe
vel.
Wh
en
set
to
SOF
T,
acc

ess
is
not
affe
cte
d
eve
n if
not
det
ecti
ng
any
ma
sk
on
the
fac
e
bas
ed
on
ma
skD
ete
ctio
nLe
vel
but
lea
ves
a
rela
ted
log.
If
ma
skC
hec
kMo
de
is
set
to
No
use
(0),
The
sett
ing
of

ma
skD
ete
ctio
nLe
vel
is
ign
ore
d.
And
the
reje
ct
sou
nd
due
to
ma
sk
det
ecti
on
che
ck
by
use
Rej
ect
Sou
nd,
the
ma
sk
det
ecti
on
che
ck
by
fac
eCh
eck
Ord
er
is
ign
ore
d.



3.
res
erv
ed
Res
erv
ed

4.
ther
mal
For
mat
Rep
res
ent
s
the
tem
per
atur
e
unit
. You
ma
y
cho
ose
the
unit
in
Fah
ren
heit
or
Cel
sius



5.
res
erv
ed2
Res
erv
ed

6.
ther
mal

Thr
esh
old
Low
Sup
por
ted
ver
sio
n :
Fac
eSt
ati
on
F2
V1.
0.2

,
Fac
eSt
ati
on
2
V1.
5.0
This
is
the
ran
ge
val
ue
for
det
erm
inin
g
hig
h
tem
per
atur
e
and
mu
st
be
ent
ere
d
as

a
val
ue
mul
tipli
ed
by
100
of
the
tem
per
atur
e to
be
set.
Als
o,
you
can
onl
y
ent
er
in
deg
ree
s
Cel
sius

.

This
val
ue
is
the
basi
s
for
the
den
ial
of
aut
hen
tifica
tion

,

and
the
sett

ing
ran
ge
is
bet
wee
n
100
(1°)
and
450
0
(45
°).
The
def
ault
val
ue
is
320
0
(32
°),
and
if a
val
ue
larg
er
or
sm
alle
r
tha
n
the
sett
ing
ran
ge
is
ent
ere
d,
the
def
ault
val
ue
a

set
to
320
0
(32
°).
And
you
mu
st
set
a
val
ue
less
tha
n
ther
mal
Thr
esh
old
Hig
h.

7.
*ther
mal
Thr
esh
old
Hig
h*
This
is
the
ran
ge
val
ue
for
det
erm
inin
g
hig
h
tem
per
atur
e

and
mu
st
be
ent
ere
d
as
a
val
ue
mul
tipli
ed
by
100
of
the
tem
per
atur
e to
be
set.
Als
o,
you
can
onl
y
ent
er
in
deg
ree
s
Cel
sius
. This
val
ue
is
the
basi
s
for
the
den
ial
of

aut
hen
tica
tion
,

and
the
sett
ing
ran
ge
is
bet
wee
n
100
(1°)
and
450
0
(45
°).
The
def
ault
val
ue
is
380
0
(38
°),
and
if a
val
ue
larg
er
or
sm
alle
r
tha
n
the
sett
ing
ran
ge
is
ent

ere
d,
the
def
ault
val
ue
a
set
to
380
0
(38
º).
And
you
mu
st
set
a
val
ue
gre
ater
tha
n
ther
mal
Thr
esh
old
Low

.

8.
ma
skD
ete
ctio
nLe
vel
Fac
eSt
ati
on
F2
Set
s
the
ma
sk

det
ecti
on
lev
el.
The
det
ecti
ng
lev
el is
bas
ed
on
inte
rnal
sett
ing
val
ue.
Fac
eSt
ati
on
2
This
sett
ing
is
ign
ore
d.



9.
*aud
itTe
mp
erat
ure
Dec
ides
wh
eth
er
the
me
asu
red
tem*

per
atur
e is
rec
ord
ed
in
the
log
or
not.

10.
use
Rej
ect
Sou
nd
Dec
ides
wh
eth
er it
sou
nds
wh
en
reje
ctin
g a
use
r
due
to
ther
mal
Thr
esh
old
or
ma
skD
ete
ctio
nLe
vel.

11.
use
Ove
rlap

The
rma
/
Dis
pla
ys a
ther
mal
ima
ge
ove
rlai
d
on
the
scr
een

.

12.
use
Dyn
ami
cRO
/
Wh
en
set
to
true

,

wh
en
me
asu
ring
tem
per
atur
e,
the
use
r's
fore
hea
d is
fou
nd
and
me
asu

red,
not
a
fixe
d
are
a.

13.
*fac
eCh
eck
Ord
er
It
defi
nes
the
seq
uen
ce
of
ther
mal
che
ck
and
ma
sk
det
ecti
on
and
aut
hen
tica
tion*

.
Bec
aus
e
the
use
r
sho
uld
tou
ch
the
dev
ice

in
the
cas
e of
ID
co
mbi
nati
on
aut
hen
tica
tion
or
PIN
co
mbi
nati
on
aut
hen
tica
tion
,

it is
imp
orta
nt
to
dec
ide
wh
eth
er
the
dev
ice
aut
hen
tica
tes
bef
ore
all
che
ck
mo
des
or
afte
rwa

rd
esp
ecia
lly
in a
hig
h-
risk
env
iron
me
nt.

=====

Aut
he
nti
cati
on
bef
ore
Te
mp
era
tur
e
che
ck
or
Ma
sk
det
ect
ion
che
ck

<input type="checkbox"/>	Check after	Initial
<input type="checkbox"/>	Check before	Initial
<input type="checkbox"/>	Check after	Initial
<input type="checkbox"/>	Check before	Initial
<input type="checkbox"/>	Check after	Initial

BS
2T
he
rm
al
Ca
m
er
aC

onfig

```
type  
pe  
de  
f  
st  
ru  
ct  
{  
ui  
nt  
8_  
t  
di  
st  
an  
ce  
;  
ui  
nt  
8_  
t  
em  
is  
si  
on  
Ra  
te  
;  
  
st  
ru  
ct  
{  
ui  
nt  
16  
_t  
x;  
ui  
nt  
16  
_t  
y;  
ui  
nt  
16  
_t  
wi
```

```
dt
h;
ui
nt
16
_t
he
ig
ht
;
}
ro
i;

ui
nt
8_
t
us
eB
od
yC
om
pe
ns
at
io
n;
in
t8
_t
co
mp
en
sa
ti
on
Te
mp
er
at
ur
e;
}
BS
2T
he
rm
al
Ca
me
```

ra
Co
nf
ig
;

1.
distanc e
The distance measured by the thermal imager is approximately 100.

2.
emissionRate
The emissivity of the subject

ject
refl
ecti
ng
hea
t.

It is
rec
om
me
nde
d to
ent
er
wit
hin
the
[95/
97/
98]

ran
ge.

If
the
sub
ject
is a
hu
ma
n,
98
is
rec
om
me
nde
d.

3.
roi
ROI
(Re
gio
n of
inte
rest
)
refe
rs
to
the

regi
on
of
inte
rest
. It
can
be
spe
cifi
ed
thro
ugh
coo
rdin
ate
s
(x,
y)
and
ran
ge
(wi
dth,
hei
ght)
val
ues
wh
en
me
asu
ring
tem
per
atur
e
on
the
fac
e.

4.
*use
Bod
yCo
mp
ens
atio
n*

It
dec
ides
wh
eth
er
to
use
the
co
mp
ens
ate
the
bod
y
tem
per
atur
e.

5.
*co
mp
ens
atio
nTe
mp
erat
ure*
The
re
ma
y
be
a
slig
ht
diff
ere
nce
bet
wee
n
the
act
ual
bod
y
tem
per

atur
e
and
the
bod
y
tem
per
atur
e
me
asu
rem
ent
usi
ng
the
ca
mer
a,
and
you
can
corr
ect
the
diff
ere
nce
by
sett
ing
a
val
ue
her
e.
It
mu
st
be
as
the
val
ue
mul
tipli
ed
by
10
of

the
tem
per
atur
e to
be
set.
The
val
ue
is
ava
ilab
le
-50
~
+5
0

BS 2B ar co de Co nfi g

```
ty  
pe  
de  
f  
st  
ru  
ct  
{  
ui  
nt  
8_  
t  
us  
eB  
ar  
co  
de  
;  
ui  
nt  
8_
```

```
t  
sc  
an  
Ti  
me  
ou  
t;  
ui  
nt  
8_  
t  
by  
pa  
ss  
Da  
ta  
;  
ui  
nt  
8_  
t  
tr  
ea  
tA  
sC  
SN  
;  
  
ui  
nt  
8_  
t  
re  
se  
rv  
ed  
[1  
2]  
;  
}  
BS  
2B  
ar  
co  
de  
Co  
nf  
ig  
;
```

1.

use
Bar
cod
e
Bar
cod
e
usa
ge
flag

.

2.
sca
nTi
me
out
Set
the
Bar
cod
e
sca
n
tim
e.

The
unit
is in
sec
ond
s.

The
def
ault
is 4
sec
ond
s,
and
can
be
ent
ere
d
wit
hin
a
ran
ge
of 4

to
10
sec
ond
s.

3.
byp
ass
Dat
a
[+2
.8.2
]
Use
d to
sen
d
rea
d
bar
cod
e
info
rma
tion
to
the
ser
ver,
not
pro
ces
sed
by
the
dev
ice.
If
the
bar
cod
e
val
ue
is
stor
ed
in
the
use

r
info
rma
tion
stru
ctur
e
for
use
r
aut
hen
tica
tion

,
The
re
is a
size
con
stra
int
of
32
byt
es
(BS
2CS
NCa
rd
dat
a),
Call
the
BS2
_Se
tBa
rco
deS
can
List
ene
r,
use
this
opti
on
to
sen
d
bar

cod
es
up
to
512
byt
es
of
size
to
the
ser
ver.

4.
tre
tAs
CS
N
[+2
.8.2
]
Indi
cat
es
wh
eth
er
the
Bar
cod
e
sho
uld
be
tre
ted
the
sa
me
as
a
reg
ular
CS
N
car
d.
It is
app
lied

fro
m
XS2
-QR
1.1.
3
and
in
the
cas
e of
fals
e, it
is
trea
ted
the
sa
me
as
bef
ore.
This
allo
ws
you
to
free
ly
spe
cify
cha
ract
er
sets
that
can
be
trea
ted
as
bar
cod
es
fro
m
ASC
II
cod
es
32

to
126
. (Se
e
des
crip
tion
in
[BS2](#)
[_Wr](#)
[ite](#)
[QR](#)
[Cod](#)
[e](#))
If
set
to
true
,the
bar
cod
e is
tre
ated
like
a
nu
mb
er
just
like
the
exis
ting
CS
N.
The
refo
re,
if
you
wa
nt
to
set
the
bar
cod
e

car
d
dat
a
wit
h
spe
cial
cha
ract
ers
and
Eng
lish
cha
ract
ers.
In
this
cas
e,
onl
y
the
car
d
typ
e
ma
y
be
diff
ere
nt,
and
the
CS
N
car
d
and
bar
cod
e
dat
a
ma
y
be
use
d in

the
sa
me
val
ue.

5.
res
erv
ed
Res
erv
ed
spa
ce.

BS
2I
np
ut
Co
nfi
gE
x

```
ty
pe
de
f
st
ru
ct
{
ui
nt
8_
t
nu
mI
np
ut
s;
ui
nt
8_
t
nu
mS
up
er
```

```
vi  
se  
d;  
ui  
nt  
8_  
t  
re  
se  
rv  
ed  
[1  
8]  
;  
  
st  
ru  
ct  
{  
ui  
nt  
8_  
t  
po  
rt  
In  
de  
x;  
ui  
nt  
8_  
t  
sw  
it  
ch  
Ty  
pe  
;  
ui  
nt  
16  
_t  
du  
ra  
ti  
on  
;  
  
ui  
nt  
8_
```

```
t  
re  
se  
rv  
ed  
;  
ui  
nt  
8_  
t  
su  
pe  
rv  
is  
ed  
Re  
si  
st  
or  
;  
ui  
nt  
8_  
t  
re  
se  
rv  
ed  
1[  
16  
];  
  
ui  
nt  
8_  
t  
re  
se  
rv  
ed  
2[  
26  
];  
}  
in  
pu  
ts  
[B  
S2  
_M  
AX
```

```
_I  
NP  
UT  
_N  
UM  
_E  
X]  
;  
  
ui  
nt  
8_  
t  
re  
se  
rv  
ed  
2[  
20  
0]  
;  
}  
BS  
2I  
np  
ut  
Co  
nf  
ig  
Ex  
;
```

1.
nu
mln
put
s
Nu
mb
er
of
Inp
ut
port

.

2.
nu
mS
upe
rvis

ed
Nu
mb
er
of
sup
ervi
sed
inp
ut
port
.

3.
res
erv
ed
Res
erv
ed
Spa
ce.

4.
port
Ind
ex
Inp
ut
Port
Nu
mb
er.

5.
swit
chT
ype
Inp
ut
Sig
nal
Typ
e.

Value	Description
0	Normal
1	Normal

6.
dur
atio
n

Inp
ut
Sig
nal
Dur
atio
n
Tim
e
Me
asu
rem
ent
is
mill
isec
ond
s(m
s).

7.
*res
erv
ed*
Res
erv
ed
Spa
ce.

8.
*sup
ervi
sed*
Res
*isto
r*
You
can
set
Sup
ervi
sed
inp
ut
resi
sta
nce
val
ue
typ

e or
uns
upe
rvis
e it.



9.
res
erv
ed1
Res
erv
ed
Spa
ce.

10.
res
erv
ed2
Res
erv
ed
Spa
ce.

11.
res
erv
ed2
Res
erv
ed
Spa
ce.

BS
2R
el
ay
Ac
tio
nC
on
fig

ty

```
pe
de
f
st
ru
ct
{
ui
nt
32
_t
de
vi
ce
ID
;
//<
4
by
te
s
ui
nt
8_
t
re
se
rv
ed
[1
6]
;
//<
16
by
te
s

st
ru
ct
{
ui
nt
8_
t
po
rt
;
```

```
//  
/<  
1  
by  
te  
(r  
el  
ay  
po  
rt  
)  
ui  
nt  
8_  
t  
re  
se  
rv  
ed  
0;  
//  
/<  
1  
by  
te  
ui  
nt  
8_  
t  
di  
sc  
on  
nE  
na  
bl  
ed  
;  
//  
/<  
1  
by  
te  
(R  
S4  
85  
di  
sc  
on  
ne  
ct  
io
```

```
n)
ui
nt
8_
t
re
se
rv
ed
[9
];
//<
9
by
te
s

st
ru
ct
{
ui
nt
8_
t
po
rt
;
//<
1
by
te
(i
np
ut
po
rt
)
ui
nt
8_
t
ty
pe
;
//<
1
by
```

```
te  
(l  
in  
ka  
ge  
/l  
at  
ch  
in  
g/  
re  
le  
as  
e)  
ui  
nt  
8_  
t  
ma  
sk  
;  
//  
/<  
1  
by  
te  
(a  
la  
rm  
/f  
au  
lt  
)  
ui  
nt  
8_  
t  
re  
se  
rv  
ed  
[9  
];  
//  
/<  
9  
by  
te  
s  
}  
in
```

```
put[BS2_MA_X_REALA_Y_AC_TI_ON_I_NP_UT];//<192bytes}re8laty[BS2_MA_X_REALA_Y_AC_TI_ON];//<816bytesui8nt8t8re
```

```
se  
rv  
ed  
2[  
15  
2]  
;  
//  
/<  
15  
2  
by  
te  
s  
}  
BS  
2R  
el  
ay  
Ac  
ti  
on  
Co  
nf  
ig  
;
```

1.
dev
iceI
D
Dev
ice
Ide
ntifi
er

2.
res
erv
ed
Res
erv
ed
Spa
ce.

3.
rela
y
Rel

ay
Sett
ing
Info
rma
tion

4.
port
Rel
ay
port
Nu
mb
er.

5.
res
erv
ed0
Res
erv
ed
Spa
ce.

6.
disc
onn
Ena
ble
d
If
set
to
true
, a
sig
nal
is
ma
de
wh
en
RS4
85
is
disc
onn
ect
ed.

7.
res
erv
ed
Res
erv
ed
Spa
ce.

8.
inp
ut
Defi
nes
to
whi
ch
inp
ut
port
s
the
rela
y
port
s
will
tak
e
acti
on.

9.
port
Inp
ut
port
Ide
ntifi
er.

10.
typ
e
Defi
nes
in
whi
ch
inp

ut
typ
e
the
inp
ut
will
tak
e
acti
on.
If
set
to
Link
age
,

,
sig
nal
can
be
ma
de
wh
en
alar
m
is
set
to
ma
sk.



11.
ma
sk
Set
ma
sk
to
Inp
ut
Sig
nal
Info
.



12.
res
erv
ed
Res
erv
ed
Spa
ce.

13.
res
erv
ed2
Res
erv
ed
Spa
ce.

BS 2V oi pC on fig Ex t

```
ty  
pe  
de  
f  
st  
ru  
ct  
{  
BS  
2_  
US  
ER  
_I  
D  
ph  
on  
eN  
um  
be  
r;
```

```
char de sc ri pt io n[ 48 * 3 ] ;  
uint8_t re se rv ed [ 3 2 ] ; }  
BS2E xt en si on Nu mb er ;  
type de f st ru ct { BS2_B00L en ab le
```

```
d;  
BS  
2_  
B0  
0L  
us  
e0  
ut  
bo  
un  
dP  
ro  
xy  
;  
ui  
nt  
16  
_t  
re  
gi  
st  
ra  
ti  
on  
Du  
ra  
ti  
on  
;  
  
BS  
2_  
UR  
L  
ad  
dr  
es  
s;  
BS  
2_  
PO  
RT  
po  
rt  
;  
  
st  
ru  
ct  
{  
ui
```

```
nt  
8_  
t  
sp  
ea  
ke  
r;  
//  
0  
~  
10  
0  
ui  
nt  
8_  
t  
mi  
c;  
//  
0  
~  
10  
0  
}  
vo  
lu  
me  
;  
//  
/<  
2  
by  
te  
s  
  
BS  
2_  
US  
ER  
_I  
D  
id  
;  
BS  
2_  
US  
ER  
_I  
D  
pa  
ss
```

```
wo
rd
;
BS
2_
US
ER
_I
D
au
th
or
iz
at
io
nC
od
e;

st
ru
ct
{
BS
2_
UR
L
ad
dr
es
s;
BS
2_
PO
RT
po
rt
;
ui
nt
8_
t
re
se
rv
ed
[2
];
}
ou
tb
```

```
ound
Pr
ox
y;
ui
nt
8_
t
ex
it
Bu
tt
on
;
// /
*, ,
#, ,
0~
9
ui
nt
8_
t
re
se
rv
ed
1;
ui
nt
8_
t
nu
mP
ho
ne
Bo
ok
;
BS
2_
B0
0L
sh
ow
Ex
te
ns
```

```
io  
nN  
um  
be  
r;  
  
BS  
2E  
xt  
en  
si  
on  
Nu  
mb  
er  
ph  
on  
eb  
oo  
k[  
12  
8]  
;  
  
ui  
nt  
8_  
t  
re  
se  
rv  
ed  
2[  
32  
];  
//  
/<  
32  
by  
te  
s  
(r  
es  
er  
ve  
d)  
}  
BS  
2V  
oi  
pC
```

on
fi
gE
xt
;

1.
photoNumber
This
is
the
ext
ensi
on.

2.
description
Dis
pla
y
info
rma
tion
.

3.
reserved
Res
erv
ed
spa
ce.

4.
enabled
Set
s
wh
eth
er
the
Vol

P
ext
ensi
on
feat
ure
is
ena
ble
d.

5.
use
Out
bou
ndP
rox
y
Set
s
wh
eth
er
the
Out
bou
nd
Pro
xy
Ser
ver
is
con
figu
red.

6.
regi
stra
tion
Dur
atio
n
The
cycl
e of
upd
atin
g
the
rele

van
t
info
rma
tion
to
the
SIP
ser
ver.
Set
in
sec
ond
s
and
mu
st
be
bet
wee
n
60
and
600
.

7.
add
res
s
Ent
er
the
IP
add
res
s of
the
SIP
ser
ver
(us
uall
y
Bio
Star
).

8.
port

Enter
the
SIP
ser
ver
port

.

The
def
ault
port
is
506
0.

9.
*spe
ake
r*
Enter
the
*spe
ake
r*
vol
um
e
info
rma
tion
for
the
inte
rco
m
in
the
ran
ge
0 to
100

.

The
def
ault
val
ue
is
50.

10.
mic
Enter
the
mic
rop
hon
e
vol
um
e
info
rma
tion
for
the
inte
rco
m
in
the
ran
ge
0 to
100

.

The
def
ault
val
ue
is
50.

11.
id
Enter
the
ID
to
con
nec
t to
the
SIP
ser
ver.
12.
pas

swo
rd
Spe
cifi
es
the
pas
swo
rd
to
con
nec
t to
the
SIP
ser
ver.

13.
aut
hori
zati
onC
ode
The
aut
hen
tica
tion
cod
e
val
ue
req
uire
d to
con
nec
t to
the
SIP
ser
ver.

14.
out
bou
ndP
rox
y
Ent

er
Out
bou
nd
pro
xy
ser
ver
info
rma
tion
.

15.
add
res
s
Ent
er
the
IP
add
res
s of
the
Out
bou
nd
Pro
xy
Ser
ver.

16.
port
Ent
er
the
Out
bou
nd
Pro
xy
Ser
ver
port
.

17.
res
erv

ed
Res
erv
ed
spa
ce.

18.
exit
But
ton
But
ton
sy
mb
ol
to
be
use
d
as
a
che
ck-
out
butt
on.



19.
res
erv
ed1
Res
erv
ed
spa
ce.

20.
nu
mP
hon
eBo
ok
Nu
mb
er
of
pho

ne
boo
ks.

21.
sho
wEx
ten
sion
Nu
mb
er
Det
erm
ines
wh
eth
er
to
sho
w
the
pho
ne
boo
k.

22.
pho
neb
ook
You
can
spe
cify
up
to
128
ext
ensi
ons
in
you
r
pho
ne
boo
k.

23.
res

erv
ed2
Res
erv
ed
spa
ce.

BS 2R ts pC on fig

```
ty  
pe  
de  
f  
st  
ru  
ct  
{  
BS  
2_  
US  
ER  
_I  
D  
id  
;  
BS  
2_  
US  
ER  
_I  
D  
pa  
ss  
wo  
rd  
;  
BS  
2_  
UR  
L  
ad  
dr
```

```
es
s;

BS
2_
PO
RT
po
rt
;
BS
2_
B0
0L
en
ab
le
d;
ui
nt
8_
t
re
se
rv
ed
;

ui
nt
8_
t
re
se
rv
ed
2[
32
];
}
BS
2R
ts
pC
on
fi
gi;
```

1.
id
Acc

oun
t
info
rma
tion
wh
en
con
nec
ting
to
the
RTS
P
ser
ver.

2.
pas
swo
rd
Pas
swo
rd
wh
en
con
nec
ting
to
the
RTS
P
ser
ver.

3.
add
res
s
Ent
er
the
add
res
s of
the
RTS
P
ser
ver.

4.
port
Enter
the
RTS
P
ser
ver
con
nec
tion
port

.
The
def
ault
port
is
554

.

5.
enable
ble
d
Set
s
wh
eth
er
an
RTS
P
con
nec
tion
is
enable
ble
d.

6.
res
erv
ed
Res
erv
ed
spa
ce.

7.
res
erv
ed2
Res
erv
ed
spa
ce.

1)

Maximum
Transmission Unit

2)

Most Significant Bit

3)

Least Significant Bit

