

<b>BS2_SetDisplayConfig</b>	.....	1
	.....	1
	.....	1
	.....	1

Configuration API > [BS2\\_SetDisplayConfig](#)

## BS2\_SetDisplayConfig

UI

```
#include "BS_API.h"

int BS2_SetDisplayConfig(void* context, uint32_t deviceId, BS2DisplayConfig*
config);
```

[BS2DisplayConfig](#)

- [In] *context* : Context
- [In] *deviceId* :
- [In] *config* : UI

BS\_SDK\_SUCCESS , 가

From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar 2 Device SDK**

Permanent link:

[http://kb.supremainc.com/bs2sdk/doku.php?id=ko:bs2\\_setdisplayconfig](http://kb.supremainc.com/bs2sdk/doku.php?id=ko:bs2_setdisplayconfig)

Last update: **2016/07/12 09:08**