Table of Contents

User Management API > BS2_GetSupportedUserMask

BS2_GetSupportedUserMask

[+ 2.5.0] Gets user settings supported by the device.
This information can be different by device type.

Declaration

```
#include "BS_API.h"

int BS2_GetSupportedUserMask(void* context, uint32_t deviceId,
BS2_USER_MASK* userMask);
```

Parameter

- [In] *context* : Context
- [In] *deviceId* : Device ID
- [Out] *userMask* : User mask

Value	Description
0x0004	User name
0x0008	Image
0x0010	PIN
0x0020	Card
0x0040	Fingerprint
0x0080	Face
0x0200	Jobcode
0x0400	Phrase
0xFFFF	All information

Return Value

If successfully done, BS_SDK_SUCCESS will be returned. If there is an error, the corresponding error code will be returned.

From:
http://kb.supremainc.com/bs2sdk./ - **BioStar Device SDK**

Permanent link:
http://kb.supremainc.com/bs2sdk./doku.php?id=en:bs2_getsupportedusermask&rev=1559529928

Last update: **2019/06/03 11:45**