

# Table of Contents

- BS2\_GetUserInfosExFromDir*** ..... 1
- Declaration ..... 1
- Parameter ..... 1
- Return Value ..... 1
- See Also ..... 1

# BS2\_GetUserInfosExFromDir

Gets the user information of the given user ID.

## Declaration

```
#include "BS_API.h"

int BS2_GetUserInfosExFromDir(void* context, const char* szDir, char* uids,
uint32_t uidCount, BS2UserBlobEx* userBlob);
```

[See BS2UserBlobEx Structure](#)

## Parameter

- [In] *context* : Context
- [In] *szDir* : Storage path in device
- [In] *uids* : User ID list trying to get
- [In] *uidCount* : Number of user ID
- [Out] *userBlob* : Pointer to store the user information

## Return Value

If successfully done, BS\_SDK\_SUCCESS will be returned.  
If there is an error, the corresponding error code will be returned.

## See Also

[BS2\\_GetUserListFromDir](#)  
[BS2\\_GetUserInfosFromDir](#)

From:  
<https://kb.supremainc.com/bs2sdk/> - **BioStar 2 Device SDK**

Permanent link:  
[https://kb.supremainc.com/bs2sdk./doku.php?id=en:bs2\\_getuserinfosexfromdir&rev=1504600615](https://kb.supremainc.com/bs2sdk./doku.php?id=en:bs2_getuserinfosexfromdir&rev=1504600615)

Last update: **2017/09/05 17:36**