

# Table of Contents

<b>BS2_GetUserInfosExFromDirWithKey</b> .....	1
Declaration .....	1
Parameters .....	1
Return value .....	1
Watch Together .....	1

[USB Exported Control API](#) > [BS2\\_GetUserInfosExFromDirWithKey](#)

---

## BS2\_GetUserInfosExFromDirWithKey

[+2.8.2] Gets the user information corresponding to the user identifier from the data extracted by USB.

### Declaration

```
#include "BS_API.h"

int BS2_GetUserInfosExFromDirWithKey(void* context, const char* szDir, char*
uids, uint32_t uidCount, BS2UserBlobEx* userBlob, const BS2EncryptKey* key);
```

[View of the structure BS2UserBlobEx](#)

### Parameters

- [In] *context* : Context
- [In] *szDir* : Data storage path
- [In] *uids* : List of user identifiers to be imported
- [In] *uidCount* : Number of user identifiers
- [Out] *userBlob* : Pointer to store user information
- [In] *key* : Encryption key and the key value specified by [BS2\\_SetDataEncryptKey](#)

### Return value

Returns `BS_SDK_SUCCESS` if performed successfully, or a corresponding error code if an error occurs.

### Watch Together

[BS2\\_GetUserDatabaseInfoFromDirWithKey](#)  
[BS2\\_GetUserListFromDirWithKey](#)  
[BS2\\_GetUserInfosFromDirWithKey](#)  
[BS2\\_GetUserDatasesFromDirWithKey](#)  
[BS2\\_GetUserDatasesExFromDirWithKey](#)  
[BS2\\_GetLogFromDirWithKey](#)  
[BS2\\_GetLogBlobFromDirWithKey](#)  
[BS2\\_GetFilteredLogFromDirWithKey](#)

From:

<https://kb.supremainc.com/bs2sdk/> - **BioStar 2 Device SDK**

Permanent link:

[https://kb.supremainc.com/bs2sdk./doku.php?id=en:bs2\\_getuserinfosexfromdirwithkey&rev=1650245648](https://kb.supremainc.com/bs2sdk./doku.php?id=en:bs2_getuserinfosexfromdirwithkey&rev=1650245648)

Last update: **2022/04/18 10:34**