

Table of Contents

BS2_SetDoor	1
Declaration	1
Parameter	1
Return Value	1
See Also	1

[Door Control API](#) > [BS2_SetDoor](#)

BS2_SetDoor

Configures a door. 2 devices connected through TCP/IP cannot be allocated to 1 logical door.

Declaration

```
#include "BS_API.h"

int BS2_SetDoor(void* context, uint32_t deviceId, BS2Door* doors, uint32_t
doorCount);
```

[See BS2Door Structure](#)

Parameter

- [In] *context* : Context
- [In] *deviceId* : Device ID
- [In] *doors* : List of the doors to be stored
- [In] *doorCount* : Number of doors

Return Value

If successfully done, BS_SDK_SUCCESS will be returned.
If there is an error, the corresponding error code will be returned.

See Also

[BS2_GetDoor](#)
[BS2_GetAllDoor](#)
[BS2_GetDoorStatus](#)
[BS2_GetAllDoorStatus](#)
[BS2_SetDoorAlarm](#)
[BS2_RemoveDoor](#)
[BS2_RemoveAllDoor](#)
[BS2_ReleaseDoor](#)
[BS2_LockDoor](#)
[BS2_UnlockDoor](#)

From:

<https://kb.supremainc.com/bs2sdk/> - **BioStar Device SDK**

Permanent link:

https://kb.supremainc.com/bs2sdk/doku.php?id=en:bs2_setdoor

Last update: **2017/01/16 18:13**