

Table of Contents

SDK API	1
----------------------	----------

SDK API

The followings are a set of APIs that initialize device management information and that are used for dynamic memory control and PIN code generation.

- [BS2_Version](#): Returns the SDK version.
- [BS2_AllocateContext](#): Allocates the device management Context.
- [BS2_ReleaseContext](#): Releases the device management Context.
- [BS2_Initialize](#): Initializes the device management Context.
- [BS2_ReleaseObject](#): Releases dynamic memory.
- [BS2_MakePinCode](#): Encrypts the PIN.
- [BS2_SetMaxThreadCount](#): Specifies the maximum thread count.
- [BS2_ComputeCRC16CCITT](#): Calculates the CRC-16 CCITT checksum.
- [BS2_GetCardModel](#): Retrieves the supported card models.
- [BS2_GetCredentialKeyInfo](#): Gets the encryption key for the device.
- [BS2_SetCredentialKeyInfo](#): Sets the encryption key for the device.
- [BS2_RemoveCredentialKeyInfo](#): Removes the encryption key for the device.

From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar 2 Device SDK**

Permanent link:

http://kb.supremainc.com/bs2sdk/doku.php?id=en:sdk_api&rev=1521525910

Last update: **2018/03/20 15:05**