

Table of Contents

USB Exported Control API 1

USB Exported Control API

This API allows to control/manage USB Exported.

- **BS2_AllocateUsbContext**: [Depredated] Allocates context which manages & controls USB device.
- **BS2_ReleaseUsbContext**: [Depredated] Releases context which manages & controls USB device.
- **BS2_GetUserDatabaseInfoFromDir**: Gets total user information(Number of user/card/fingerprint/face) from USB exported data.
- **BS2_GetUserListFromDir**: Gets the enrolled user ID list from USB exported data.
- **BS2_GetUserInfosFromDir**: Gets the user information of the given user ID from USB exported data.
- **BS2_GetUserDatasFromDir**: Gets the user information of the given user ID & usermask from USB exported data.
- **BS2_GetUserInfosExFromDir**: Gets the user information of the given user ID from USB exported data. (Including Job, phrase)
- **BS2_GetUserDatasExFromDir**: Gets the user information of the given user ID & usermask from USB exported data. (Including Job, phrase)
- **BS2_GetUserSmallInfosFromDir**: [+ 2.6.3] Gets the user information of the given user ID from USB exported data.
- **BS2_GetUserSmallDatasFromDir**: [+ 2.6.3] Gets the user information of the given user ID & usermask from USB exported data.
- **BS2_GetUserSmallInfosExFromDir**: [+ 2.6.3] Gets the user information of the given user ID from USB exported data. (Including Job, phrase)
- **BS2_GetUserSmallDatasExFromDir**: [+ 2.6.3] Gets the user information of the given user ID & usermask from USB exported data. (Including Job, phrase)
- **BS2_GetLogFromDir**: Gets certain amount of logs from USB exported data.
- **BS2_GetLogBlobFromDir**: Gets certain amount of logs based on the event mask from USB exported data.
- **BS2_GetFilteredLogFromDir**: Gets filtered logs from USB exported data.
- **BS2_GetLogSmallBlobFromDir**: [+ 2.6.4] Gets certain amount of logs based on the event mask from USB exported data in an efficient way.
- **BS2_GetLogSmallBlobExFromDir**: [+ 2.7.1] Gets certain amount of logs including temperature information based on the event mask from USB exported data in an efficient way.
- **BS2_GetUserInfosFaceExFromDir**: [+2.7.1] Gets the user information of the given user ID from USB exported data.
- **BS2_GetUserDatasFaceExFromDir**: [+2.7.1] Gets the user information of the given user ID & usermask from USB exported data.

[+2.8.2] USB Exported, | °ü, @Çİ±â ÀŞÇÑ APIÀÔ'Í'Û.

»çzèÀÚ °ü-Ä ÄÖzä 1í°° Äæ°, 'Ä ÄâÄi ³»zi¼ »çÄÛzi ÄæÄÇµÈ Ä° °âÄ, 'Í ¾ÄËÈÈ µÇ¾Ä ÄúÄâµË'Í'Û.

,,ÄÏ **BS2_SetDataEncryptKey** ÇÖ¼äö, | ÄìèçÏì© ÄâÄiÄÇ »çzèÀÚ Äæ°, ¾ÄËÈÈ Ä° , | °-°æÇÑ ÄùÄì ÄÖ'Û, é, USB°ü-Ä API, | ÄìèçÏì±â ÀŞÇØ ÇØ'ç Ä° °âÄ» Äü'þÇØ ÄÖ¾Ä¾¾Ç ÖÖ'Í'Û.

- **BS2_GetUserDatabaseInfoFromDirWithKey**: [+2.8.2] Gets total user information(Number of user/card/fingerprint/face) from USB exported data.
- **BS2_GetUserListFromDirWithKey**: [+2.8.2] Gets the enrolled user ID list from USB exported data.
- **BS2_GetUserInfosFromDirWithKey**: [+2.8.2] Gets the user information of the given user ID from

USB exported data.

- [BS2_GetUserDatasFromDirWithKey](#): [+2.8.2] Gets the user information of the given user ID & usermask from USB exported data.
- [BS2_GetUserInfosExFromDirWithKey](#): [+2.8.2] Gets the user information of the given user ID from USB exported data. (Including Job, phrase)
- [BS2_GetUserDatasExFromDirWithKey](#): [+2.8.2] Gets the user information of the given user ID & usermask from USB exported data. (Including Job, phrase)
- [BS2_GetUserSmallInfosFromDirWithKey](#): [+2.8.2] Gets the user information of the given user ID from USB exported data.
- [BS2_GetUserSmallDatasFromDirWithKey](#): [+2.8.2] Gets the user information of the given user ID & usermask from USB exported data.
- [BS2_GetUserSmallInfosExFromDirWithKey](#): [+2.8.2] Gets the user information of the given user ID from USB exported data. (Including Job, phrase)
- [BS2_GetUserSmallDatasExFromDirWithKey](#): [+2.8.2] Gets the user information of the given user ID & usermask from USB exported data. (Including Job, phrase)
- [BS2_GetLogFromDirWithKey](#): [+2.8.2] Gets certain amount of logs from USB exported data.
- [BS2_GetLogBlobFromDirWithKey](#): [+2.8.2] Gets certain amount of logs based on the event mask from USB exported data.
- [BS2_GetFilteredLogFromDirWithKey](#): [+2.8.2] Gets filtered logs from USB exported data.
- [BS2_GetLogSmallBlobFromDirWithKey](#): [+2.8.2] Gets certain amount of logs based on the event mask from USB exported data in an efficient way.
- [BS2_GetLogSmallBlobExFromDirWithKey](#): [+2.8.2] Gets certain amount of logs including temperature information based on the event mask from USB exported data in an efficient way.
- [BS2_GetUserInfosFaceExFromDirWithKey](#): [+2.8.2] Gets the user information of the given user ID from USB exported data.
- [BS2_GetUserDatasFaceExFromDirWithKey](#): [+2.8.2] Gets the user information of the given user ID & usermask from USB exported data.

From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar Device SDK**

Permanent link:

http://kb.supremainc.com/bs2sdk/doku.php?id=en:use_exported_control_api&rev=1650844622

Last update: **2022/04/25 08:57**