

BS2_GetAllInterlockZoneStatus 1
..... 1
..... 1
..... 1
..... 1

BS2_GetAllInterlockZoneStatus

가 .

```
#include "BS_API.h"

int BS2_GetAllInterlockZoneStatus(void* context, uint32_t deviceId,
uint32_t* zoneIds, uint32_t zoneIdCount, BS2ZoneStatus** zoneStatusObj,
uint32_t* numZoneStatus);
```

BS2ZoneStatus

- [In] *context* : Context
- [In] *deviceId* :
- [In] *zoneIds* : 가 id
- [In] *zoneIdCount* : id
- [Out] *zoneStatusObj* : zone status
- [Out] *numZoneStatus* : zone status

zoneStatusObj [BS2_ReleaseObject](#)

BS_SDK_SUCCESS , 가

[BS2_GetInterlockZone](#)
[BS2_GetInterlockZoneStatus](#)

[BS2_SetInterlockZone](#)
[BS2_SetInterlockZoneAlarm](#)
[BS2_RemoveInterlockZone](#)
[BS2_RemoveAllInterlockZone](#)

From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar 2 Device SDK**

Permanent link:

http://kb.supremainc.com/bs2sdk/doku.php?id=ko:bs2_getallinterlockzonestatus&rev=1520397341

Last update: **2018/03/07 13:35**