

BS2_GetAllScheduledLockUnlockZone 1
..... 1
..... 1
..... 1
..... 1

BS2_GetAllScheduledLockUnlockZone


/ 가 .

```
#include "BS_API.h"

int BS2_GetAllScheduledLockUnlockZone(void* context, uint32_t deviceId,
BS2ScheduledLockUnlockZone** zoneObj, uint32_t* numZone);
```

BS2ScheduledLockUnlockZone

- [In] *context* : Context
- [In] *deviceId* :
- [Out] *zoneObj* : scheduled lock/unlock zone
- [Out] *numZone* : scheduled lock/unlock zone



BS_SDK_SUCCESS , 가

- [BS2_GetScheduledLockUnlockZone](#)
- [BS2_GetScheduledLockUnlockZoneStatus](#)
- [BS2_GetAllScheduledLockUnlockZoneStatus](#)
- [BS2_SetScheduledLockUnlockZone](#)
- [BS2_SetScheduledLockUnlockZoneAlarm](#)

[BS2_RemoveScheduledLockUnlockZone](#)

[BS2_RemoveAllScheduledLockUnlockZone](#)

From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar 2 Device SDK**

Permanent link:

http://kb.supremainc.com/bs2sdk./doku.php?id=ko:bs2_getallscheduledlockunlockzone

Last update: **2016/07/12 09:47**