

**BS2\_GetAllScheduledLockUnlockZoneStatus** ..... 1  
..... 1  
..... 1  
..... 1  
..... 1

# BS2\_GetAllScheduledLockUnlockZoneStatus

/ 가 .

```
#include "BS_API.h"

int BS2_GetAllScheduledLockUnlockZoneStatus(void* context, uint32_t
deviceId, BS2ZoneStatus** zoneStatusObj, uint32_t* numZoneStatus);
```

BS2ZoneStatus

- [In] *context* : Context
- [In] *deviceId* :
- [Out] *zoneStatusObj* : zone status
- [Out] *numZoneStatus* : zone status

zoneStatusObj	BS2_ReleaseObject
---------------	-------------------

BS\_SDK\_SUCCESS , 가

- [BS2\\_GetScheduledLockUnlockZone](#)
- [BS2\\_GetAllScheduledLockUnlockZone](#)
- [BS2\\_GetScheduledLockUnlockZoneStatus](#)
- [BS2\\_SetScheduledLockUnlockZone](#)
- [BS2\\_SetScheduledLockUnlockZoneAlarm](#)

[BS2\\_RemoveScheduledLockUnlockZone](#)

[BS2\\_RemoveAllScheduledLockUnlockZone](#)

From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar 2 Device SDK**

Permanent link:

[http://kb.supremainc.com/bs2sdk./doku.php?id=ko:bs2\\_getallscheduledlockunlockzonestatus](http://kb.supremainc.com/bs2sdk./doku.php?id=ko:bs2_getallscheduledlockunlockzonestatus)

Last update: **2016/07/12 10:02**