

BS2_GetAllTimedAntiPassbackZone 1
..... 1
..... 1
..... 1
..... 1

BS2_GetAllTimedAntiPassbackZone

가 .

```
#include "BS_API.h"

int BS2_GetAllTimedAntiPassbackZone(void* context, uint32_t deviceId,
BS2TimedAntiPassbackZone** zoneObj, uint32_t* numZone);
```

[BS2TimedAntiPassbackZone](#)

- [In] *context* : Context
- [In] *deviceId* :
- [Out] *zoneObj* : timed anti-passback zone
- [Out] *numZone* : timed anti-passback zone



BS_SDK_SUCCESS , 가

- [BS2_GetTimedAntiPassbackZone](#)
- [BS2_GetTimedAntiPassbackZoneStatus](#)
- [BS2_GetAllTimedAntiPassbackZoneStatus](#)
- [BS2_SetTimedAntiPassbackZone](#)
- [BS2_SetTimedAntiPassbackZoneAlarm](#)

[BS2_RemoveTimedAntiPassbackZone](#)
[BS2_RemoveAllTimedAntiPassbackZone](#)
[BS2_ClearTimedAntiPassbackZoneStatus](#)
[BS2_ClearAllTimedAntiPassbackZoneStatus](#)

From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar 2 Device SDK**

Permanent link:

http://kb.supremainc.com/bs2sdk./doku.php?id=ko:bs2_getalltimedantipassbackzone

Last update: **2016/07/12 09:47**