

BS2_GetAllTimedAntiPassbackZoneStatus 1
..... 1
..... 1
..... 1
..... 1

BS2_GetAllTimedAntiPassbackZoneStatus


가 .

```
#include "BS_API.h"

int BS2_GetAllTimedAntiPassbackZoneStatus(void* context, uint32_t deviceId,
BS2ZoneStatus** zoneStatusObj, uint32_t* numZoneStatus);
```

[BS2ZoneStatus](#)

- [In] *context* : Context
- [In] *deviceId* :
- [Out] *zoneStatusObj* : zone status
- [Out] *numZoneStatus* : zone status



BS_SDK_SUCCESS , 가

- [BS2_GetTimedAntiPassbackZone](#)
- [BS2_GetAllTimedAntiPassbackZone](#)
- [BS2_GetTimedAntiPassbackZoneStatus](#)
- [BS2_SetTimedAntiPassbackZone](#)
- [BS2_SetTimedAntiPassbackZoneAlarm](#)

[BS2_RemoveTimedAntiPassbackZone](#)
[BS2_RemoveAllTimedAntiPassbackZone](#)
[BS2_ClearTimedAntiPassbackZoneStatus](#)
[BS2_ClearAllTimedAntiPassbackZoneStatus](#)

From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar 2 Device SDK**

Permanent link:

http://kb.supremainc.com/bs2sdk./doku.php?id=ko:bs2_getalltimedantipassbackzonestatus

Last update: **2016/07/12 10:03**