

BS2_GetInterlockZoneStatus 1

..... 1

..... 1

..... 1

..... 1

BS2_GetInterlockZoneStatus

[+ V2.6.0]


가 .

```
#include "BS_API.h"

int BS2_GetInterlockZoneStatus(void* context, uint32_t deviceId, uint32_t* zoneIds, uint32_t zoneIdCount, BS2ZoneStatus** zoneStatusObj, uint32_t* numZoneStatus);
```

[BS2ZoneStatus](#)

- [In] *context* : Context
- [In] *deviceId* :
- [In] *zoneIds* : 가 id
- [In] *zoneIdCount* : id
- [Out] *zoneStatusObj* : zone status
- [Out] *numZoneStatus* : zone status



BS_SDK_SUCCESS , 가

[BS2_GetInterlockZone](#)
[BS2_GetAllInterlockZoneStatus](#)

[BS2_SetInterlockZone](#)
[BS2_SetInterlockZoneAlarm](#)
[BS2_RemoveInterlockZone](#)
[BS2_RemoveAllInterlockZone](#)

From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar 2 Device SDK**

Permanent link:

http://kb.supremainc.com/bs2sdk/doku.php?id=ko:bs2_getinterlockzonestatus

Last update: **2018/03/11 20:42**