

**BS2\_GetInterlockZoneStatus** ..... 1  
..... 1  
..... 1  
..... 1  
..... 1

# BS2\_GetInterlockZoneStatus

가 .

```
#include "BS_API.h"

int BS2_GetInterlockZoneStatus(void* context, uint32_t deviceId, uint32_t* zoneIds, uint32_t zoneIdCount, BS2ZoneStatus** zoneStatusObj, uint32_t* numZoneStatus);
```

## BS2ZoneStatus

- [In] *context* : Context
- [In] *deviceId* :
- [In] *zoneIds* : 가 id
- [In] *zoneIdCount* : id
- [Out] *zoneStatusObj* : zone status
- [Out] *numZoneStatus* : zone status

zoneStatusObj      [BS2\\_ReleaseObject](#)

BS\_SDK\_SUCCESS , 가

[BS2\\_GetInterlockZone](#)  
[BS2\\_GetAllInterlockZoneStatus](#)

[BS2\\_SetInterlockZone](#)  
[BS2\\_SetInterlockZoneAlarm](#)  
[BS2\\_RemoveInterlockZone](#)  
[BS2\\_RemoveAllInterlockZone](#)

From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar 2 Device SDK**

Permanent link:

[http://kb.supremainc.com/bs2sdk./doku.php?id=ko:bs2\\_getinterlockzonestatus&rev=1520397225](http://kb.supremainc.com/bs2sdk./doku.php?id=ko:bs2_getinterlockzonestatus&rev=1520397225)

Last update: **2018/03/07 13:33**