

BS2_GetOsdpStandardDevice 1

..... 1

..... 1

..... 1

..... 1

(C++) 1

(C#) 2

[Slave Control API](#) > [BS2_GetOsdpStandardDevice](#)

BS2_GetOsdpStandardDevice

[+ 2.8.4] CoreStation40 OSDP 가 .

```
#include "BS_API.h"

int BS2_GetOsdpStandardDevice(void* context, uint32_t osdpDeviceId,
BS2OsdpStandardDevice* osdpDevice);
```

[BS2OsdpStandardDevice](#)

- [In] *context* : Context
- [In] *osdpDeviceId* : OSDP
- [Out] *osdpDevice* : OSDP

BS_SDK_SUCCESS , 가

[BS2_AddOsdpStandardDevice](#)
[BS2_GetOsdpStandardDevice](#)
[BS2_GetAvailableOsdpStandardDevice](#)
[BS2_UpdateOsdpStandardDevice](#)
[BS2_RemoveOsdpStandardDevice](#)
[BS2_GetOsdpStandardDeviceCapability](#)
[BS2_SetOsdpStandardDeviceSecurityKey](#)

(C++)

[sample_bs2_getosdpstandarddevice.cpp](#)

```
BS2osdpStandardDevice osdpDevice = { , };

BS2_DEVICE_ID osdpID = Utility::selectSlaveID();
int sdkResult = BS2_GetOsdpStandardDevice(context_, osdpID,
&osdpDevice);
if (BS_SDK_SUCCESS != sdkResult)
    printf("BS2_GetOsdpStandardDevice call failed: %d", sdkResult);

return sdkResult;
```

(C#)

[sample_bs2_getosdpstandarddevice.cs](#)

```
UInt32 id = Util.GetInputSlaveID();

BS2osdpStandardDevice osdpDevice;
BS2ErrorCode result =
(BS2ErrorCode)API.BS2_GetOsdpStandardDevice(sdkContext, id, out
osdpDevice);
if (result != BS2ErrorCode.BS_SDK_SUCCESS)
    Console.WriteLine("Got error({0}).", result);
else
    Console.WriteLine("Call success.");

return result;
```

From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar 2 Device SDK**

Permanent link:

http://kb.supremainc.com/bs2sdk/doku.php?id=ko:bs2_getosdpstandarddevice&rev=1675928043

Last update: **2023/02/09 16:34**