

**BS2\_RemoveAllIntrusionAlarmZone** ..... 1

..... 1

..... 1

..... 1

..... 1

[Zone Control API](#) > [BS2\\_RemoveAllScheduledLockUnlockZone](#)

---

## BS2\_RemoveAllIntrusionAlarmZone

```
#include "BS_API.h"

int BS2_RemoveAllIntrusionAlarmZone(void* context, uint32_t deviceId);
```

- [In] *context* : Context
- [In] *deviceId* :

BS\_SDK\_SUCCESS , 가

[BS2\\_GetIntrusionAlarmZone](#)  
[BS2\\_GetIntrusionAlarmZoneStatus](#)  
[BS2\\_GetAllIntrusionAlarmZoneStatus](#)  
[BS2\\_SetIntrusionAlarmZone](#)  
[BS2\\_SetIntrusionAlarmZoneAlarm](#)  
[BS2\\_RemoveIntrusionAlarmZone](#)  
[BS2\\_SetIntrusionAlarmZoneArm](#)

From:  
<http://kb.supremainc.com/bs2sdk/> - **BioStar 2 Device SDK**

Permanent link:  
[http://kb.supremainc.com/bs2sdk/doku.php?id=ko:bs2\\_removeallintrusionalarmzone&rev=1504480741](http://kb.supremainc.com/bs2sdk/doku.php?id=ko:bs2_removeallintrusionalarmzone&rev=1504480741)

Last update: **2017/09/04 08:19**