

BS2_RemoveLift 1
..... 1
..... 1
..... 1
..... 1

BS2_RemoveLift

Lift


```
#include "BS_API.h"

int BS2_RemoveLift(void* context, uint32_t deviceId, uint32_t* liftIds,
uint32_t liftIdCount);
```

- [In] *context* : Context
- [In] *deviceId* :
- [In] *liftIds* : lift id
- [In] *liftIdCount* : lift id

BS_SDK_SUCCESS , 가

- [BS2_GetLift](#)
- [BS2_GetAllLift](#)
- [BS2_GetLiftStatus](#)
- [BS2_GetAllLiftStatus](#)
- [BS2_SetLift](#)
- [BS2_SetLiftAlarm](#)
- [BS2_RemoveAllLift](#)
- [BS2_ReleaseFloor](#)
- [BS2_ActivateFloor](#)
- [BS2_DeActivateFloor](#)



From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar 2 Device SDK**

Permanent link:

http://kb.supremainc.com/bs2sdk./doku.php?id=ko:bs2_removelift

Last update: **2017/06/28 11:42**