

**Slave Control API** ..... 1  
..... 1  
BS2Rs485SlaveDevice ..... 1  
BS2Rs485SlaveDeviceEX ..... 1

# Slave Control API

## RS485

- [BS2\\_GetSlaveDevice](#): RS485
- [BS2\\_SetSlaveDevice](#): 가/ /
- [BS2\\_GetSlaveExDevice](#): CoreStation RS485
- [BS2\\_SetSlaveExDevice](#): CoreStation 가/ /
- [BS2\\_SearchDevicesCoreStation](#): CoreStation
- [BS2\\_GetDevicesCoreStation](#): CoreStation

SDK가 가

## BS2Rs485SlaveDevice

```
typedef struct {
    uint32_t deviceID;
    uint16_t deviceType;
    uint8_t enableOSDP;
    uint8_t connected;
} BS2Rs485SlaveDevice;
```

1. *deviceID*

2. *deviceType*

3. *enableOSDP*

flag

4. *connected*

가

flag

## BS2Rs485SlaveDeviceEX

```
typedef struct {
    uint32_t deviceID;
```

```

uint16_t deviceType;
uint8_t enableOSDP;
uint8_t connected;
uint8_t channelInfo;
uint8_t reserved[3];
} BS2Rs485SlaveDeviceEX;

```

1. *deviceID*

2. *deviceType*

3. *enableOSDP*

flag

4. *connected*

가

flag

5. *channelInfo*

Channel

6. *reserved*

From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar 2 Device SDK**

Permanent link:

[http://kb.supremainc.com/bs2sdk./doku.php?id=ko:slave\\_control\\_api&rev=1538714716](http://kb.supremainc.com/bs2sdk./doku.php?id=ko:slave_control_api&rev=1538714716)

Last update: **2018/10/05 13:45**